

159
160
90A
148
115
57
146
158
4A
3A
3
3B
105
104
12A
121
31
120
37
37A
37B
100
54
117
53
116
11
31A
118
127
156
155
166
145
113
52
112
12
122
123
119
40
124
65
125
151
152
139
137
140
64
2
1
167
11A
103
134
135
138
126
133
136
165
164
154
107
101
106
108
109
110
102
84
111
113
51
175
861
170
129
147
130
131
142
141
40A
132
143
144
123
122
12
65A

Parts List for 362V Type 8

Item Number	Part Number	Description	Qty Required
1	909832	ARMATURE	1
2	887416	FIELD (360VS 362VS)	1
2	803104	LEAD	1
3	N031635	BRUSH & SPRING	2
3	803483	BRUSH CAP	2
3	873497	BRUSH HOLDER	2
4	5140066-97	SWITCH	1
4	5140066-97	SWITCH	1
4	883201	SWITCH VS(360/2 VS)	1
5	882313	CORD	1
11	803876SV	BEARING	3
11	883202SV	BEARING	3
12	804211	BEARING,NEEDLE	3
12	803846SV	BEARING	3
31	896468	GEAR	1
31	D883500	PINION	1
37	903809	BELT	1
37	903840	DRIVE PULLEY	1
37	904252	DRIVEN PULLEY	1
40	883196	SHAFT DRIVE PULLEY 4	1
40	885104	PULLEY SHAFT 4	1
51	894943	FRAME	1
52	5140060-87	HOUSING KIT	1
53	882859	GEAR HSG COVER	1
54	910499	COVER-BELT	1
57	A23100	HANDLE SET	1
64	839306	FRAME PROTECTOR BAR	1

COPYRIGHT© 2005. All Rights Reserved.
Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for 362V Type 8

Item Number	Part Number	Description	Qty Required
65	823466	DRIVE PULLEY	1
65	698496	PULLEY	1
84	A03070	SS/A HANDLE SET	1
90	873366	PLASTIC TIE	1
90	696167	DUST BAG ASSY-	1
90	692639	DUST BAG	1
100	883485	SCREW	10
101	888117	GASKET	1
102	883782	RUBBER PLUG	1
103	883483	SCREW	10
104	802388	SCREW	10
105	803496	WASHER	10
106	883183	BAFFLE-COOLING SEC	1
107	883182	BAFFLE-COOLING PRIM	1
108	883010	DUST BAFFLE	1
109	883482	SCREW	10
110	886538	SCREW	10
111	879678	SCREW	10
112	892780	SCREW	10
113	883480	SCREW	10
114	694010	SCREW	10
115	882185	SCREW MACHINE STEEL	10
116	883192	GEAR HSG GASLET	1
117	883486	SCREW	10
118	855284	BEARING	3
119	878563	KEY	1
120	801372	NUT	10

COPYRIGHT© 2005. All Rights Reserved.
Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for 362V Type 8

Item Number	Part Number	Description	Qty Required
121	802942	RING	10
122	801852	SEAL	1
123	803365	CAP	1
124	803341	WASHER	10
125	823254	NUT	10
126	912484	TRACKING BOX	1
127	883479	SCREW	10
129	908909	SHOE ASSY	1
130	908909	SHOE ASSY	1
131	852310	SCREW	10
131	876384	SCREW	10
132	887650	YOKE	1
133	698507	CONTROL PLATE	1
134	883477	SCREW	10
135	698511	WEAR PLATE	1
136	698502	LEVER	1
137	848741	WASHER	10
138	874194	SHOULDER SCREW	10
139	858136	NUT	10
140	698504	SPRING	10
141	873946	SPRING	10
142	698500	SPRING	10
143	853455	RING	10
144	803317	WASHER	10
145	873945	SPRING	10
146	878262	SCREW	1
147	886988	COVER PLATE 4	1

COPYRIGHT© 2005. All Rights Reserved.
Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for 362V Type 8

Item Number	Part Number	Description	Qty Required
148	861434	CORD CLAMP	1
150	682063	CONNECTOR VS	1
151	883299	FIBER WASHER	10
153	887098	LEAD-ASSY360VS 362VS	1
154	888569	GASKET	1
155	897159	KNOB	1
156	883484	SCREW	10
158	839330	SPRING ELBOW RE	1
159	877967	BAG SUPPORT	1
160	882671	ELBOW/SUPPORT KIT	1
164	878499	TUBE GREASE	1
165	879751	LUBRICANT 4 LBS	1
166	894223	SCREW	10
167	896743	COVER	1
170	804204	CORK COVERING	1
861	A02028	CASE-CARRYING	1

COPYRIGHT© 2005. All Rights Reserved.
Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.