SERVICE PARTS LIST

BULLETIN NO.
55-40-6570

SPECIFY CATALOG NO. AND SERIAL NO. WHEN ORDERING PARTS				REVISED BULLETIN	DATE
1-1/4" STROKE SAWZALL®					Sept. 2012
CATALOG NUMBER	**6538-59**	STARTING SERIAL NO.	**D82A**	WIRING INSTRUCTION	**See Page 3**

EXAMPLE:
Component Parts (Small #) Are Included When Ordering The Assembly (Large #).





FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.
1	02-04-0845	Ball Bearing	(1)
2	02-04-0915	Ball Bearing	(1)
3	02-04-1511	Ball Bearing	(1)
4	02-50-2150	Needle Bearing	(1)
5	05-88-0302	K50 x 60mm Washer Hd. PT Screw	(4)
6	06-55-3790	5/16-24 Spinlock Hex Nut	(1)
7	06-65-0045	Dowel Pin	(2)
8	43-36-0125	Cam Follower	(1)
9	----------	Orbit Pivot Pin	(2)
10	06-82-7253	8-32 x .38 Taptite T-20 Screw	(3)
11	06-82-7255	DG50 x 10mm Screw	(3)
12	06-82-7270	8-16 x .625 Slt. Plastite T-20 Screw	(6)
13	06-82-7326	8-16 x 1" Slt. Plastite T-20 Screw	(2)
14	06-82-7453	8-16 x 2.25 Slt. Plastite T-20 Screw	(2)
15	06-82-8870	1/2-DG50 Thread Form Screw	(4)
16	06-82-7330	4-20 x .875 Plastite T-10 Screw	(1)
17	----------	Nameplate	(1)
18	14-20-1105	Remote Electronics Assembly	(1)
19	14-67-0126	Secondary Wobble Plate Assembly	(1)
20	14-67-0136	Primary Wobble Plate Assembly	(1)
21	16-34-6538	Service Armature	(1)
22	18-34-6538	Service Field	(1)
23	22-20-6538	Carbon Brush Assembly	(2)
24	22-64-0111	Cord Assembly	(1)
25	23-66-2490	Switch	(1)
26	22-56-0625	Terminal Block	(1)
29	14-30-0080	Orbit Pocket Assembly	(2)
30	28-14-2600	Gearcase	(1)
31	28-28-2600	Diaphragm	(1)
32	31-05-0155	Baffle	(1)
33	31-11-0130	Orbital Cam Plate	(1)
34	31-15-0170	Spring Cover	(1)
35	31-44-2090	Handle Half - Right	(1)
36	31-44-2095	Handle Half - Left	(1)
37	31-50-6538	Motor Housing	(1)
38	31-52-0045	Orbit Shift Lever	(1)
39	31-52-0090	Shoe Release Lever	(1)
40	32-40-2050	Intermediate Gear	(1)
41	34-40-0040	O-Ring	(2)
42	34-60-0125	Retaining Ring	(1)
43	34-60-1315	External Retaining Ring	(2)
44	34-60-3700	Retaining Ring	(1)
45	36-92-0701	Wobble Shaft	(1)
46	38-50-6400	Reciprocating Spindle	(1)
47	40-50-0162	Torsion Spring	(1)
48	40-50-8850	Disc Spring	(1)
49	42-12-0190	Wobble Shaft Axle	(1)
50	42-24-0066	Front Spindle Bushing	(1)
51	42-24-0525	Rear Spindle Bushing	(1)
52	42-38-0055	Orbit Bumper	(1)
53	42-50-0355	Front Cam	(1)
54	42-50-0360	Rear Cam	(1)
55	42-52-0380	Bearing Cap	(1)

FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.
56	42-87-0180	Counter Weight	(1)
57	43-06-0676	Bronze Plate	(1)
58	43-06-0685	Metal Plate	(2)
60	43-56-0620	Orbit Plate	(1)
61	43-78-0576	Orbit Drive Hub	(1)
64	44-60-1635	Shoe Pin	(1)
65	44-60-1750	Lock Pin	(1)
66	44-66-0880	Shoe Retainer	(1)
67	44-86-0035	Front Orbit Cap	(1)
68	44-86-0655	Bearing Retainer	(1)
69	45-06-0110	Orbit Seal	(1)
70	45-06-0475	Polypak Seal	(1)
71	45-12-0700	Gearcase Insulator	(1)
72	45-16-0645	Shoe Assembly	(1)
73	45-22-0175	Sleeve	(1)
74	45-28-0555	Slinger	(1)
75	45-36-1445	Spacer	(1)
76	45-88-1555	Washer	(1)
77	45-88-8577	Washer	(1)
78	22-84-0531	Fan	(1)
79	44-76-0210	Cord Protector	(1)
80	14-46-1060	Large Quik-Lok Blade Clamp	(1)
81	14-08-0075	Gear Protecting Clutch Assembly	(1)
82	23-38-0200	Magnet (Tachometer)	(1)
83	31-17-0260	Cord Clamp	(1)
84	31-17-0265	Cord Clamp	(1)
87	45-06-0501	Felt Seal	(1)
88	42-55-2051	Carrying Case	(1)
	23-94-0100	Leadwire Assembly - Black (Not Shown)	(2)
	23-94-0305	Leadwire Assembly - White (Not Shown)	(2)


MILWAUKEE ELECTRIC TOOL CORPORATION
13135 W. LISBON RD., BROOKFIELD, WI 53005

FIG.	NOTES:
1	Bearing to be installed with seal towards commutator.
4,31	Press needle bearing flush ±.005 with inner surface of diaphragm.
6,49	Apply Blue Loctite® 242 to treads of wobble shaft axle prior to installing spinlock hex nut. Torque spinlock hex nut to 160-190 in. lbs.
6,40	Hold the intermediate gear still with a large pair of pliers and a piece of rubber hose (or other tough, but pliable material to protect the gear from the jaws of the pliers) and remove the 5/16" spinlock hex nut with a wrench, as shown.



Service Fixture
61-10-0270
(Pressing Pin Tool)

7,46,50,51,56	Press dowel pins flush to front side of front spindle bushing. Press dowel pins flush to back side of rear spindle bushing. **NOTE:** Reciprocating spindle (46) and counter weight (56) must be installed inside assembly (7,50) and (7,51) prior to pressing last spindle bushing into place. Be sure to orientate the counter weight with the hole on bottom towards rear spindle bushing, as shown.
17,37	Install nameplate in motor housing recess prior to assembling diaphragm onto motor housing.
29,42	**Service fixture #61-10-0205** must be used when installing retaining ring (42) onto orbit pocket assembly (29).
40,57	Tabs of bronze plate engage intermediate gear.
40,48	Concave side of disc spring towards intermediate gear.
58,61	Tabs of metal plates engage orbit drive hub.
70	O-ring of polypak seal faces mechanism - toward rear of tool.
74	Shoulder extension of grease slinger should face bearing.




REMOVING THE STEEL QUIK-LOK® BLADE CLAMP

- Remove external retaining ring (44) and pull front cam (53) off.
- Pull lock pin (65) out and remove remainder of parts and discard.

REASSEMBLY OF THE STEEL QUIK-LOK® BLADE CLAMP

- Coat new lock pin with powdered graphite.
- Hold tool in a vertical position.
- Place spring cover (34) onto spindle.
- Slide torsion spring (47) onto spindle shaft with leg positioned at the 6:00 position.
- Slide sleeve (73) onto spindle aligning hole on sleeve with hole in spindle.
- Slide rear cam (54) over sleeve, aligning hole in rear cam with spring leg. Ensure spring leg inserts into hole in rear cam.
- Rotate rear cam (54) counter clockwise until there is clearance for lock pin (65) to be inserted into sleeve/spindle holes. Insert lock pin.
- Align front cam (53) inner ribs with rear cam outer slots *(see insert)* and slide front cam onto sleeve until it bottoms. Retaining ring (44) groove should be completely visible.
- Attach retaining ring by separating coils and inserting end of ring into groove, then wind remainder of ring into groove. Ensure ring is seated in groove.
- Blade clamp should rotate freely. During normal usage, debris may not allow blade clamp to rotate freely. The use of spray lubricant can help free blade clamp. In extreme conditions, follow these instructions to remove, clean and reassemble blade clamp.









FIG.	LUBRICATION:
29,41	Lightly coat o-rings with lubrication for ease of installation onto assembled orbit pockets.
30	Place 3.2 oz. (80 grams ± 8 grams) of type "T" grease (Cat. No. 49-08-4290), in mechanism cavity of gear case.
31	Place .8 oz. (20 grams ± 2 grams) of type "T" grease (Cat. No. 49-08-4290), in lower needle bearing-gear train cavity of diaphragm.
40,58	Apply a thin coat of type "T" grease (Cat. No. 49-08-4290) between gear and metal plate.
65	Pin to be coated with graphite prior to assembly.
87	Soak in lightweight bushing oil prior to assembly.





AS AN AID TO REASSEMBLY, TAKE NOTICE OF WIRE ROUTING AND POSITION IN WIRE GUIDES AND TRAPS WHILE DISMANTLING TOOL.

BE CAREFUL AND AVOID PINCHING WIRES BETWEEN HANDLE HALVES WHEN ASSEMBLING.









Prior to installing black module wires #1 and white module wire #3 onto switch, place a sleeve (23-48-6538) over each wire and slide towards module. Locate both sleeves between the module and the adjacent wire traps.

WIRING SPECIFICATIONS

Wire No.	Wire Color	Origin or Gauge	Length	Terminals, Connectors and 1 or 2 End Wire Preparation
1	Black	14-20-1105	-----	Component of the speed control module. Connect to position '2' on the back of the on-off switch.
2	Yellow	14-20-1105	-----	Component of the speed control module. Connect to the bottom right field terminal.
3	White	14-20-1105	-----	Component of the speed control module. Connect to position '1' on the back of the on-off switch.
4	Black	14-20-1105	-----	Component of the speed control module. Connect to position '3' on the left side of the on-off switch.
5	White	14-20-1105	-----	Component of the speed control module. Connect to position '4' on the left side of the on-off switch.
6	Black	23-94-0100	-----	Leadwire assy. Connect one end to terminal block opposite brown cord wire #10. Connect the other end to position '2↑' on switch.
7	Black	23-94-0100	-----	Leadwire assy. Connect one end to terminal block opposite blue cord wire #11. Connect the other end to position '1↑' on switch.
8	Black	14-20-1105	-----	Component of the speed control module. Connect to the upper left field terminal.
9	Blue	14-20-1105	-----	Component of the speed control module. Connect to position '5' on the left side of the on-off switch.
10	Brown	22-64-4523	-----	Component of the power cord set. Connect to terminal block opposite black leadwire #6.
11	Blue	22-64-4523	-----	Component of the power cord set. Connect to terminal block opposite black leadwire #7.
12	White	23-94-0305	-----	Leadwire assembly. Connect one end to the upper right field terminal. Connect the other end to the upper brush tube terminal.
13	White	23-94-0305	-----	Leadwire assembly. Connect one end to the lower left field terminal. Connect the other end to the lower brush tube terminal.