
# JET EHB-1018V | Stock 891060

## Diagram A - Stand and Bed

Band Saw | Original JET parts reference




mmToolParts
Big Time Experience. Small Town Service. .com

# JET EHB-1018V | Stock 891060

## Parts List A - Stand and Bed

Band Saw | Original JET parts reference

| Ref. | Part number | Description | Size | Qty. |
|---|---|---|---|---|
| 1 | EHB916V-64 | Fitting | | 2 |
| 2 | EHB916V-65 | Tubing | 5/16" × 65". | 2 |
| 3 | EHB916V-66 | Valve | | 1 |
| 4 | EHB916V-67 | Feed Knob | | 1 |
| 5 | EHB916V-101 | Cable Gland | PG-11 | 5 |
| 6 | TS-0209071 | Socket Head Cap Screw | 3/8 × 1-1/2" | 2 |
| 7 | EHB916V-191 | Special Washer | | 2 |
| 8 | EHB1018V-192 | Vise Jaw Bracket | | 1 |
| 9 | EHB916V-193 | Roll Pin | M5 x 20 | 1 |
| 10 | EHB916V-194 | Bracket | | 1 |
| 11 | EHB916V-195 | Acme Nut Assembly | | 1 |
| 12 | EHB916V-196 | Button | | 1 |
| 13 | EHB916V-197 | Retainer | | 1 |
| 14 | TS-0680011 | Flat Washer | 3/16" | 2 |
| 15 | EHB916V-199 | Round Head Screw | 3/16" x 3/8" | 1 |
| 16 | EHB916V-200 | Block | | 1 |
| 17 | EHB1018V-201 | Vise Jaw Bracket (fi xed) | | 1 |
| 18 | EHB916V-191 | Special Washer | | 2 |
| 19 | TS-0209061 | Socket Head Cap Screw | 3/8 ×1-1/4" | 2 |
| 20 | TS-0070031 | Hex Cap Screw | 1/2-13 ×1-1/2" | 1 |
| 21 | TS-0561031 | Hex Nut | 3/8" | 1 |
| 22 | EHB916V-206 | Limit Switch | | 1 |
| 23 | EHB916V-207 | Limit Switch Seat(Ser No.13100009 and lower) | | 1 |
| | EHB916V-207N | Limit Switch Seat (Ser No.xxxx0010 and higher) | | 1 |
| | EHB1018V-OHCA | Oil Hydraulic Cylinder As-sembly (includes # 24-34) | | 1 |
| 24 | EHB916V-210 | Cap | | 1 |

mmToolParts
Big Time Experience. Small Town Service. .com

# JET EHB-1018V | Stock 891060

## Parts List A - Stand and Bed (continued)

Band Saw | Original JET parts reference

| Ref. | Part number | Description | Size | Qty. |
|---|---|---|---|---|
| 25 | EHB916V-211 | Oil Seal | 20.35.7 | 1 |
| 26 | EHB916V-213 | Rod | | 1 |
| 27 | TS-0680031 | Flat Washer | 5/16" | 1 |
| 28 | EHB916V-215 | Piston | | 1 |
| 29 | EHB916V-216 | Seal | | 1 |
| 30 | EHB916V-217 | Inoin ring | P53 | 1 |
| 31 | TS-0561021 | Hex Nut | 5/16" x 18T | 2 |
| 32 | EHB1018V-219 | Tube Assembly | | 1 |
| 33 | EHB916V-221 | Tube Fitting | | 1 |
| 34 | EHB916V-222 | Tube Fitting | | 1 |
| 35 | EHB916V-223 | Retaining Ring | S-17 | 1 |
| 36 | EHB916V-224 | Pivot shaft | | 1 |
| 37 | EHB916V-225 | Socket Set Screw | 3/8"-16T × 3/8" | 1 |
| 38 | TS-0680031 | Flat Washer | 5/16" | 4 |
| 39 | TS-0051051 | Hex Cap Screw | 5/16 × 1" | 4 |
| 40 | EHB916V-232 | Motor Plate | | 1 |
| 41 | EHB1018V-233 | Rear Pivot Bracket | | 1 |
| 42 | EHB916V-234 | Special Socket Set Screw | 1/2" x 2" | 2 |
| 43 | EHB916V-235 | Hex Nut | 1/2"-12 | 2 |
| 44 | TS-0209081 | Socket Head Cap Screw | 3/8"-16T × 1-3/4" | 3 |
| 45 | TS-0680041 | Flat Washer | 3/8" | 3 |
| 46 | TS-0050031 | Hex Cap Screw | 1/4-20T × 3/4" | 1 |
| 47 | TS-0680021 | Flat Washer | 1/4" | 1 |
| 48 | TS-0271051 | Set Screw | 3/8"-16 × 1/2" | 1 |
| 49 | EHB916V-241 | Strap | | 1 |
| 50 | TS-0680021 | Flat Washer | 1/4" | 2 |
| 51 | EHB916V-243 | Hex Cap Screw | 1/4-20T ×3/4" | 2 |

mmToolParts
Big Time Experience. Small Town Service. .com

# JET EHB-1018V | Stock 891060

## Parts List A - Stand and Bed (continued)

Band Saw | Original JET parts reference

| Ref. | Part number | Description | Size | Qty. |
|---|---|---|---|---|
| 52 | EHB916V-26 | Special Washer | | 1 |
| 53 | EHB916V-245 | Knob | | 1 |
| 54 | EHB1018V-247 | Bed | | 1 |
| 55 | EHB916V-248 | Pin | | 1 |
| 56 | EHB916V-249 | Hand Wheel | | 1 |
| 56-1 | EHB916V-249-1 | Handle | | 1 |
| 57 | EHB1018V-252 | Acme Screw | | 1 |
| 57-1 | EHB916V-252-1 | Collar | | 1 |
| 58 | EHB916V-253 | Roll Pin | 6 ø ×30 ø | 1 |
| 59 | EHB1018V-254 | Work Support | | 1 |
| 60 | TS-0680041 | Flat Washer | 3/8" | 2 |
| 61 | TS-0060061 | Hex Cap Screw | 3/8" ×1-1/4" | 2 |
| | EHB1018V-SA | Adj. Stock Stop Assembly (includes #62-66) | | 1 |
| 62 | TS-0060061 | Hex Cap Screw | 3/8" ×1-1/4" | 1 |
| 63 | EHB1018V-258 | Shaft | | 1 |
| 64 | EHB1018V-259 | Stop Bracket | | 1 |
| 65 | EHB1018V-260 | Bar | | 1 |
| 66 | EHB916V-261 | Knob | | 2 |
| 67 | EHB916V-265 | Collar | | 2 |
| 68 | TS-0271031 | Socket Set Screw | 3/8-16T ×3/8" | 4 |
| 69 | EHB916V-267 | Copper | | 2 |
| 70 | TS-0271031 | Socket Set Screw | 3/8-16T ×3/8" | 2 |
| 71 | EHB916V-269 | Pivot Shaft | | 1 |
| 72 | EHB1018V-272 | Base Assembly | | 1 |
| 72-1 | EHB916V-272-1 | Door | | 1 |
| 72-2 | EHB916V-272-2 | Door | | 1 |

mmToolParts
Big Time Experience. Small Town Service. .com

# JET EHB-1018V | Stock 891060

## Parts List A - Stand and Bed (continued)

Band Saw | Original JET parts reference


| Ref. | Part number | Description | Size | Qty. |
|---|---|---|---|---|
| 73 | TS-0060031 | Hex Cap Screw | 3/8" x 3/4" | 2 |
| 74 | TS-0680041 | Flat washer | 3/8" | 2 |
| 75 | EHB-916V-275 | Knob | | 1 |
| 76 | EHB-916V-276 | Adjustable Bolt | | 1 |
| 77 | EHB916V-277 | Spring | | 1 |
| 78 | EHB916V-278 | Gun Set | | 1 |
| 78-1 | EHB916V-278-1 | Hook | | 1 |
| 78-2 | EHB916V-278-2 | Hex Cap Screw | | 2 |
| 79 | EHB916V-281 | Coolant Tank | | 1 |
| 79-1 | EHB1018V-281-1 | Coolant Pump | | 1 |
| 79-2 | EHB916V-281-2 | Pan Head Machine Screw | | 4 |
| 79-3 | EHB916V-96 | 3 Way Coolant Block | | 1 |
| 79-4 | EHB916V-281-4 | Lock W/Key | | 1 |
| 79-5 | EHB916V-281-5 | Lock W/o Key | | 1 |
| 80 | EHB916V-283 | Hex Nut | 1/2"-12T | 4 |
| 81 | EHB916V-284 | Hex Cap Screw | 1/2" -12T x 2" | 4 |
| 82 | EHB1018V-285 | Seat | | 1 |
| 83 | TS-0720081 | Lockwasher | 5/16" | 3 |
| 84 | TS-0051051 | Hex Head Screw | 5/16"-18 ×1" | 3 |
| 85 | EHB916V-289 | Socket Head Button Screw | 3/16" x 3/8" | 8 |
| 86 | EHB916V-300 | Nameplate | | 1 |
| 87 | EHB916V-301 | Start Switch | | 1 |
| 88 | EHB916V-302 | Emergency Switch | | 1 |
| 89 | EHB916V-303 | Selection Switch | | 1 |
| 90 | EHB916V-305 | Indication Light For Power | | 1 |
| 91 | EHB916V-306 | Control Box | | 1 |
| 91-1 | EHB916V-306-1 | Tube | | 1 |

mmToolParts
Big Time Experience. Small Town Service. .com

# JET EHB-1018V | Stock 891060

## Diagram B - Saw Arm

Band Saw | Original JET parts reference




mmToolParts
Big Time Experience. Small Town Service. .com

# JET EHB-1018V | Stock 891060

## Parts List B - Saw Arm

Band Saw | Original JET parts reference

| Ref. | Part number | Description | Size | Qty. |
|---|---|---|---|---|
| 1 | EHB916V-01 | Handwheel | | 1 |
| 1-1 | EHB916V-01-1 | Handwheel handle | | 2 |
| 2 | EHB916V-20 | Lock Nut | | 1 |
| 3 | EHB916V-03 | Shaft | | 1 |
| 4 | EHB916V-04 | Bracket | | 1 |
| 5 | EHB916V-05 | Slide | | 1 |
| 6 | EHB916V-06 | Gib | | 2 |
| 7 | EHB916V-07 | Collar | | 1 |
| 8 | EHB916V-08 | Roll pin | M5x30 | 2 |
| 8-1 | EHB916V-08-1 | Roll pin | M5x40 | 1 |
| 9 | TS-0081031 | Hex Cap Screw | 5/16 x 3/4 | 4 |
| 10 | EHB916V-10 | Adjusting Screw | 3/4 x 1-1/2 | 1 |
| 11 | TS-0060111 | Hex Cap Screw | 3/8 x 2-1/2 | 1 |
| 12 | TS-0271031 | Set Screw | 3/8" x 3/8 | 1 |
| 13 | EHB916V-13 | Spindle | | 1 |
| 14 | BB-51103 | Thrust Bearing | #51103 | 2 |
| 15 | TS-0060061 | Hex Cap Screw | 3/8 x 1-1/4 | 1 |
| 16 | EHB916V-16 | Roll pin | 5 × 30L | 1 |
| 17 | TS-0732061 | Lock Washer | 3/8" | 1 |
| 18 | EHB916V-18 | Driven | | 1 |
| 19 | EHB916V-19 | Thrust Bearing Housing | | 1 |
| 20 | EHB916V-02 | Collar | | 1 |
| 21 | EHB916V-21 | Disc Spring | | 6 |
| 22 | EHB916V-22 | Copper | | 1 |
| 23 | TS-0267041 | Set Screw | 1/4 x 3/8 | 1 |

mmToolParts
Big Time Experience. Small Town Service. .com

# JET EHB-1018V | Stock 891060

## Parts List B - Saw Arm (continued)

Band Saw | Original JET parts reference

| Ref. | Part number | Description | Size | Qty. |
|---|---|---|---|---|
| 24 | TS-0720081 | Lock Washer | 5/16" | 1 |
| 25 | TS-0060051 | Hex Cap Screw | 3/8" x 1" | 1 |
| 26 | EHB916V-26 | Special Washer | | 1 |
| 28 | EHB916V-28 | Wheel L.H. | | 1 |
| 29 | BB-6306ZZ | Bearing | 6306ZZ | 2 |
| 31 | EHB916V-31 | Output Shaft | | 1 |
| 32 | EHB916V-32 | Oil Seal | 32.42.7 | 1 |
| 33 | BB-30207 | Bearing | | 1 |
| 34 | EHB916V-34 | Oil Plug | 1/4" | 1 |
| 35 | EHB916V-35 | Gear Box housing | 1 | |
| 35-1 | EHB916V-35-1 | Cover | 1 | |
| | EHB916V-GBCA | Gear Box Cover Assembly (includes 35, 35-1) | 1 | |
| 36 | TS-0060081 | Hex Cap Screw | 3/8-16 × 3/4" | 3 |
| 37 | TS-0732061 | Lock Washer | 3/8" | 3 |
| 38 | EHB916V-38 | Worm Gear | | 1 |
| 39 | EHB916V-39 | Key | 7 x 7 x 35 | 1 |
| 40 | BB-30206 | Bearing | | 1 |
| 41 | TS-0267121 | Set Screw | 1/4" × 3/4" | 3 |
| 42 | EHB916V-42 | Cap | | 1 |
| 43 | TS-0732061 | Lock Washer | 3/8" | 3 |
| 44 | TS-0060071 | Hex Cap Screw | 3/8"-16 × 1-1/2" | 3 |
| 45 | TS-0207021 | Socket Head Cap Screw | 1/4"-20 × 5/8" | 3 |
| 46 | TS-0561011 | Hex Nut | 1/4” | 3 |
| 47 | EHB916V-47 | Cap | | 1 |
| 48 | SB-3/16 | Steel Ball | | 2 |

mmToolParts
Big Time Experience. Small Town Service. .com

# JET EHB-1018V | Stock 891060

## Parts List B - Saw Arm (continued)

Band Saw | Original JET parts reference

| Ref. | Part number | Description | Size | Qty. |
|---|---|---|---|---|
| 49 | TS-0270061 | Set Screw | 5/16"-18 × 5/8" | 1 |
| 50 | TS-0207021 | Socket Head Cap Screw | 1/4"-20 × 5/8" | 4 |
| 51 | BB-6004 | Bearing | 6004 | 1 |
| 52 | EHB916V-52 | Input Shaft | | 1 |
| 55 | BB-3205 | Bearing | 3205 | 1 |
| 56 | EHB916V-56 | Oil Seal | 25.35.7 | 1 |
| 57 | EHB916V-57 | Cap | | 1 |
| 58 | TS-0207021 | Socket Head Cap Screw | 1/4"-20 × 5/8" | 4 |
| 68 | EHB1018V-68 | Bow Frame | | 1 |
| 68-1 | EHB916V-68-1 | Frame Handle | | 1 |
| 70 | TS-0081031 | Hex Cap Screw | 5/16" x 3/4" | 2 |
| 71 | TS-0680031 | Flat Washer | 5/16" | 2 |
| 73 | EHB916V-73 | Tube Retainer | | 2 |
| 74 | EHB916V-74 | Round Head Screw | 3/16" x 3/8" | 2 |
| 75 | EHB1018V-75 | Bracket (Left Side) | | 1 |
| 76 | TS-0680031 | Flat Washer | 5/16" | 2 |
| 77 | TS-0081031 | Hex Cap Screw | 5/16-18 × 3/4" | 2 |
| 78 | TS-0081031 | Hex Cap Screw | 5/16-18 × 3/4" | 2 |
| 79 | TS-0680031 | Flat Washer | 5/16" | 2 |
| 80 | EHB916V-80 | Drive Wheel. | | 1 |
| 81 | TS-0271032 | Socket Set Screw | 3/8-24 ×3/8" | 1 |
| 82 | EHB916V-82 | Key | 7 x 7 x 40 | 1 |
| 83 | TS-0081031 | Hex Cap Screw | 5/16-18 ×3/4" | 2 |
| 84 | TS-0720081 | Lock Washer | 5/16" | 2 |
| 85 | EHB916V-85 | Bracket | | 1 |
| 86 | EHB916V-86 | Sensor | | 1 |

mmToolParts
Big Time Experience. Small Town Service. .com

# JET EHB-1018V | Stock 891060

## Parts List B - Saw Arm (continued)

Band Saw | Original JET parts reference

| Ref. | Part number | Description | Size | Qty. |
|---|---|---|---|---|
| 86-1 | EHB916V-86-1 | Sensor seat | | 1 |
| 86-2 | EHB916V-86-2 | Screw | | 2 |
| 87 | EHB1018V-87 | Bracket | | 1 |
| 88 | EHB916V-88 | Knob | | 2 |
| 89 | EHB916V-88 | Knob | | 1 |
| 90 | EHB916V-90 | Blade Tension Gauge | | 1 |
| | EHB916V-90A | Blade Tension Gauge As-sembly (includes #20,90) | | 1 |
| BTA | EHB916-BTA | Blade Tension Assembly (includes 1~24, 48~49, 90~90-1) | | 1 |
| 90-1 | EHB916V-90-1 | Pin | | 1 |
| 91 | EHB1018V-91 | Front Pivot Bracket | | 1 |
| 92 | TS-0732061 | Lock Washer | 3/8" | 3 |
| 93 | TS-0060081 | Hex Cap Screw | 3/8-16 ×3/4" | 3 |
| 94 | TS-0271051 | Socket Set Screw | 3/8-16 ×1/2" | 1 |
| 95 | EHB1018V-95 | Motor | 2Hp,230V | 1 |
| 96 | EHB916V-96 | 3 Way Coolant Block | | 1 |
| 97 | EHB916V-97 | Hose | | 2 |
| 98 | EHB916V-98 | Valve | | 2 |
| 99 | EHB1018V-99 | Hose Clamp | | 2 |
| 100 | EHB916V-100 | Belt | | 1 |
| 103 | EHB916V-103 | Upper Guard | | 1 |
| 109 | EHB916V-109 | Lower Guard | | 1 |
| 110 | EHB916V-110 | Motor Pulley | | 1 |
| 111 | TS-0270021 | Socket Set Screw | 5/16-18 ×5/16" | 1 |
| 112 | EHB916V-112 | Pulley | | 1 |
| 113 | TS-0270021 | Socket Set Screw | 5/16-18 ×5/16" | 1 |

mmToolParts
Big Time Experience. Small Town Service. .com

# JET EHB-1018V | Stock 891060

## Parts List B - Saw Arm (continued)

Band Saw | Original JET parts reference

| Ref. | Part number | Description | Size | Qty. |
|---|---|---|---|---|
| 114 | EHB916V-114 | Key | 5 x 5 x 40 | 1 |
| 118 | TS-0720081 | Lock Washer | 5/16" | 2 |
| 119 | EHB916V-119 | Hex Head Screw | 5/16”-20 ×3/4" | 2 |
| 121 | EHB916V-121 | Round Head Screw | #10-3/16 ×3/8" | 4 |
| 122 | EHB916V-122 | Cover R.H | | 1 |
| 123 | TS-0680041 | Lock Washer | 3/8" | 4 |
| 126 | TS-0680041 | Lock Washer | 3/8" | 3 |
| 127 | TS-0060081 | Hex Cap Screw | 3/8"×16 ×3/4" | 3 |
| 128 | EHB1018V-128 | Stationary plate | | 2 |
| 129 | EHB1018V-129 | Bracket | | 1 |
| 130 | TS-0209061 | Socket Head Cap Screw | 3/8"-16 ×1-1/4" | 2 |
| 131 | TS-0267071 | Set Screw | 1/4"-20 ×3/4" | 4 |
| 132 | TS-0270061 | Set Screw | 5/16"-18 ×5/8" | 1 |
| 133 | EHB1018V-133 | Bracket-R.H. | | 4 |
| 134 | EHB1018V-134 | Slide Way. | | 1 |
| 134-1 | EHB916V-134-1 | Scale | | 1 |
| 135 | EHB916V-135 | Screw | 3/16"-24 × 7/8" | 4 |
| 136 | EHB916V-136 | Carbide Guide | | 4 |
| 137 | EHB1018V-137 | Collar | | 2 |
| 138 | TS-0267021 | Set Screw | 1/4"×1/4" | 2 |
| 139 | EHB916V-139 | Wire Brush | | 1 |
| 140 | EHB1018V-140 | Brush Holder | | 1 |
| 141 | TS-0207021 | Socket Head Cap Screw | 1/4"-20 × 5/8" | 2 |
| 142 | TS-0680021 | Flat Washer | 1/4" x 19 x 2.0 | 2 |
| 144 | EHB916V-144 | Guide, Right | | 1 |

mmToolParts
Big Time Experience. Small Town Service. .com

# JET EHB-1018V | Stock 891060

## Parts List B - Saw Arm (continued)

Band Saw | Original JET parts reference


| Ref. | Part number | Description | Size | Qty. |
|---|---|---|---|---|
| 144-1 | EHB916V-144-1 | Guide, Left | | 1 |
| 145 | TS-0561021 | Hex Nut | 5/16"-18T | 2 |
| 146 | TS-0680041 | Flat Washer | 3/8" | 4 |
| 147 | BB-6200ZZ | Bearing | 6200 ZZ | 2 |
| 148 | EHB916V-148 | Special Screw | M10 x 30 | 1 |
| 149 | BB-6200ZZ | Bearing | 6200 ZZ | 4 |
| 150 | EHB916V-150 | Special Screw | | 1 |
| 151 | EHB916V-151 | Special Screw | | 1 |
| 153 | EHB916V-153 | Adjustable Handle | | 1 |
| 154 | EHB916V-154 | Guide Cover | | 1 |
| 154-1 | EHB916V-154-1 | Screw | 3/16” x 3/8” | 2 |
| 154-2 | TS-0680011 | Washer | | 2 |
| 155 | EHB1018V-155 | Bracket-L.H. | | 4 |
| 156 | EHB916V-156 | Blade Cover | | 1 |
| 156-1 | EHB916V-156-1 | Screw | | 2 |
| 156-2 | TS-0680011 | Washer | | 2 |
| 157 | EHB916V-157 | Blade Cover | | 1 |
| 158 | EHB916V-158 | Special Knob | | 2 |
| 159 | TS-0680041 | Flat Washer | 3/8" | 3 |
| 160 | EHB1018V-160 | Hex Head Screw | 3/8”-16 x 3/4” | |
| 161 | EHB1018V-161 | Bracket | | 1 |
| 165 | EHB916V-165 | Round Head Screw | 3/16 ×3/8" | 4 |
| 166 | EHB-916V-166 | Cover L.H | | 1 |
| 167 | EHB916V-167 | Handle | | 2 |
| 168 | TS-081F051 | Phillips Screw | 1/4"-20 × 3/4" | 4 |
| 169 | 891096 | Blade | 1" x 0.035" x 132-1/2"( 4/6T) | 1 |

mmToolParts
Big Time Experience. Small Town Service. .com

# JET EHB-1018V | Stock 891060

## Diagram C - Electrical Box

Band Saw | Original JET parts reference




mmToolParts
Big Time Experience. Small Town Service. .com

# JET EHB-1018V | Stock 891060

## Parts List C - Electrical Box

Band Saw | Original JET parts reference

| Ref. | Part number | Description | Size | Qty. |
|---|---|---|---|---|
| 308-1 | EHB916V-308-1 | Transformer | 115/230/110V | 1 |
| 308-2 | EHB916V-308-2 | Fuse Blocks | 32A | 1 |
| 308-2-1 | EHB916V-308-2-1 | Fuse | 3A | 1 |
| 308-3 | EHB916V-308-3 | Relay | 100/110VAC | 1 |
| 308-4 | EHB916V-308-4 | Relay Socket | CT-BMY2 | 1 |
| 308-5 | EHB916V-308-5 | Terminal Block | | 5 |
| 308-6 | EHB916V-308-6 | Electrical Plate | | 1 |
| 308-7 | EHB916V-308-7 | Round Head Screw | 3/16” x 3/8” | 30 |
| 308-8 | TS-0680011 | Washer | 3/16” | 30 |
| 308-9 | EHB1018V-308-9 | Power Cable | | 1 |
| 308-10 | EHB916V-308-10 | Control Wire | | 1 |
| 308-11 | EHB916V-308-11 | Ground Cable | Yellow/Green | 1 |
| 308-12 | EHB1018V-308-12 | Overload Relay | 11.3-16A | 1 |
| 308-13 | EHB916V-308-13 | Magnetic Contactor | CU-11 110V | 1 |
| 308-13-1 | EHB916V-308-13 | Magnetic Contactor | CU-11 110V | 1 |
| 308-15 | EHB1018V-308-15 | Motor Cable | | 1 |
| 308-16 | EHB916V-308-16 | Pump Cable | | 1 |
| 308-19 | EHB916V-308-19 | Limit Switch Cable | | 1 |

mmToolParts
Big Time Experience. Small Town Service. .com