
JET 1-HDT | Stock 262010

Diagram A - HDT Series - Manual trolley

Shared JET family parts list. Select the capacity, model and electrical variant specified for your trolley.



mmToolParts
Big Time Experience. Small Town Service. .com

JET 1-HDT | Stock 262010

Parts List A - HDT Series - Manual trolley

Shared JET family parts list. Select the capacity, model and electrical variant specified for your trolley.

Ref.	Part number	Description	Size	Qty.
1	1/2HDT-1	Wheel (1/2 ton)		4
1	1HDT-1	Wheel (1 ton)		4
1	2HDT-1	Wheel (2 ton)		4
1	3HDT-1	Wheel (3 ton)		4
1	5HDT-1	Wheel (5 ton)		4
2	BB-6201	Bearing (1/2 ton)		4
2	BB-6202	Bearing (1 ton)		4
2	BB-6204	Bearing (2 ton)		4
2	BB-6206	Bearing (3 ton)		4
2	BB-6207	Bearing (5 ton)		4
3	1/2HDT-3	Snap Ring ø12 (1/2 ton)		4
3	1HDT-3	Snap Ring ø15 (1 ton)		4
3	2HDT-3	Snap Ring ø20 (2 ton)		4
3	3HDT-3	Snap Ring ø30 (3 ton)		4
3	5HDT-3	Snap Ring ø35 (5 ton)		4
4	1/2HDT-4	Shield (1/2 ton)		4
4	1HDT-4	Shield (1 ton)		4
4	2HDT-2	Shield (2 ton)		4
4	3HDT-4	Shield (3 ton)		4
4	5HDT-4	Shield (5 ton)		4
5	1/2HD-5	Snap Ring ø32 (1/2 ton)		4
5	1HDT-5	Snap Ring ø35 (1 ton)		4

mmToolParts
Big Time Experience. Small Town Service. .com

JET 1-HDT | Stock 262010

Parts List A - HDT Series - Manual trolley (continued)

Shared JET family parts list. Select the capacity, model and electrical variant specified for your trolley.

Ref.	Part number	Description	Size	Qty.
5	2HDT-5	Snap Ring ø47 (2 ton)		4
5	3HDT-5	Snap Ring ø62 (3 ton)		4
5	5HDT-5	Snap Ring ø72 (5 ton)		4
6	1/2HDT-6	Shaft (1/2 ton)		1
6	1HDT-6	Shaft (1 ton)		1
6	2HDT-6	Shaft (2 ton)		1
6	3HDT-6	Shaft (3 ton)		1
6	5HDT-6	Shaft (5 ton)		1
7	1/2HDT-7	Side Plate (1/2 ton)		2
7	1HDT-7	Side Plate (1 ton)		2
7	2HDT-7	Side Plate (2 ton)		2
7	3HDT-7	Side Plate (3 ton)		2
7	5HDT-7	Side Plate (5 ton)		2
8	1/2GBT-23	Split Pin ø4x50 (1/2,1,2 ton)		2
8	1GBT-23	Split Pin ø6x65 (3 ton)		2
8	2GBT-23	Split Pin ø6x75 (5 ton)		2
9	1/2HDT-9	Nut M16 (1/2 ton)		2
9	1HDT-9	Nut M20 (1 ton)		2
9	2HDT-9	Nut M24 (2 ton)		2
9	3HDT-9	Nut M30 (3 ton)		2
9	5HDT-9	Nut M36 (5 ton)		2
10	1/2HDT-10	Outer Adjusting Washer (1/2 ton)		2
10	1HDT-10	Outer Adjusting Washer (1 ton)		2

mmToolParts
Big Time Experience. Small Town Service. .com

JET 1-HDT | Stock 262010

Parts List A - HDT Series - Manual trolley (continued)

Shared JET family parts list. Select the capacity, model and electrical variant specified for your trolley.

Ref.	Part number	Description	Size	Qty.
10	2HDT-10	Outer Adjusting Washer (2 ton)		2
10	3HDT-10	Outer Adjusting Washer (3 ton)		2
10	5HDT-10	Outer Adjusting Washer (5 ton)		2
11	1/2HDT-11	Adjusting Washer (1/2 ton)		22
11	1HDT-11	Adjusting Washer (1 ton)		22
11	2HDT-11	Adjusting Washer (2 ton)		26
11	3HDT-11	Adjusting Washer (3 ton)		26
11	5HDT-11	Adjusting Washer (5 ton)		28
12	1/2HDT-12	Adjusting Washer (1/2 ton)		14
12	1HDT-12	Adjusting Washer (1 ton)		12
12	2HDT-12	Adjusting Washer (2 ton)		10
12	3HDT-12	Adjusting Washer (3 ton)		6
12	5HDT-12	Adjusting Washer (5 ton)		4
13	1/2HDT-13	Hanger Plate (1/2 ton)		1
13	1HDT-13	Hanger Plate (1 ton)		1
13	2HDT-13	Hanger Plate (2 ton)		1
13	3HDT-13	Hanger Plate (3 ton)		1
13	5HDT-13	Hanger Plate (5 ton)		1
14	LM000101	Name Plate, 1/2-HDT		2
14	LM000102	Name Plate, 1-HDT		2
14	LM000103	Name Plate, 2-HDT		2
14	LM000104	Name Plate, 3-HDT		2
14	LM000105	Name Plate, 4-HDT		2

Shared JET family parts list. Select the capacity, model and electrical variant specified for your trolley.

1/2HDT-SPK, Spacer Kit for 1⁄2 ton (includes #11 and 12)

1HDT-SPK, Spacer Kit for 1 ton (includes #11 and 12)

2HDT-SPK, Spacer Kit for 2 ton (includes #11 and 12)

3HDT-SPK, Spacer Kit for 3 ton (includes #11 and 12)

5HDT-SPK, Spacer Kit for 5 ton (includes #11 and 12)

Source discrepancy retained: JET prints part 2HDT-2 for shield, and LM000105 as "Name Plate, 4-HDT". Confirm these references with JET before ordering.

mmToolParts
Big Time Experience. Small Town Service. .com