

856
800
861
90
3A
3
126
3B
3C
132
5
158
140
57
11
179
4
130
195
2
1A
57
193
115
149
1
145
11A
148
140
145
140
190
133
4A
144
129
31A
111
110
116
53
37B
112
54
37A
37
37C
104
115
141
113
181
177
170
11
124
184
186
187
12
31
15
140
139
125
196
164
188
93
183
197
135
136
40A
128
59
131
189
12
120
51
177
40
117
175
118
174
23
109
108
65
107
137
64
137
66
121
122
13
65A
13
122

Parts List for 352VS Type 5

Item Number	Part Number	Description	Qty Required
1	810238	FAN	1
1	680967	ARMATURE 115V	1
1	892798	AIR BAFFLE	1
2	887737	FIELD	1
3	887720	LEAD	1
3	N030461	BRUSH & SPRING	2
3	823727	CAP	2
3	887716	BRUSH HOLDER	2
3	801271	CLIP	2
4	5140112-36	SWITCH KIT	1
4	N059514	SPEED CONTROL	1
5	839549	CORD	1
11	330003-85	BEARING	1
11	859293	BEARING	1
12	803856	BEARING	1
13	804211	BEARING,NEEDLE	2
15	684188	BEARING	1
23	848537	SEAL	1
31	899233	PINION DRIVE	1
31	878571	GEAR	1
37	848530	BELT	1
37	695738	DRIVE PULLEY	1
37	899259	DRIVE PULLEY	1
37	906520	NUT	1
40	698038	SHAFT	1
40	878569	PULLEY SHAFT	1
51	896446SV	MOTOR FRAME	1

COPYRIGHT© 2005. All Rights Reserved.
Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for 352VS Type 5

Item Number	Part Number	Description	Qty Required
53	848523	COVER	1
54	893326	BELT COVER	1
57	A23096	HANDLE SET	1
59	904039	VACUUM HOUSING	1
64	878380	FRAME PROTECTOR BAR	1
65	698041	DRIVE PULLEY	1
65	900527	DRIVEN PULLEY	1
66	878570	IDLER ARM	1
90	A23158	DUST BAG ASSY	1
93	897160	SCREW	10
104	852003	GASKET	1
107	849808	SCREW	10
108	859359	WASHER	10
109	848508	WASHER	10
110	804454	WASHER	10
111	802943	NUT	10
112	847994	SCREW	10
113	847564	SNAP RING	1
115	882187	SCREW	10
116	848524	GASKET	1
117	848512	SPRING	1
118	903693	NUT	10
120	801374	SCREW	10
121	853455	RING	1
122	848551	WASHER	10
124	878579	TRACKING BOX	1
125	848514	SPRING	1

COPYRIGHT© 2005. All Rights Reserved.
Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for 352VS Type 5

Item Number	Part Number	Description	Qty Required
126	844107	SCREW	10
128	848565	SCREW	10
129	A03070	SS/A HANDLE SET	1
130	802995	WASHER	10
131	879678	SCREW	10
132	901266	STRAIN RELIEVER	1
133	886538	SCREW	10
135	903400	CORK & SHOE ASSY.	1
136	684987	CLAMP	1
137	883485	SCREW	10
137	802764	SCREW	10
139	869687	NUT	10
140	848148	SCREW	10
141	695812	SCREW & WASHER	10
144	877817	SCREW	10
145	893792	SCREW	10
148	875322	SCREW	1
149	878404	DUST BAFFLE	1
158	883483	SCREW	10
164	892780	SCREW	10
170	850218	WASHER	10
174	696039	LOCATOR	1
175	801530	WASHER	10
177	810523	WASHER	10
179	682063	CONNECTOR VS	1
181	695813	SPACER	1
183	858008	SCREW	10

COPYRIGHT© 2005. All Rights Reserved.
Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for 352VS Type 5

Item Number	Part Number	Description	Qty Required
183	872835	SCREW	10
184	695868	WEAR PLATE	1
186	698042	SPRING	1
187	695789	LEVER	1
188	877537	COVER PLATE	1
189	878563	KEY	1
190	850410	OILER	1
193	698027	ENCLOSURE-TRIAC	1
195	882185	SCREW MACHINE STEEL	10
196	849314	TERM	1
197	848547	COVER	1
800	801945	TUBE GREASE	1
800	801946	LUBE	1
856	48118	GRAPHITE SNDR SHOE	1
861	891582	CARRYING CASE	1

COPYRIGHT© 2005. All Rights Reserved.
Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.