SERVICE PARTS LIST

BULLETIN NO. 54-00-2590


SPECIFY CATALOG NO. AND SERIAL NO. WHEN ORDERING PARTS		REVISED BULLETIN	DATE
10 H.P. ALTERNATOR–5000 WATTS			OCT. '80
CATALOG NO. 4772	STARTING SERIAL NO. H793 477202	WIRING INSTRUCTION	58-01-0968

3600 R.P.M.


FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.
1	-	10 H.P. Engine (For Components Refer to Engine Manufacturer)	(1)
2	06-55-1970	5/16-18 Hex. Nut W/E.T. Lockwasher	(6)
3	42-36-1320	Receptacle Box Bracket	(2)
4	06-55-1505	1/4-20 Hex. Nut W/E.T. Lockwasher	(4)
5	42-04-3550	Engine to Generator Adapter	(1)
6	06-75-0498	3/8-16x7/8" Hex. Hd. Cap screw W/I.T. Lockwasher	(4)
7	23-40-0490	Rotor (Includes 22-84-0730 Fan)	(1)
8	06-92-1260	5/16x6.69" Stud	(1)
9	45-22-0370	Sleeve	(1)
10	23-58-0650	Stator	(1)
11	06-55-3780	Internal Wrenching Nut	(1)
12	06-75-0005	8-32x3/8" Hex. Hd. Cap screw W/Cone Washer	(12)
13	22-12-0180	Receptacle Box Wrapper	(1)
14	-	Receptacle Panel	(1)
15	-	End Bell	(1)
16	22-68-0180	End Bell Cover	(1)
17	06-81-5490	6-32x1.88" Pan Hd. Screw	(2)
18	06-97-2600	1/4" I.T. Lockwasher	(5)
19	42-36-1300	Generator Mounting Bracket	(1)
20	06-75-0268	1/4-20x5-1/2" Hex. Hd. Cap screw	(4)
21	06-57-5165	3/8-16 Hex. Locking Nut	(4)
22	06-75-0021	10-32x1/2" Hex. Hd. Cap screw W/E.T. Lockwasher	(2)
23	23-74-0760	Ground Lug	(1)
24	45-56-0171	Ground Strap	(1)
25	06-97-5450	No. 10 E.I.T. Lockwasher	(1)
26	06-75-0338	5/16-18x1-3/4" Hex. Hd. Cap screw W/E.T. Lockwasher	(4)
27	42-20-0570	Mounting Channel	(2)
28	06-75-0302	5/16-18x3/4" Hex. Hd. Cap screw W/E.T. Lockwasher	(2)
29	44-34-0090	Vibration Dampener	(4)
30	43-40-0205	Carrying Frame	(1)
31	02-50-4250	Roller Bearing	(1)
32	44-60-0580	Locking Pin	(4)
33	06-81-5670	6x3/8" Pan Hd. Tapping Screw	(4)
34	42-36-0990	Capacitor Mounting Bracket	(1)
35	23-33-0230	Capacitor	(1)
36	42-25-0330	End Bell	(1)
37	23-94-9690	3" Lead	(1)
	23-94-9695	3-1/4" Lead	(1)
38	22-20-0310	Brush Guide	(1)
39	22-18-0510	Carbon Brush	(2)
40	23-74-0770	Terminal Tab	(1)
41	23-74-0490	Terminal Tab	(1)
42	06-75-0014	6x5/8" Hex. Hd. Cap screw	(1)
43	-	Control Assembly	(1)
44	42-42-0170	Hole Plug	(4)
45	06-81-5640	8-32x3/4" Pan Hd. Screw W/E.T. Lockwasher	(1)
46	23-74-0790	Terminal Tab	(1)
47	22-36-0110	20 AMP Circuit Breaker	(2)
	22-36-0120	30 AMP Circuit Breaker	(1)
	22-36-0100	15 AMP Circuit Breaker	(2)
48	23-38-2781	Bridge Rectifier	(1)
49	06-55-0830	8-32 Hex Nut	(1)
50	23-66-1210	Switch	(1)
51	23-33-0390	240V 20A Twist Lock Receptacle	(1)
52	23-33-0380	120V 30A Twist Lock Receptacle	(1)
53	23-33-0370	120V Duplex Receptacle	(1)
54	23-35-0290	Receptacle Panel	(1)
55	06-81-5477	6-32x3/8" Pan Hd. Screw W/E.T. Lockwasher	(5)

SEE REVERSE SIDE FOR ILLUSTRATION

MILWAUKEE ELECTRIC TOOL CORPORATION
13135 W. LISBON RD., BROOKFIELD, WIS. 53005


1
2
2
3
4
5
6
6
7
8
9
10
11
12
12
12
13
14
15
16
17
18
18
2
19
3
20
21
21
26
25
24
23
22
27
29
26
28
30

CONTROL ASSEMBLY
51
52
53
54
55
50
49
47
48
46
44
45
43


31
32
33
34
35
37
36
38
40
33
39
33
41
42
END BELL