
3/8" CORDLESS DRILL

Model 6043D
Model 6043DWK



WIRING DIAGRAM

IMPORTANT — To assure product SAFETY and RELIABILITY, repairs, maintenance or adjustments should be performed by MAKITA Service Centers or other qualified service organizations. Always use MAKITA replacement parts.

Fig.	Part No.	Qty. Used	Description
1	265837-4	7	TAPPING SCREW M3x20
3	415250-8	1	HOUSING SET (Incll. Fig. 15)
4	265998-0	1	HEX SCREW 5x21
6	153175-5	1	GEAR Cpl.
7	214017-9	1	PLANE BEARING 5
8	629649-3	1	DC MOTOR 4.8V (with Gear, 221851-0)
9	414113-5	1	SWITCH LEVER
10	231311-4	1	COMPRESSION SPRING 7
11	651852-8	1	SWITCH, ON/OFF
12	631161-1	1	CIRCUIT BOARD
13	678102-6	1	BATTERY
14	415231-2	1	COVER
15	415250-8	1	HOUSING SET (Incl. Fig. 3)
16	651889-5	1	SWITCH, FWD/REV.
17	214019-5	1	PLANE BEARING 4
18	226077-9	1	GEAR Cpl., 11-65
19	214019-5	1	PLANE BEARING 4
20	411640-3	1	HOLDER 6
			ACCESSORIES
400	763110-1	1	KEYLESS CHUCK
401	784202-3	1	PHILLIPS BIT No.2
402	150087-3	1	3-HOUR CHARGER DC4100
403	824417-1	1	PLASTIC TOOL CASE