


WIRING DIAGRAM



IMPORTANT! - To assure product **SAFETY** and **RELIABILITY**, repairs, maintenance or adjustments should be performed by **MAKITA** Service Centers, or other qualified service organizations. Always use **MAKITA** replacement parts.

Fig.	Part No.	Qty. Used	Description	Fig.	Part No.	Qty. Used	Description
1	265998-0	1	PAN HEAD SCREW M5X20	14	183016-1	1	HOUSING SET (INCL. 7, 15)
3	125087-2	1	GEAR ASS'Y	16	263022-3	2	RUBBER PIN 6
4	629726-1	1	DC MOTOR, (INCL. SPUR GEAR 14, 226359-9)	ACCESSORIES			
5	125091-1	1	SPEED CHANGE LEVER ASS'Y	400	632007-4	2	BATTERY 9000
7	183016-1	1	HOUSING SET (INCL. 14, 15)	401	113103-2	1	CHARGER, DC9700
8	266130-9	7	TAPPING SCREW BIND PT 3X16	402	824516-9	1	PLASTIC TOOL CASE, 6096DWE
9	256252-3	1	PIN 3	402	824535-5	1	PLASTIC TOOL CASE, 6096DWLE
10	344549-3	1	SET PLATE	403	ML902	1	FLASHLIGHT, 6096DWLE
11	651966-3	1	SWTCH	404	763132-1	1	KEYLESS DRILL CHUCK
12	232182-2	1	LEAF SPRING	405	414938-7	2	BATTERY COVER
13	911003-8	2	PAN HEAD SCREW M3X6	406	784614-0	1	PHILLIPS BIT 2-45