


PORTER-CABLE TIGER SAW®

WARNING: Electrical repairs should only be attempted by trained repairmen. Contact the nearest Porter-Cable Service Center or other competent repair center.



Parts List for J-627 Type 7

| Item Number | Part Number | Description | Qty Required |
|-------------|-------------|----------------------|--------------|
| 1 | 000000-00 | No Longer Available | 1 |
| 1 | 699050 | ARMATURE | 1 |
| 1 | 878904SV | FAN | 1 |
| 2 | 000000-00 | No Longer Available | 1 |
| 2 | 000000-00 | No Longer Available | 1 |
| 3 | 874289 | BRUSH & RETAINER ASY | 2 |
| 3 | 865323 | BRUSH HOLDER | 2 |
| 3 | 865321 | BRUSH INSULATOR | 2 |
| 4 | 872240 | SWITCH KIT-AC | 1 |
| 4 | 000000-00 | No Longer Available | 1 |
| 5 | A10193 | CORDSET | 1 |
| 11 | 855284 | BEARING | 3 |
| 11 | 330003-17 | BEARING,BALL | 3 |
| 14 | 699047 | INTERN HSG | 1 |
| 15 | 855284 | BEARING | 3 |
| 15 | 874538SV | BALL BEARING | 3 |
| 15 | 699049 | BEARING | 3 |
| 22 | 801852 | SEAL | 1 |
| 40 | 000000-00 | No Longer Available | 1 |
| 40 | 861663 | PIN | 10 |
| 52 | 000000-00 | No Longer Available | 1 |
| 57 | 000000-00 | No Longer Available | 1 |
| 81 | 847420 | CLAMP | 1 |
| 81 | 847423 | SCREW | 10 |
| 92 | 802905 | ALLEN WRENCH | 1 |
| 107 | 882703 | SCREW | 10 |
| 108 | 000000-00 | No Longer Available | 1 |

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for J-627 Type 7

| Item Number | Part Number | Description | Qty Required |
|-------------|-------------|---------------------|--------------|
| 114 | 694432 | BEARING MOUNT | 3 |
| 115 | 842610 | SPRING-PRELOAD | 1 |
| 116 | 862450 | TERMINAL | 2 |
| 117 | 849314 | TERM | 1 |
| 118 | 000000-00 | No Longer Available | 1 |
| 121 | 882704 | SCREW | 10 |
| 123 | 000000-00 | No Longer Available | 1 |
| 125 | 823254 | NUT | 10 |
| 125 | 698297 | LOCKNUT | 10 |
| 127 | 000000-00 | No Longer Available | 1 |
| 128 | 855178 | BEARING | 3 |
| 129 | 847406 | SPACER | 10 |
| 130 | 695508 | REAR BRNG HOUSING | 1 |
| 130 | 000000-00 | No Longer Available | 10 |
| 131 | 844107 | SCREW | 10 |
| 132 | 847418 | SPRING | 10 |
| 133 | 851572 | SPACER | 10 |
| 134 | 000000-00 | No Longer Available | 1 |
| 135 | 849322 | SEAL | 1 |
| 136 | 000000-00 | No Longer Available | 1 |
| 138 | 847404 | SPACER | 10 |
| 139 | 802648 | WASHER | 10 |
| 140 | 848148 | SCREW | 10 |
| 141 | D881293 | DRIVE SHAFT | 1 |
| 142 | 841002 | KEY | 1 |
| 143 | 698294 | WOBBLE PLATE | 1 |
| 147 | 802942 | RING | 10 |

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for J-627 Type 7

| Item Number | Part Number | Description | Qty Required |
|-------------|-------------|----------------------|--------------|
| 150 | 698352 | SUPPORT PKG | 1 |
| 151 | 847417 | OILER | 1 |
| 152 | 863237 | PLATE LUBE | 1 |
| 153 | 849165 | PLATE | 1 |
| 155 | 000000-00 | No Longer Available | 1 |
| 156 | 878262 | SCREW | 10 |
| 157 | 847398 | PIN | 10 |
| 158 | 000000-00 | No Longer Available | 1 |
| 159 | 847395 | SEAL | 2 |
| 161 | 891672SV | SHOE & BRACKET ASSY. | 1 |
| 162 | 800471 | WASHER | 10 |
| 163 | 849235 | SCREW | 1 |
| 164 | 882187 | SCREW | 10 |
| 165 | 879999 | SCREW | 10 |
| 167 | 847398 | PIN | 10 |
| 174 | 901266 | STRAIN RELIEVER | 1 |
| 176 | 842323 | WRENCH HOLDER | 1 |
| 179 | 900826 | SCREW | 10 |
| 181 | 900826 | SCREW | 10 |
| 182 | 867348 | HARDWARE KIT | 1 |
| 800 | 5140061-28 | GREASE | 1 |
| 800 | 5140061-28 | GREASE | 1 |

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.