
PORTER-CABLE

D-HANDLE ROUTER


nearest Porter-Cable Service Center or other competent repair center.


6911
6912
694917

TYPE 1



TYPES 2, 3, 4, 5, 6, 7





Parts List for 6911 Type 4

Item Number	Part Number	Description	Qty Required
102	849314	TERM	3
116	810716	RELIEVER	1
214	839279	KNOB	1
215	872998	DEPTH RING	1
216	800869	SPRING	1
218	823374	WASHER	1
219	42186	ROUTER SUB-BASE	1
220	874117	SCREW	10
220	688860	SCREW	10
222	801821	WASHER	10
225	876770	SWITCH	1
226	802787	115V CORD	1
227	879348	BASE KIT	1
228	876335	HANDLE SET	1
229	874582	CLAMP KNOB	1
230	685526	SCREW	10
231	694125	OUTLET	1
233	882703	SCREW	1
234	892780	SCREW	10
235	859384	SCREW	1
236	803004	SCREW	10
237	694115	SCREW	1
240	694681	COVER	1
241	882183	SCREW	1
242	861434	CORD CLAMP	1
244	839120	EDGE GUIDE	1
245	803160	SCREW	10

COPYRIGHT© 2005. All Rights Reserved.
Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for 6911 Type 4

Item Number	Part Number	Description	Qty Required
246	882810	KNOB	1
247	824588	ROD GUIDE	1

COPYRIGHT© 2005. All Rights Reserved.
Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.