


PORTER-CABLE D-HANDLE ROUTER



nearest Porter-Cable Service Center or other competent repair center.

6912
694917

TYPE 1



TYPES 2, 3, 4, 5, 6, 7



Parts List for 694917 Type 1

Item Number	Part Number	Description	Qty Required
1	682058	ARMATURE 115V	1
2	000000-00	No Longer Available	1
3	N031652	BRUSH	2
3	803483	BRUSH CAP	2
3	873497	BRUSH HOLDER	2
4	842606SV	SWITCH	1
4	694771	HEX NUT	10
5	876683	CORD KIT	1
11	855284	BEARING	3
11	858464	BEARING	3
52	903967SV	CASING & PINS FRONT	1
52	899192SV	REAR HOUSING	1
52	888727	MOTOR HOUSING CAP	1
81	875893	COLLET NUT	1
83	872793	CHUCK	1
83	42950	1/2 INCH COLLET ASSY	1
83	42999	1/4 INCH COLLET ASSY	1
83	876671	COLLET 1/2 INCH	1
83	876669	COLLET 1/4 INCH	1
98	823030	SNAP-RING	10
100	878389	SCREW	10
102	849314	TERM	1
103	804360	SCREW	10
104	803496	WASHER	10
105	842597	PLUG	1
106	863393	SCREW	10
107	802430	LOCKWASHER	10

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for 694917 Type 1

Item Number	Part Number	Description	Qty Required
108	802426	RING	10
111	800835	PIN	10
113	682063	CONNECTOR VS	1
114	842598	BRACKET SWITCH	1
115	802764	SCREW	10
116	901266	STRAIN RELIEVER	1
120	681260	SCREW & WASHER	10
121	874137	CORD CLAMP	1
122	877817	SCREW	10
123	803104	LEAD	1
124	000000-00	No Longer Available	1
125	A22709	OPEN-END WRENCH	1
125	A22709	OPEN-END WRENCH	1
126	683157	WRENCH OPEN END	1
126	683157	WRENCH OPEN END	1
214	839279	KNOB	1
215	800942	RING	10
215	872998	DEPTH RING	1
216	800869	SPRING	3
217	847143	LOCK	1
218	823374	WASHER	10
219	875807	SUB BASE	1
219	42186	ROUTER SUB-BASE	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.