

107
106
110
108
109
111
191
114
118
119
121
129
122
116
115
117
190
51
145
114
14
15
113
102
105
103
104
103
101
136
132
133
134
130
135
131
138
79
140
100
141
142
9
94
25
81
11
12
8
85
86
84
98
250
90
56
58
78
79
122
52
195
8
10
21
3
10
7
6
2
88
1
20
24
83
26
29
28
27
189
187
96
82
78
4
8
192
122
79
57
90
56
5
196
184

Parts List for 7538 Type 4

Item Number	Part Number	Description	Qty Required
1	873638	ARMATURE	1
2	873637	FIELD	1
3	N031634	BRUSH	2
4	5140066-97	SWITCH	1
5	877287	CORD	1
6	698874	BRUSH INSULATOR	2
7	698872	SPRING	2
8	882703	SCREW	6
9	5140102-22	SOFT START MODULE	1
10	852310	SCREW	4
11	330003-75	BEARING, BALL	1
12	A23885SV	SWITCH	1
14	698811	BRG RETAINER	1
15	849819	SCREW	3
20	875931	FAN	1
21	698844	BRUSH HOLDER	2
24	146555-01	BEARING, BALL	1
25	A22441	COVER	1
26	876671	COLLET 1/2 INCH	1
27	823030	SNAP-RING	1
28	875893	COLLET NUT	1
29	42950	1/2 INCH COLLET ASSY	1
51	A23886	MOTOR FRAME	1
52	A22557	HOUSING	1
56	A21906	HANDLE MOUNT	2
57	885318	HANDLE SET R.H.	1
58	698847	HANDLE SET-LH	1

COPYRIGHT© 2005. All Rights Reserved.
Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for 7538 Type 4

Item Number	Part Number	Description	Qty Required
78	879678	SCREW	8
79	850596	SCREW	6
81	859069	PLUG	1
82	874514	SCREW	2
83	698807	CHUCK	1
84	698822	LEAD	1
85	892498	LEAD	1
86	698834	LEAD	1
87	695620	SEAL	1
88	892778	SCREW	2
90	872519	SCREW	2
94	899411	SCREW	4
96	A23261SV	CORD CLAMP	1
97	698875	TRIAC ENCLOSURE	1
98	689032	CONNECTOR	1
100	A23863	BASE & COLUMN ASSY	1
101	873311	ROLLED PIN	2
102	698827	COLUMN	2
103	800190	NUT	3
104	698842	ROD-UPSTART	1
105	698835	LOCK NUT	1
106	892552	LEVER	1
107	872242	SCREW	1
108	699675	CLAMP SCREW	1
109	892531	SPRING SS/A	1
110	699563	SET SCREW	1
111	699552	CLAMP PLUG	1

COPYRIGHT© 2005. All Rights Reserved.
Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for 7538 Type 4

Item Number	Part Number	Description	Qty Required
113	865090	SEAL	1
114	698814	BUSHING	4
115	873499	SCREW	2
116	698899	SCALE	1
117	897162	KNOB	1
118	699988	POINTER	1
119	882054	THUMB SCREW	1
121	699991	DEPTH ROD	1
122	872520	SCREW	8
129	899725	INSERT,SPRING	2
130	872659	SCREW	3
131	862641	NUT	3
132	883806	SCREW	1
133	685533	WASHER	1
134	850552	SPRING	1
135	895591	WASHER	1
136	860687	BALL	1
138	698805	TURRET	1
140	872762	SHIELD	1
141	695870	BASE-SUB	1
142	800539	SCREW	4
145	698829	SPRING	1
184	892780	SCREW	1
187	330005-02	PROTECTOR, CORD	1
189	A22709	OPEN-END WRENCH	1
190	A15178	ID LABEL	1
191	A23046	NAMEPLATE	1

COPYRIGHT© 2005. All Rights Reserved.
Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for 7538 Type 4

Item Number	Part Number	Description	Qty Required
192	694010	SCREW	4
195	A15179	WARNING LABEL	1
196	A11331	WARNING LABEL	1

COPYRIGHT© 2005. All Rights Reserved.
Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.