
PORTER-CABLE

CORDLESS HAMMER DRILL/DRIVER

WARNING: Electrical repairs should only be attempted by trained repairmen. Contact the nearest Porter-Cable Service Center or other competent repair center.

887



Parts List for 9887 Type 2

Item Number	Part Number	Description	Qty Required
1	891236	MOTOR	1
1	891238	PINION	1
4	894852	SWITCH	1
53	891269	GEAR BOX/CLUTCH ASSY	1
53	891270	CLUTCH RING	1
57	891250	HANDLE SET	1
83	330075-91	KEYLESS CHUCK	1
100	894098	SCREW	10
101	897046	SPRING CLIP	2
103	897120	SCREW	10
104	000000-00	No Longer Available	1
105	000000-00	No Longer Available	1
106	891244	SPEED SLECTOR	1
107	888993	SCREW	10
108	891352	RELEASE BUTTON	1
109	891353	SPRING	10
110	892955	CLIP	10
111	5140070-56	19.2V BATTERY	1
111	5140070-56	19.2V BATTERY	1
112	901562	BATTERY TOP	1
113	8924	UNIVERSAL CHARGER	1
114	8924	UNIVERSAL CHARGER	1
115	000000-00	No Longer Available	1
116	000000-00	No Longer Available	10
117	000000-00	No Longer Available	1
118	895781	WASHER	10
119	698950	BIT	1

COPYRIGHT© 2005. All Rights Reserved.
Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for 9887 Type 2

Item Number	Part Number	Description	Qty Required
120	000000-00	No Longer Available	1
120	895824	CARRYING CASE	1
121	887712	LATCH CARRYING CASE	1
121	890390	LATCH	1
125	8924	UNIVERSAL CHARGER	1

COPYRIGHT© 2005. All Rights Reserved.
Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.