
D25902K Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: D25902K Type 1 | Additional parts have no assigned figure

SE




mmToolParts
Big Time Experience. Small Town Service. .com

D25902K Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: D25902K Type 1 | Additional parts have no assigned figure




mmToolParts
Big Time Experience. Small Town Service. .com

D25902K Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: D25902K Type 1 | Additional parts have no assigned figure



mmToolParts
Big Time Experience. Small Town Service. .com

D25902K Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: D25902K Type 1 | Additional parts have no assigned figure

Fig. 1	579837-03	ARMATURE 120V
Fig. 2	NA170790	FIELD SA 115V
Fig. 3	1007719-01	BRUSH HOLDER SA
Fig. 4	590191-00	SLEEVE INSULATING
Fig. 5	577745-00	BEARING
Fig. 7	1007800-00	SEAL
Fig. 8	1005550-03	BRUSH PAIR 115V
Fig. 9	487377-00	BRUSH SPRING
Fig. 10	N542569	FAN SA
Fig. 11	324119-02	SCREW
Fig. 12	1005637-00	SPRING COMPRESSION
Fig. 13	1005640-00	HOUSING HANDLE
Fig. 14	1005643-00	BELLOWS
Fig. 15	1005672-00	SCREW
Fig. 16	1005646-00	TUBE GUIDE
Fig. 17	1005644-00	STOP
Fig. 18	487326-03	LEAD & SOCKET SA
Fig. 19	1005639-01	PLATE
Fig. 20	1005496-01	GUIDE BUSH
Fig. 21	N572223	CARRIER
Fig. 22	N485854	SWITCH
Fig. 23	1005645-00	ROD
Fig. 24	1005641-00	HANDLE COVER
Fig. 25	821070	CORD CLAMP
Fig. 27	1005942-00	SLEEVE BEARING
Fig. 28	323091-01	CORD PROTECTOR
Fig. 29	330100-98	CORDSET
Fig. 30	1005642-00	COVER GEARCASE
Fig. 31	N345479	BRIDGE

mmToolParts
Big Time Experience. Small Town Service. .com

D25902K Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: D25902K Type 1 | Additional parts have no assigned figure

Fig. 32	487224-00	SEAL
Fig. 33	330065-08	SCREW
Fig. 34	324821-04	CIRCLIP
Fig. 35	N570313	BEARING
Fig. 36	487209-01	SEAL
Fig. 37	324821-03	CIRCLIP
Fig. 38	N542565	CON ROD
Fig. 39	578452-00	SPACER
Fig. 40	578451-00	SPACER
Fig. 41	605040-26	BEARING
Fig. 42	579782-00	GEAR
Fig. 43	579783-00	GEAR
Fig. 44	579772-00	GEARCASE SA
Fig. 45	579839-00	CRANKSHAFT
Fig. 46	576451-00	RING
Fig. 47	487208-00	PIN
Fig. 48	581656-00	PIN
Fig. 49	487213-00	O RING
Fig. 50	579774-00	PISTON
Fig. 51	579779-01	PISTON KIT
Fig. 52	323711-47	O RING
Fig. 53	N147097	COVER SA
Fig. 54	N325419	ELECTRONIC 120V
Fig. 55	479319-00	CLAMPING INSERT
Fig. 56	487284-00	WASHER CLAMP
Fig. 57	1005666-00	MOTOR COVER
Fig. 58	N514174	SCREW
Fig. 59	1007718-00	SIDE HANDLE
Fig. 60	487343-00	BOLT

mmToolParts
Big Time Experience. Small Town Service. .com

D25902K Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: D25902K Type 1 | Additional parts have no assigned figure

Fig. 61	487277-00	HANDLE
Fig. 62	479317-01	WASHER LOCK
Fig. 63	487281-00	CLAMP
Fig. 64	487291-00	KNOB SA
Fig. 65	949886-32	SCREW
Fig. 66	N718060	COVER HOUSING
Fig. 67	579832-00	BEAT PIECE
Fig. 68	487270-00	BUSH
Fig. 69	496678-00	DAMPER
Fig. 70	579786-00	BUSH
Fig. 71	487298-00	O RING
Fig. 72	496847-00	BUSH
Fig. 73	487297-00	O RING
Fig. 74	323711-41	O RING
Fig. 75	N075954	CYLINDER
Fig. 76	579780-00	RAM
Fig. 77	487296-00	O RING
Fig. 78	579769-00	HOUSING FRONT
Fig. 79	323711-55	O RING
Fig. 80	487293-00	SPRING GUIDE
Fig. 81	487247-00	SPRING
Fig. 82	576488-00	SPRING GUIDE
Fig. 83	579781-00	COUNTERWEIGHT
Fig. 84	N577800	COVER
Fig. 86	576489-00	SPRING GUIDE
Fig. 87	487238-01	SEAL
Fig. 88	487205-00	RING
Fig. 89	487241-00	WASHER
Fig. 90	487244-00	RUBBER

mmToolParts
Big Time Experience. Small Town Service. .com

D25902K Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: D25902K Type 1 | Additional parts have no assigned figure

Fig. 91	487236-00	SLEEVE
Fig. 92	579784-00	LOCKING RING
Fig. 93	487218-00	SPRING
Fig. 94	487249-00	BUSH
Fig. 95	489672-00	KEY
Fig. 96	487240-00	BUSHING
Fig. 97	487216-00	SPRING
Fig. 98	487268-00	SPRING GUIDE
Fig. 99	487289-00	SPRING
Fig. 100	N542567	SLEEVE SA
Fig. 101	487237-00	SLEEVE
Fig. 102	918825-02	SCREW
Fig. 103	579778-00	FLANGE
Fig. 104	323711-15	O RING
Fig. 105	496677-00	DAMPER
Fig. 107	579773-00	SPINDLE SA
Fig. 108	N014007	SEAL
Fig. 109	487287-00	O RING
Fig. 110	1007543-00	BEARING BUSH
Fig. 112	487392-00	LABEL
Fig. 120	330003-68	BEARING
Fig. 130	330003-69	BEARING
Fig. 800	578970-06	GREASE 150 GMS
Fig. 802	870889-02	GREASE
Fig. 821	N323699	RATING PLATE
Fig. 826	487395-01	LABEL
Fig. 836	559617-99	S.T.SUPPORT JIG
Fig. 837	559618-99	S.T.SUPPORT JIG
Fig. 838	559621-99	SERVICE TOOL

mmToolParts
Big Time Experience. Small Town Service. .com

D25902K Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: D25902K Type 1 | Additional parts have no assigned figure

Fig. 840	559619-99	S.T.CIRCLIP REMOVER
Fig. 845	559620-99	S.T.SEAL FITTING TOOL
Fig. 861	487353-04	KITBOX
Fig. 876	1008773-00	SERVICE KIT 120V

mmToolParts
Big Time Experience. Small Town Service. .com