
DC330K-CA Type 11 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DC330K-CA Type 11 | Additional parts have no assigned figure



mmToolParts
Big Time Experience. Small Town Service. .com

DC330K-CA Type 11 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DC330K-CA Type 11 | Additional parts have no assigned figure

Fig. 1	586202-01SV	MOTOR ASSY.
Fig. 2	603754-01	BRUSH & HOLDER
Fig. 3	152274-23	SWITCH
Fig. 4	496429-00	FAN
Fig. 5	496428-00	BAFFLE
Fig. 6	156179-01	SCREW
Fig. 7	330045-15	SCREW
Fig. 8	652425-00	LEVER
Fig. 10	490989-00	PINION
Fig. 11	621367-00	LEAD PURPLE
Fig. 12	389923-00	LEAD BLACK
Fig. 15	330065-07	SCREW
Fig. 16	N173566	HOUSING ASSY.
Fig. 17	581269-00	GUARD
Fig. 20	324006-00	SCREW
Fig. 21	581577-00	CASTING
Fig. 22	584627-00	PIN
Fig. 23	581418-00	SPRING
Fig. 24	586923-00	ACTUATOR
Fig. 25	590334-02	GEARCASE
Fig. 26	581244-00	GASKET
Fig. 27	330045-09	SCREW
Fig. 28	584451-00	SPRING CLIP
Fig. 30	330045-06	SCREW
Fig. 31	582837-00	BOLT
Fig. 32	N072135SV	BLADE CLAMP
Fig. 33	582262-00	HOLDER
Fig. 34	582263-00	FELT SEAL
Fig. 35	586646-00	SPRING

mmToolParts
Big Time Experience. Small Town Service. .com

DC330K-CA Type 11 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DC330K-CA Type 11 | Additional parts have no assigned figure

Fig. 36	582259-00	BEARING
Fig. 37	581274-00	RECIPROCATOR
Fig. 38	582260-00	SUPPORT BEARING
Fig. 40	490329-00	BEARING
Fig. 46	582261-00	CLAMP
Fig. 47	582257-00	DRIVE ROLLER
Fig. 48	571181-00	CLIP
Fig. 49	582829-00	WASHER
Fig. 50	N466547	SCREW
Fig. 51	330004-02	BEARING NEEDLE
Fig. 52	N607672	CRANK KIT
Fig. 53	N034837	COUNTERWEIGHT
Fig. 55	N607665	GEAR ASSEMBLY
Fig. 56	581247-00	ACTUATOR
Fig. 58	585113-00SV	GEARCASE ASSY
Fig. 65	581255-05	LEVER
Fig. 66	326467-00	DETENT
Fig. 67	582830-05	BODY
Fig. 68	582831-00	BAFFLE
Fig. 70	581280-00	BRACKET
Fig. 72	330041-29	PIN
Fig. 73	584450-00	NOZZLE
Fig. 74	330041-49	PIN
Fig. 76	581257-01	LEVER
Fig. 77	330003-95	BEARING
Fig. 78	N089310	SPRING CLIP
Fig. 85	581263-00	SHOE
Fig. 86	495746-00	LEVER LOCK
Fig. 88	584686-00	PLUNGER

mmToolParts
Big Time Experience. Small Town Service. .com

DC330K-CA Type 11 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DC330K-CA Type 11 | Additional parts have no assigned figure

Fig. 89	496996-00	CLAMP
Fig. 90	582826-00	BOLT
Fig. 91	582828-00	WASHER
Fig. 92	582827-00	BOLT
Fig. 94	581264-00	SOLE PLATE
Fig. 95	389235-00	SCREW
Fig. 96	581268-00	SOLE PLATE
Fig. 800	283484-01	GREASE
Fig. 816	587466-00	BRAND LABEL
Fig. 821	N416543	RATING LABEL
Fig. 856	1004501-00	FENCE
Fig. 856	402140-00	ANTI SPLINTER DEVICE
Fig. 861	N179861	KIT BOX
Fig. 866	DC9096	BATTERY 18V - 2.4AH
Fig. 867	645221-00	CAP
Fig. 871	388683-12	CHARGER

mmToolParts
Big Time Experience. Small Town Service. .com

DC330K-CA Type 11 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DC330K-CA Type 11 | Additional parts have no assigned figure

Additional parts - no figure assigned by DeWalt

-	581255-00	LEVER
-	582830-00	BODY
-	N037466	BAG
-	N442675	GEAR ASSEMBLY
-	N442676	CRANK KIT

mmToolParts
Big Time Experience. Small Town Service. .com