
DC740-BR Type 2 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DC740-BR Type 2 | Additional parts have no assigned figure



mmToolParts
Big Time Experience. Small Town Service. .com

DC740-BR Type 2 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DC740-BR Type 2 | Additional parts have no assigned figure

Fig. 1	649284-00	HOUSING & COVER
Fig. 2	389080-00	BUTTON
Fig. 3	389081-01	TERMINAL BOX
Fig. 4	391092-00SV	LEAD RED
Fig. 5	391091-00SV	LEAD-BLACK
Fig. 6	682211-00	SCREW
Fig. 7	391996-00	SLIDER
Fig. 8	631445-00	MOTOR & PINION
Fig. 11	330075-87	CHUCK KEYLESS
Fig. 12	638563-00	TRANSMISSION ASSEMBLY
Fig. 13	149518-01	SCREW
Fig. 14	152274-28	SWITCH SA
Fig. 15	395657-00	BRAND LABEL
Fig. 16	148354-03	HOLDER
Fig. 17	607918-41	BIT SCREWDRIVER
Fig. 20	562160-01	SCREW
Fig. 21	650519-00	NAMEPLATE
Fig. 22	389083-00	PLATE
Fig. 861	389108-02	KITBOX
Fig. 867	DE9074	BATTERY 12V - 1.3AH - 15.6WH

mmToolParts
Big Time Experience. Small Town Service. .com

DC740-BR Type 2 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DC740-BR Type 2 | Additional parts have no assigned figure

Additional parts - no figure assigned by DeWalt

-	388683-15	CHARGER

mmToolParts
Big Time Experience. Small Town Service. .com