
DC800KL-CA Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DC800KL-CA Type 1 | Additional parts have no assigned figure



mmToolParts
Big Time Experience. Small Town Service. .com

DC800KL-CA Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DC800KL-CA Type 1 | Additional parts have no assigned figure

Fig. 1	633412-00	CLAMSHELL SET
Fig. 2	637843-00	IDENTITY LABEL
Fig. 3	330019-04	SCREW
Fig. 4	611202-00SV	MAGNET
Fig. 5	610552-00SV	SWITCH SA
Fig. 6	636747-00	TERMINAL & LEAD
Fig. 9	610023-00	IMPACTOR
Fig. 10	615803-00SV	BARREL
Fig. 11	615801-00SV	ANVIL ASSEMBLY
Fig. 12	610542-00	O RING
Fig. 13	610539-00	WASHER THRUST
Fig. 14	648605-00	GEAR
Fig. 15	610545-00	GEAR
Fig. 16	611316-00	ROLL PIN
Fig. 17	611488-00	WASHER
Fig. 19	330019-06	SCREW
Fig. 20	N232656	RATING LABEL
Fig. 21	610544-00	CARRIER
Fig. 22	005190-00	BALL STEEL
Fig. 23	613461-00	SPRING
Fig. 24	613724-00	WASHER THRUST
Fig. 25	610541-00	BEARING THRUST
Fig. 26	N020802	DETENT
Fig. 27	099205-07	ROLL PIN
Fig. 28	038769-00	SPRING
Fig. 29	N360880	ARMATURE 36V
Fig. 30	391032-00	BEARING & SEAL
Fig. 31	605040-17	BEARING BALL
Fig. 32	605040-25	BEARING,BALL

mmToolParts
Big Time Experience. Small Town Service. .com

DC800KL-CA Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DC800KL-CA Type 1 | Additional parts have no assigned figure

Fig. 33	330019-49	SCREW
Fig. 34	330019-25	SCREW
Fig. 35	610126-00	BRUSHBOX SA
Fig. 36	610550-00	BAFFLE FAN
Fig. 37	611205-00	GEARCASE
Fig. 38	N171820	SUPPORT BEARING
Fig. 800	284778-00	GREASE
Fig. 800	286436-00	GREASE
Fig. 861	380865-02	HANDLE FRAME KIT
Fig. 861	637475-00	LATCH ASSEMBLY
Fig. 861	N232344	KITBOX
Fig. 866	DCB361	BATTERY 36V - 2.0AH - 72WH
Fig. 871	DC9000	CHARGER 28V - 36V

mmToolParts
Big Time Experience. Small Town Service. .com

DC800KL-CA Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DC800KL-CA Type 1 | Additional parts have no assigned figure

Additional parts - no figure assigned by DeWalt

-	143891-00	DETENT
-	330003-12	BEARING
-	330003-63	BEARING,BALL
-	381109-00	LATCH
-	38769-00	SPRING
-	5190-00	BALL STEEL
-	610107-00	SUPPORT BEARING
-	610547-00	GEAR
-	610552-00	SWITCH SA
-	611200-06SV	ARMATURE ASSY.
-	611202-00	MAGNET
-	615801-00	ANVIL ASSEMBLY
-	615803-00	BARREL
-	637845-00	NAMEPLATE
-	99205-07	ROLLPIN
-	DC9360	BATTERY 36V - 2.2AH
-	N017298	GREASE

mmToolParts
Big Time Experience. Small Town Service. .com