
DCD447WW1 Type 2 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DCD447WW1 Type 2 | Additional parts have no assigned figure



mmToolParts
Big Time Experience. Small Town Service. .com

DCD447WW1 Type 2 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DCD447WW1 Type 2 | Additional parts have no assigned figure

Fig. 1	NA730701	HOUSING
Fig. 2	N901130	GEARCASE SA
Fig. 3	NA611077	SPINDLE SA
Fig. 4	330045-06	SCREW
Fig. 5	N825538	QUICK CONNECT CHUCK
Fig. 6	NA560830	BOOT
Fig. 7	330019-74	SCREW
Fig. 8	N514195	HANDLE
Fig. 9	N561739	SCREW
Fig. 10	NA202175	GEAR & SHAFT
Fig. 11	N764617	DEFLECTOR
Fig. 12	330019-08	SCREW
Fig. 13	NA611047	ROTOR SA
Fig. 14	N827399	BAFFLE
Fig. 15	NB418029	STATOR SA
Fig. 16	N394333	LENS
Fig. 17	N508751	ACTUATOR FWD/REV
Fig. 18	330019-04	SCREW
Fig. 21	330021-11	STOP NUT
Fig. 22	NA129421	SCREW
Fig. 50	NA760666	RATING LABEL
Fig. 51	NA760667	WARNING LABEL
Fig. 52	NB420233	CONTROL MODULE SA
Fig. 800	429698-00	GREASE

mmToolParts
Big Time Experience. Small Town Service. .com

DCD447WW1 Type 2 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DCD447WW1 Type 2 | Additional parts have no assigned figure

Additional parts - no figure assigned by DeWalt

-	DCB118	CHARGER
-	DCB2108	BATTERY

mmToolParts
Big Time Experience. Small Town Service. .com