
DCD710S2-CA Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DCD710S2-CA Type 1 | Additional parts have no assigned figure



mmToolParts
Big Time Experience. Small Town Service. .com

DCD710S2-CA Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DCD710S2-CA Type 1 | Additional parts have no assigned figure

Fig. 1	N031199	CLAMSHELL SET
Fig. 2	N034293	COLLAR
Fig. 3	N075846	KEYLESS CHUCK
Fig. 4	N075847	MOTOR SA
Fig. 5	N075843	TRANSMISSION SA
Fig. 6	N037108	WIRE STEEL
Fig. 7	N037111	SELECTOR
Fig. 8	N075234	SWITCH SA
Fig. 10	N017247	ACTUATOR FWD/REV
Fig. 11	326467-00	DETENT
Fig. 12	682211-00	SCREW
Fig. 13	149518-01	SCREW
Fig. 15	N031603	RUBBER
Fig. 20	N073447	BRAND LABEL
Fig. 21	N070138	NAMEPLATE
Fig. 22	N073390	LABEL-WARNING (SPANI
Fig. 30	N068674	HOOK
Fig. 856	DW2002 Z	#2 PHILLIPS BIT TIP
Fig. 862	N294699	BAG
Fig. 866	DCB127	BATTERY
Fig. 871	DCB115	CHARGER

mmToolParts
Big Time Experience. Small Town Service. .com

DCD710S2-CA Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DCD710S2-CA Type 1 | Additional parts have no assigned figure

Additional parts - no figure assigned by DeWalt

-	DCB100	CHARGER 10.8V
-	DCB120	BATTERY PACK
-	DW2002	#2 BIT TIP
-	N041318	BAG
-	N052424	BELT HOOK

mmToolParts
Big Time Experience. Small Town Service. .com