
DCD796E1-B3 Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DCD796E1-B3 Type 1 | Additional parts have no assigned figure



mmToolParts
Big Time Experience. Small Town Service. .com

DCD796E1-B3 Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DCD796E1-B3 Type 1 | Additional parts have no assigned figure

Additional parts - no figure assigned by DeWalt

-	682211-00	SCREW
-	DCB107-B3	CHARGER
-	DCBP034-B3	BATTERY
-	N014681	LEAF SPRING
-	N035441	WIRE STEEL
-	N042665	SCREW
-	N268199	HOLDER BIT
-	N268241	HOOK SA
-	N377990	SCREW
-	N392855	DETENT
-	N393603	SELECTOR
-	N397466	SELECTOR
-	N399342	ACTUATOR FWD/REV
-	N415400	CLAMSHELL SET
-	N438603	TRANSMISSION SA
-	N439415	ID LABEL
-	N439417	LABEL
-	N458060	RATING LABEL
-	N599497	CHUCK KEYLESS
-	N680324	MOTOR & SWITCH SA
-	NA040219	BAG

mmToolParts
Big Time Experience. Small Town Service. .com