
DCD930KX-AR Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DCD930KX-AR Type 1 | Additional parts have no assigned figure



mmToolParts
Big Time Experience. Small Town Service. .com

DCD930KX-AR Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DCD930KX-AR Type 1 | Additional parts have no assigned figure

Fig. 1	N026313	GEARCASE SA
Fig. 23	N135767	CONVERSION KIT T1-T2
Fig. 24	652378-00	PLATE
Fig. 25	650470-00	LOCKING RING
Fig. 26	652379-00	ANVIL
Fig. 27	654110-00	ROLLER
Fig. 28	N017098SV	GEAR SA
Fig. 29	N038862	SPRING
Fig. 30	650444-00	GEAR
Fig. 31	N017099SV	GEAR SA
Fig. 32	N030490SV	GEAR SA
Fig. 33	657453-00SV	SLIDER SA
Fig. 34	654927-00SV	BAFFLE SA
Fig. 42	N016695SV	CLAMSHELL SET
Fig. 43	N020621SV	SWITCH SA
Fig. 45	N023149SV	ARMATURE ASSEMBLY
Fig. 46	N230576	MAGNET
Fig. 47	N007948	CLAMP
Fig. 48	N091392	ACTUATOR FWD/REV
Fig. 49	N031214	BRUSHBOX SA
Fig. 50	148354-03	HOLDER
Fig. 51	N028034	BRAND LABEL
Fig. 52	682211-00	SCREW
Fig. 53	330019-52	SCREW
Fig. 54	N014681	LEAF SPRING
Fig. 56	N389651	SIDE HANDLE
Fig. 61	N120429SV	GEARCASE SA
Fig. 61	N211312	GEARCASE ASSY
Fig. 70	N025675	NAME PLATE

mmToolParts
Big Time Experience. Small Town Service. .com

DCD930KX-AR Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DCD930KX-AR Type 1 | Additional parts have no assigned figure

Fig. 800	429698-00	GREASE
Fig. 800	N017298	GREASE
Fig. 836	233947-00	HOLDER
Fig. 836	559661-99	S.T.CHUCK REMOVAL JIG
Fig. 836	559662-99	S.T.CHUCK REMOVAL JIG
Fig. 836	596004-99	S.T.INSERT
Fig. 861	N303239	KITBOX
Fig. 866	615824-12	BATTERY 14.4V - 2.0AH - 29WH
Fig. 867	645221-00	CAP
Fig. 871	DW9116-AR	CHARGER

mmToolParts
Big Time Experience. Small Town Service. .com