
DCD930KX Type 3 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DCD930KX Type 3 | Additional parts have no assigned figure



mmToolParts
Big Time Experience. Small Town Service. .com

DCD930KX Type 3 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DCD930KX Type 3 | Additional parts have no assigned figure

Fig. 22	N391336	CHUCK KEYLESS
Fig. 23	605256-01	SCREW
Fig. 24	652378-00	PLATE
Fig. 25	650470-00	LOCKING RING
Fig. 26	652379-00	ANVIL
Fig. 27	654110-00	ROLLER
Fig. 28	N388924	GEAR SA
Fig. 32	N388150	GEAR SA
Fig. 33	N388923	SLIDER SA
Fig. 34	N347360	BAFFLE SA
Fig. 42	N016695SV	CLAMSHELL SET
Fig. 43	N020621SV	SWITCH SA
Fig. 45	N161059	ARMATURE ASSEMBLY
Fig. 46	NA146883	STATOR
Fig. 47	N007948	CLAMP
Fig. 48	N091392	ACTUATOR FWD/REV
Fig. 49	N031214	BRUSHBOX SA
Fig. 50	148354-03	HOLDER
Fig. 51	N028034	BRAND LABEL
Fig. 52	682211-00	SCREW
Fig. 53	330019-52	SCREW
Fig. 54	N014681	LEAF SPRING
Fig. 56	N389651	SIDE HANDLE
Fig. 61	N211312	GEARCASE ASSY
Fig. 70	N155165	RATING LABEL
Fig. 800	N017298	GREASE
Fig. 836	233947-00	HOLDER
Fig. 836	559661-99	S.T.CHUCK REMOVAL JIG
Fig. 836	559662-99	S.T.CHUCK REMOVAL JIG

mmToolParts
Big Time Experience. Small Town Service. .com

DCD930KX Type 3 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DCD930KX Type 3 | Additional parts have no assigned figure

Fig. 836	596004-99	S.T.INSERT
Fig. 861	N303239	KITBOX
Fig. 866	615824-12	BATTERY 14.4V - 2.0AH - 29WH
Fig. 867	645221-00	CAP
Fig. 871	388683-12	CHARGER

mmToolParts
Big Time Experience. Small Town Service. .com