
DCD940KX-CA Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DCD940KX-CA Type 1 | Additional parts have no assigned figure



mmToolParts
Big Time Experience. Small Town Service. .com

DCD940KX-CA Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DCD940KX-CA Type 1 | Additional parts have no assigned figure

Fig. 1	N026314	GEARCASE SA
Fig. 20	N196034	CHUCK KEYLESS
Fig. 21	605256-01	SCREW
Fig. 22	652378-00	PLATE
Fig. 23	650470-00	LOCKING RING
Fig. 24	652379-00	ANVIL
Fig. 25	654110-00	ROLLER
Fig. 26	N017098SV	GEAR SA
Fig. 27	N038862	SPRING
Fig. 28	650444-00	GEAR
Fig. 29	N017099SV	GEAR SA
Fig. 30	N030490SV	GEAR SA
Fig. 31	657453-00SV	SLIDER SA
Fig. 32	654927-00SV	BAFFLE SA
Fig. 42	N014498SV	CLAMSHELL SET
Fig. 43	N020621SV	SWITCH SA
Fig. 45	N023147SV	ARMATURE SA
Fig. 46	N230576	MAGNET
Fig. 46	NA146883	STATOR
Fig. 47	N007948	CLAMP
Fig. 48	N091392	ACTUATOR FWD/REV
Fig. 49	N031214	BRUSHBOX SA
Fig. 50	148354-03	HOLDER
Fig. 51	N028034	BRAND LABEL
Fig. 52	682211-00	SCREW
Fig. 53	330019-52	SCREW
Fig. 54	N014681	LEAF SPRING
Fig. 56	N389651	SIDE HANDLE
Fig. 61	658849-00SV	GEARCASE ASSY

mmToolParts
Big Time Experience. Small Town Service. .com

DCD940KX-CA Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DCD940KX-CA Type 1 | Additional parts have no assigned figure

Fig. 61	N211232	GEARCASE ASSY
Fig. 70	N037635	NAMEPLATE
Fig. 800	N017298	GREASE
Fig. 836	233947-00	HOLDER
Fig. 836	559661-99	S.T.CHUCK REMOVAL JIG
Fig. 836	559662-99	S.T.CHUCK REMOVAL JIG
Fig. 836	596004-99	S.T.INSERT
Fig. 861	N303239	KITBOX
Fig. 866	389795-23	BATTERY 18V - 2.4AH
Fig. 866	DC9096	BATTERY 18V - 2.4AH
Fig. 867	645221-00	CAP
Fig. 871	388683-12	CHARGER

mmToolParts
Big Time Experience. Small Town Service. .com

DCD940KX-CA Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DCD940KX-CA Type 1 | Additional parts have no assigned figure

Additional parts - no figure assigned by DeWalt

-	233804-44	INSERT
-	330075-91	CHUCK KEYLESS
-	389795-13	BATTERY PACK
-	650413-00	IDENT. LABEL
-	650414-00	ACTUATOR FWD/REV
-	650421-00	SIDE HANDLE
-	654927-00	BAFFLE SA
-	657453-00	SLIDER SA
-	N014498	CLAMSHELL SET
-	N017098	GEAR SA
-	N017099	GEAR SA
-	N020621	SWITCH SA
-	N023147	ARMATURE SA
-	N026385	NAMEPLATE
-	N030490	GEAR SA
-	N031214SV	BRUSH & HOLDER SA
-	N073084	SPRING
-	N082200	KITBOX

mmToolParts
Big Time Experience. Small Town Service. .com