
DCD959KX Type 2 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DCD959KX Type 2 | Additional parts have no assigned figure



mmToolParts
Big Time Experience. Small Town Service. .com

DCD959KX Type 2 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DCD959KX Type 2 | Additional parts have no assigned figure

Fig. 1	N016701	CLAMSHELL SET
Fig. 3	148354-03	HOLDER
Fig. 4	607918-41	BIT SCREWDRIVER
Fig. 5	N131172	RATING LABEL
Fig. 6	398649-00	BUTTON
Fig. 7	152274-19SV	SWITCH
Fig. 8	398646-00	ADAPTOR
Fig. 9	396505-22SV	MOTOR & PINION
Fig. 10	682211-00	SCREW
Fig. 11	397892-05SV	TRANSMISSION SA
Fig. 12	608060-00	DETENT
Fig. 13	N391336	CHUCK KEYLESS
Fig. 14	395657-00	BRAND LABEL
Fig. 15	N016837SV	GEARCASE ASSY
Fig. 16	330019-49	SCREW
Fig. 17	605256-01	SCREW
Fig. 18	399059-00	SPRING
Fig. 20	603785-00	LEAD PURPLE
Fig. 21	603786-00	LEAD BROWN
Fig. 22	603754-01	BRUSH & HOLDER
Fig. 23	NA292261	SIDE HANDLE
Fig. 24	609133-00	END CAP
Fig. 25	604643-00	COLLAR
Fig. 26	395460-00	SPRING GUIDE
Fig. 28	611904-00SV	SPINDLE SA
Fig. 861	660141-00	KITBOX
Fig. 866	DC9096	BATTERY 18V - 2.4AH
Fig. 867	645221-00	CAP
Fig. 871	388683-12	CHARGER

mmToolParts
Big Time Experience. Small Town Service. .com