
DCF880L2 Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DCF880L2 Type 1 | Additional parts have no assigned figure



mmToolParts
Big Time Experience. Small Town Service. .com

DCF880L2 Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DCF880L2 Type 1 | Additional parts have no assigned figure

Fig. 1	N309479	BRUSH HOLDER SA
Fig. 2	N309480	ARMATURE ASSEMBLY
Fig. 3	N309481	MAGNET RING
Fig. 4	N309482	MOUNT SA
Fig. 5	N309483	MECHANISM ASSY
Fig. 6	N309484	NOSE CONE ASSY.
Fig. 7	642883-01	WASHER
Fig. 8	608024-00SV	ANVIL ASSEMBLY
Fig. 9	N139775	LED LIGHT
Fig. 10	N360124	SWITCH ASSEMBLY
Fig. 10	N421268	SWITCH KIT
Fig. 11	682211-00	SCREW
Fig. 12	N633132	HOUSING
Fig. 13	N073265	LEVER
Fig. 14	N089231	BRAND LABEL
Fig. 21	N268241	HOOK SA
Fig. 22	370167-00	SCREW
Fig. 23	N174882	RATING LABEL
Fig. 25	N078823	WARNING LABEL (SPA)
Fig. 26	N020802	DETENT
Fig. 27	099205-07	ROLL PIN
Fig. 28	038769-00	SPRING
Fig. 30	330021-11	STOP NUT
Fig. 800	284778-00	GREASE
Fig. 800	286436-00	GREASE
Fig. 861	N380212	KITBOX
Fig. 866	DCB200	BATTERY PACK
Fig. 871	DCB1104	CHARGER

mmToolParts
Big Time Experience. Small Town Service. .com