
DCR015 Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DCR015 Type 1 | Additional parts have no assigned figure



mmToolParts
Big Time Experience. Small Town Service. .com

DCR015 Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DCR015 Type 1 | Additional parts have no assigned figure

Fig. 1	5140127-25	FRAME LH
Fig. 2	5140127-26	FRAME RH
Fig. 3	5140127-27	HOUSING FRONT
Fig. 4	5140127-28	BUTTON SA
Fig. 5	5140127-29	KNOB
Fig. 6	5140127-30	GRILL
Fig. 7	5140127-31	GRILL
Fig. 8	5140127-32	PCB ASSEMBLY
Fig. 9	5140127-33	PCB SA
Fig. 10	5140127-34	SPEAKER
Fig. 11	5140127-35	HANDLE
Fig. 12	5140127-36	CAGE
Fig. 13	5140127-37	CAGE
Fig. 14	5140127-38	KIT
Fig. 15	5140127-39	MOUNT SA
Fig. 16	5140127-40	MOUNT SA
Fig. 17	5140127-41	PCB SA
Fig. 18	5140127-42	PCB ASSEMBLY
Fig. 19	5140127-43	PCB ASSEMBLY
Fig. 20	5140127-44	PCB SA
Fig. 21	5140127-45	TRANSFORMER
Fig. 22	5140127-46	ANTENNA
Fig. 23	5140127-47	PCB ASSEMBLY
Fig. 24	5140127-48	PCB ASSEMBLY
Fig. 25	5140127-49	REAR CABINET
Fig. 26	5140127-50	DOOR
Fig. 27	5140127-51	BATTERY CONNECTOR
Fig. 28	5140127-52	COVER SA
Fig. 29	5140127-53	DOOR

mmToolParts
Big Time Experience. Small Town Service. .com

DCR015 Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DCR015 Type 1 | Additional parts have no assigned figure

Fig. 30	5140127-54	CORD KIT
Fig. 31	5140127-94	COVER
Fig. 32	5140127-95	KEY HOLDER
Fig. 33	5140127-96	BRACKET
Fig. 34	5140127-97	HOUSING
Fig. 35	5140127-98	OUTLET (120V)
Fig. 36	5140127-99	SPEAKER
Fig. 37	5140160-31	SWITCH
Fig. 856	5140127-14	CABLE ASSEMBLY

mmToolParts
Big Time Experience. Small Town Service. .com