
DCS371P1 Type 20 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DCS371P1 Type 20 | Additional parts have no assigned figure



mmToolParts
Big Time Experience. Small Town Service. .com

DCS371P1 Type 20 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DCS371P1 Type 20 | Additional parts have no assigned figure

Fig. 1	N388446	BASE
Fig. 2	N559549	HANDLE
Fig. 3	N071023	HOUSING MOTOR

mmToolParts
Big Time Experience. Small Town Service. .com

DCS371P1 Type 20 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DCS371P1 Type 20 | Additional parts have no assigned figure

Additional parts - no figure assigned by DeWalt

-	330019-40	SCREW
-	388531-00	PIN
-	389120-00	SPRING
-	5140103-04	COVERPLATE
-	5140103-06	WHEEL
-	5140103-08	HANDLE
-	5140103-09	GUIDE
-	5140103-11	BLOCK
-	5140103-12	CAM
-	5140103-13	GUIDE
-	5140103-14	FENCE
-	5140103-15	SPACER
-	5140103-20	BAND
-	5140103-21	SPRING
-	5140103-22	BUSHING
-	5140103-24	WASHER
-	5140103-25	WASHER
-	5140103-26	WASHER
-	5140103-27	SCREW
-	5140103-29	SCREW
-	5140103-30	SCREW
-	5140103-32	RING
-	5140103-33	SCREW
-	5140103-34	SCREW
-	5140103-35	WASHER
-	5140103-36	SCREW
-	5140103-37	SCREW
-	5140103-39	SCREW

mmToolParts
Big Time Experience. Small Town Service. .com

DCS371P1 Type 20 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DCS371P1 Type 20 | Additional parts have no assigned figure

-	5140103-40	BEARING
-	5140103-41	BEARING
-	5140103-42	DOWEL
-	5140103-43	NUT
-	5140103-44	ROLLER
-	5140103-45	WASHER
-	5140103-46	SCREW
-	5140103-48	SCREW
-	5140103-49	SCREW
-	5140103-50	SCREW
-	5140103-51	NUT
-	5140103-52	WASHER
-	5140103-54	SCREW
-	5140103-55	WASHER
-	5140103-58	GUIDE
-	5140103-59	SCREW
-	5140103-60	SCREW
-	5140103-63	SHAFT
-	5140103-64	SCREW
-	5140243-52	DRIVE PULLEY
-	604407-02	WRENCH
-	651744-00	HOOK
-	DCB1104	CHARGER
-	DCB205	BATTERY
-	DCS3711	GUARD
-	DW3982C	BAND SAW BLADE
-	DW3983C	BAND SAW BLADE
-	DW3984C	BAND SAW BLADE
-	DW3986C	BAND SAW BLADE

mmToolParts
Big Time Experience. Small Town Service. .com

DCS371P1 Type 20 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DCS371P1 Type 20 | Additional parts have no assigned figure

-	N053823	PLATE
-	N071024	END CAP
-	N123103	STOP NUT
-	N270202	SCREW
-	N270222	MODULE
-	N271627	SCREW
-	N272122	SCREW
-	N272137	LED LIGHT
-	N330379	WARNING LABEL
-	N330399	IDENTITY LABEL
-	N381405	GUARD SA
-	N381410	GUARD SA
-	N401362	COVER
-	N401363	WIPER
-	N559552	HANDLE
-	N658175	MOTOR SA
-	N658197	GEAR
-	N658225	PLATE
-	N658234	SHAFT
-	N827453	RATING LABEL
-	NA575073	BUTTON LOCK-OFF
-	NA705140	BAG

mmToolParts
Big Time Experience. Small Town Service. .com