
DCS551B Type 2 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DCS551B Type 2 | Additional parts have no assigned figure



mmToolParts
Big Time Experience. Small Town Service. .com

DCS551B Type 2 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DCS551B Type 2 | Additional parts have no assigned figure

Fig. 1	N401266	HOUSING ASSEMBLY
Fig. 2	N401267	MOTOR & SHAFT ASSY
Fig. 3	389461-00	SPRING
Fig. 4	N401268	COLLAR SA
Fig. 7	N380688	SPRING
Fig. 8	N405520	SPACER
Fig. 9	389243-00	COLLET
Fig. 9	389244-00	COLLET 1/4"
Fig. 10	389245-00	COLLET NUT
Fig. 11	330019-03	SCREW
Fig. 12	145312-00	PLUG
Fig. 13	N401269	SWITCH & MODULE
Fig. 14	N324203	ACTUATOR
Fig. 15	N558546	BOOT
Fig. 16	626734-00	RETAINER
Fig. 17	389459-00	GUIDE
Fig. 18	389460-00	GUIDE SUPPORT
Fig. 19	045687-00	WASHER SPECIAL
Fig. 20	396992-01	KNOB
Fig. 21	N412815	RATING LABEL
Fig. 22	N389197	IDENT LABEL
Fig. 23	N388450	WARNING LABEL
Fig. 856	391023-00	DRYWALL BIT
Fig. 862	NA705132	BAG SA
Fig. 866	DCB203	BATTERY PACK
Fig. 871	DCB1104	CHARGER

mmToolParts
Big Time Experience. Small Town Service. .com