
# DCS570B Type 3 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DCS570B Type 3 | Additional parts have no assigned figure






mmToolParts
Big Time Experience. Small Town Service. .com

# DCS570B Type 3 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DCS570B Type 3 | Additional parts have no assigned figure

| | | |
|---|---|---|
| Fig. 1 | N530589 | HOUSINGS |
| Fig. 2 | N499337 | GEARCASE SA |
| Fig. 4 | N123103 | STOP NUT |
| Fig. 5 | N378852 | GUARD LOWER |
| Fig. 6 | 145344-00 | SCREW |
| Fig. 7 | N419350 | LEVER |
| Fig. 8 | N099101 | BOLT |
| Fig. 9 | 330045-19 | SCREW |
| Fig. 10 | 330019-10 | SCREW |
| Fig. 15 | 330019-03 | SCREW |
| Fig. 16 | N115554 | HANDLE |
| Fig. 17 | 330019-13 | SCREW |
| Fig. 20 | N472351 | SPINDLE SA |
| Fig. 21 | N086135 | SCREW |
| Fig. 22 | 381066-00 | BUMPER |
| Fig. 24 | N135988 | STRAP |
| Fig. 25 | 593515-00 | SCREW |
| Fig. 26 | N499341 | SHOE ASSEMBLY |
| Fig. 28 | N805579 | MOTOR & SWITCH SA |
| Fig. 28 | N863843 | CONTROL MODULE SA |
| Fig. 34 | 145343-01 | WASHER OUTER CLAMP |
| Fig. 35 | N120426 | RETAINER |
| Fig. 36 | N084137 | WASHER INNER CLAMP |
| Fig. 37 | N100006 | SPRING |
| Fig. 38 | N090570 | LEVER LOCK |
| Fig. 39 | N100123 | SPRING |
| Fig. 40 | 385915-04 | SCREW |
| Fig. 42 | N917615 | ROTOR SA |
| Fig. 44 | 098094-13 | SCREW |

mmToolParts
Big Time Experience. Small Town Service. .com

# DCS570B Type 3 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DCS570B Type 3 | Additional parts have no assigned figure

| | | |
|---|---|---|
| Fig. 45 | N146857 | WASHER |
| Fig. 46 | N175185 | GUARD LEVER |
| Fig. 47 | N361499 | O RING |
| Fig. 48 | N755045 | RATING LABEL |
| Fig. 51 | N420031 | SHAFT |
| Fig. 52 | N620480 | WASHER |
| Fig. 53 | N421358 | COVER |
| Fig. 54 | N034545 | SCREW |
| Fig. 55 | 330045-14 | SCREW |
| Fig. 56 | N422878 | BUTTON LOCK-OFF |
| Fig. 57 | N433343 | SPRING |
| Fig. 58 | NA618729 | LED LIGHT |
| Fig. 61 | N447499 | WASHER FIBRE |
| Fig. 62 | N461735 | SPRING |
| Fig. 63 | 90504014 | CABLE TIE |
| Fig. 64 | N091479 | MOUNT |
| Fig. 70 | N493688 | SPANNER |
| Fig. 76 | N287119 | SCREW |
| Fig. 92 | N117921 | STOP NUT |
| Fig. 93 | 098128-90 | CARRIAGE BOLT |
| Fig. 95 | 145347-00 | LEVER |
| Fig. 96 | N094731 | SCREW |
| Fig. 97 | N560335 | HOOK |
| Fig. 101 | NA595525 | WARNING LABEL |
| Fig. 800 | 583534-00 | GREASE |
| Fig. 856 | DWE575DC | VACUUM ADAPTOR |
| Fig. 862 | NA705140 | BAG |
| Fig. 866 | DCB205 | BATTERY |
| Fig. 871 | DCB1104 | CHARGER |

mmToolParts
Big Time Experience. Small Town Service. .com

# DCS570B Type 3 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DCS570B Type 3 | Additional parts have no assigned figure

| | | |
|---|---|---|
| Fig. 997 | NA710246 | FOAM |

mmToolParts
Big Time Experience. Small Town Service. .com