
# DHS790ABR Type 22 - Parts List

Use the figure number to match each part to the corresponding parts schematic.







mmToolParts
Big Time Experience. Small Town Service. .com

# DHS790ABR Type 22 - Parts List

Use the figure number to match each part to the corresponding parts schematic.







mmToolParts
Big Time Experience. Small Town Service. .com

# DHS790ABR Type 22 - Parts List

Use the figure number to match each part to the corresponding parts schematic.






mmToolParts
Big Time Experience. Small Town Service. .com

# DHS790ABR Type 22 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

| | | |
|---|---|---|
| Fig. 1 | N597357 | BASE |
| Fig. 3 | 330045-49 | SCREW |
| Fig. 4 | N583416 | PLATE |
| Fig. 5 | 604410-00 | SCREW |
| Fig. 6 | 330045-23 | SCREW |
| Fig. 7 | 391358-01 | HOLDER |
| Fig. 8 | 330045-05 | SCREW |
| Fig. 9 | N441566 | BAR FENCE |
| Fig. 10 | N588102 | STUD |
| Fig. 11 | 618192-00 | PLATE |
| Fig. 12 | N600625 | TABLE |
| Fig. 13 | N488468 | DETENT |
| Fig. 14 | N477761 | SPRING COMPRESSION |
| Fig. 15 | 093128-00 | BEARING NEEDLE |
| Fig. 16 | 618254-00 | RETAINER |
| Fig. 17 | N050755 | ACTUATOR |
| Fig. 18 | N477762 | PLATE |
| Fig. 19 | 330045-14 | SCREW |
| Fig. 20 | N082785 | LEVER |
| Fig. 21 | N057386 | PIN |
| Fig. 23 | 618186-00 | ROD |
| Fig. 24 | 330015-03 | NUT |
| Fig. 25 | 624461-00 | SLEEVE |
| Fig. 26 | 618185-00 | BLOCK |
| Fig. 27 | 385915-03 | SCREW |
| Fig. 28 | 618253-00 | SPRING COMPRESSION |
| Fig. 29 | 622396-00 | SHAFT |
| Fig. 30 | 622395-00 | LEVER LOCK-OFF |
| Fig. 31 | N057963 | POINTER |

mmToolParts
Big Time Experience. Small Town Service. .com

# DHS790ABR Type 22 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

| | | |
|---|---|---|
| Fig. 32 | N043046 | PAWL |
| Fig. 33 | N043045 | PAWL |
| Fig. 34 | N058315 | SCREW.SPECIAL |
| Fig. 35 | N600034 | SCREW |
| Fig. 36 | 330045-45 | SCREW |
| Fig. 37 | N600059 | BOLT |
| Fig. 38 | 385946-00 | WASHER SPRING |
| Fig. 39 | N585429 | BEVEL SCALE |
| Fig. 40 | N058318 | SCREW |
| Fig. 41 | 153792-00 | WASHER |
| Fig. 42 | 153451-00 | BEARING THRUST |
| Fig. 43 | N044739 | LOCK NUT |
| Fig. 44 | N597939 | FENCE |
| Fig. 45 | 098105-03 | SCREW |
| Fig. 46 | N450335 | LEFT FENCE |
| Fig. 47 | N450342 | RIGHT FENCE |
| Fig. 48 | N480602 | KNOB SA |
| Fig. 49 | N157708 | HOUSING SA |
| Fig. 50 | N058308 | POINTER |
| Fig. 51 | N058309 | POINTER |
| Fig. 52 | N058314 | SCREW |
| Fig. 53 | N041865 | PIN |
| Fig. 54 | N080199 | KNOB |
| Fig. 55 | 060325-01 | RING |
| Fig. 56 | N049689 | STOP RH |
| Fig. 57 | N051519 | STOP LH |
| Fig. 58 | N095579 | LEVER SA |
| Fig. 59 | N058319 | RAIL |
| Fig. 60 | 397117-00 | SEAL |

mmToolParts
Big Time Experience. Small Town Service. .com

# DHS790ABR Type 22 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

| | | |
|---|---|---|
| Fig. 61 | N049684 | COVERPLATE |
| Fig. 62 | N051244 | BUMPER |
| Fig. 63 | 153666-00 | SCREW |
| Fig. 64 | 628591-00 | GUIDE |
| Fig. 65 | 153576-04 | SCREW |
| Fig. 66 | N455343 | END CAP |
| Fig. 67 | N443949 | TRUNNION |
| Fig. 69 | 659919-00 | SPRING |
| Fig. 70 | N058312 | SCREW |
| Fig. 71 | 153655-00 | WASHER |
| Fig. 72 | 153639-00 | SCREW |
| Fig. 73 | N142121 | DUST PORT |
| Fig. 74 | 330019-14 | SCREW |
| Fig. 75 | 603390-00 | SCREW |
| Fig. 76 | 153603-01 | PAWL |
| Fig. 77 | 167785-00 | SPRING |
| Fig. 78 | N104494 | RAIL |
| Fig. 79 | N450867 | BRACKET |
| Fig. 80 | 330016-04 | WASHER |
| Fig. 81 | N655935 | LOCK HANDLE |
| Fig. 83 | N618207 | ARM |
| Fig. 87 | N185664 | SCREW |
| Fig. 88 | 150718-00 | NUT WING |
| Fig. 89 | 618244-00 | RETAINING PLATE |
| Fig. 90 | N141275 | SPINDLE & GEAR SA |
| Fig. 91 | 393071-00 | PLATE |
| Fig. 92 | 153559-00 | WASHER |
| Fig. 93 | 448176-00 | SPRING |
| Fig. 94 | 153561-00 | LOCKING PIN |

mmToolParts
Big Time Experience. Small Town Service. .com

# DHS790ABR Type 22 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

| | | |
|---|---|---|
| Fig. 95 | N268679 | GEAR CASE SA |
| Fig. 96 | N510450 | GASKET |
| Fig. 97 | 605040-21 | BEARING |
| Fig. 98 | 330003-66 | BEARING,BALL |
| Fig. 99 | N139533 | GEAR SA |
| Fig. 100 | 605040-33 | BEARING |
| Fig. 101 | 153752-00 | RETAINER |
| Fig. 102 | N203541 | SHAFT SA |
| Fig. 103 | 385915-04 | SCREW |
| Fig. 104 | 049787-00 | O RING |
| Fig. 105 | 387130-00 | LOCKING PIN |
| Fig. 106 | 034158-00 | O RING |
| Fig. 108 | N126153 | PIVOT SHAFT |
| Fig. 109 | 150075-00 | SCREW |
| Fig. 110 | N639013 | SPRING |
| Fig. 111 | 146732-00 | SPACER |
| Fig. 112 | N538855 | WASHER INNER CLAMP |
| Fig. 113 | N461434 | COVER |
| Fig. 114 | N083060 | HANDLE |
| Fig. 115 | N434093 | HANDLE |
| Fig. 116 | N434094 | HANDLE |
| Fig. 117 | 330045-18 | SCREW |
| Fig. 118 | N447769 | SWITCH |
| Fig. 119 | 330019-32 | SCREW |
| Fig. 120 | 330019-12 | SCREW |
| Fig. 121 | N030322 | COVER |
| Fig. 122 | N439376 | LED LIGHT |
| Fig. 123 | N426940 | HOUSING |
| Fig. 124 | N426941 | HOUSING |

mmToolParts
Big Time Experience. Small Town Service. .com

# DHS790ABR Type 22 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

| | | |
|---|---|---|
| Fig. 125 | N426942 | HOUSING |
| Fig. 126 | 048822-00 | HEYCO BUSHING |
| Fig. 127 | 330019-16 | SCREW |
| Fig. 128 | N443878 | JUMPER |
| Fig. 129 | N449481 | BUSHING |
| Fig. 130 | N443879 | LEAD |
| Fig. 131 | NA105798 | TERMINAL BLOCK |
| Fig. 132 | N427493 | SCREW |
| Fig. 133 | N449474 | SCREW |
| Fig. 134 | 330045-15 | SCREW |
| Fig. 135 | N142523 | LINK |
| Fig. 136 | 146740-00 | SLEEVE |
| Fig. 137 | 394589-01 | SCREW |
| Fig. 138 | 330019-22 | SCREW |
| Fig. 139 | DWAFV31260 | SAW BLADE |
| Fig. 140 | 152636-00 | BLADE HOLDER |
| Fig. 141 | N448791 | COVER |
| Fig. 142 | N300152 | CAP |
| Fig. 143 | N458834 | SCREW |
| Fig. 144 | 398443-00 | CABLE CLAMP |
| Fig. 145 | N443880 | SWITCH |
| Fig. 146 | N480342 | SCREW |
| Fig. 147 | 153555-00 | BELT |
| Fig. 148 | N494159 | PCB SA |
| Fig. 149 | N538823 | CLAMP OUTER |
| Fig. 150 | N594146 | LIFTER |
| Fig. 151 | N544383 | PLATE |
| Fig. 152 | 330045-06 | SCREW |
| Fig. 153 | N377514 | BUSHING |

mmToolParts
Big Time Experience. Small Town Service. .com

# DHS790ABR Type 22 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

| | | |
|---|---|---|
| Fig. 154 | N600011 | BLADE BOLT |
| Fig. 157 | N020822 | PLATE |
| Fig. 158 | 385915-01 | SCREW |
| Fig. 159 | 621037-00 | PLATE |
| Fig. 160 | 146768-00 | BUMPER |
| Fig. 161 | 146750-03 | RETAINING PLATE |
| Fig. 162 | N034013 | SPRING |
| Fig. 163 | 148295-00 | SLEEVE |
| Fig. 167 | N506101 | MOTOR PLATE |
| Fig. 168 | N647660 | EXTENSION |
| Fig. 169 | N647661 | EXTENSION |
| Fig. 170 | N086990 | CLAMP |
| Fig. 171 | N684204 | WASHER |
| Fig. 172 | N677410 | WING NUT |
| Fig. 173 | N600007 | SPANNER |
| Fig. 174 | N142123 | CLAMP SA |
| Fig. 175 | N142125 | KNOB |
| Fig. 180 | N473903 | MOTOR ASSEMBLY |
| Fig. 876 | NA075955 | GUARD KIT |

mmToolParts
Big Time Experience. Small Town Service. .com