
DW318-B2 Type 2 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DW318-B2 Type 2 | Additional parts have no assigned figure



mmToolParts
Big Time Experience. Small Town Service. .com

DW318-B2 Type 2 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DW318-B2 Type 2 | Additional parts have no assigned figure

Fig. 1	185180-01	ARMATURE 230V
Fig. 2	185184-01	FIELD 230V
Fig. 3	445861-30	BRUSH 220V
Fig. 4	445860-00	BRUSH SPRING
Fig. 5	449899-05	RING
Fig. 6	445880-00	SCREW
Fig. 7	380763-00	SWITCH 220V
Fig. 8	185081-02	CORD
Fig. 9	605040-06	BEARING,BALL
Fig. 10	605040-15	BEARING BALL
Fig. 12	603209-00	HANDLE SA
Fig. 14	449174-00	TERMINAL
Fig. 15	444793-00	CIRCLIP
Fig. 16	445874-00	RETAINER
Fig. 17	185262-00	NAMEPLATE
Fig. 19	445857-03	FIELDCASE
Fig. 21	449193-01	LABEL
Fig. 22	395047-00	BRAND LABEL
Fig. 23	N918736	CORD PROTECTOR
Fig. 24	330019-13	SCREW
Fig. 26	330045-08	SCREW
Fig. 27	133775-03	GEARCASE COVER
Fig. 28	330019-27	SCREW
Fig. 29	400765-00	GUIDE
Fig. 30	133825-00	CLIP
Fig. 31	330019-04	SCREW
Fig. 32	445876-00	BAFFLE
Fig. 33	608389-00	BRACKET
Fig. 34	445217-02	SLEEVE

mmToolParts
Big Time Experience. Small Town Service. .com

DW318-B2 Type 2 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DW318-B2 Type 2 | Additional parts have no assigned figure

Fig. 36	445405-00	SCREW
Fig. 37	330022-16	SCREW
Fig. 38	444520-00	BLADE CLAMP
Fig. 40	133751-00	SHIELD
Fig. 41	133755-00	SEAL
Fig. 42	133820-00	PIN
Fig. 43	133847-00	OILER
Fig. 44	133750-00	CLAMP
Fig. 45	049161-00	SPRING
Fig. 46	133756-00	BEARING
Fig. 47	445387-00	BAR
Fig. 48	450285-00	PLATE
Fig. 49	133807-00	SEAL
Fig. 50	098022-26	SCREW
Fig. 51	620203-00	ROLLER
Fig. 52	133844-00	BEARING
Fig. 53	330045-05	SCREW
Fig. 54	133828-01SV	PLATE
Fig. 55	133765-00	GASKET
Fig. 56	133761-00	WEIGHT
Fig. 57	429882-64	ROD
Fig. 58	098185-20	PIN
Fig. 59	N497538	NUT, HEX
Fig. 60	133799-00	FORK
Fig. 61	098198-05	WASHER
Fig. 62	133827-02SV	GEAR SA
Fig. 63	448817-02	GEARCASE SA
Fig. 64	133770-00	SHOE
Fig. 65	445687-00	WASHER

mmToolParts
Big Time Experience. Small Town Service. .com

DW318-B2 Type 2 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DW318-B2 Type 2 | Additional parts have no assigned figure

Fig. 67	000475-00	BALL STEEL
Fig. 68	604892-00	SPRING
Fig. 69	448809-00	KNOB
Fig. 70	098121-31	SCREW
Fig. 71	386700-00	PIN
Fig. 72	330004-06	BEARING NEEDLE
Fig. 73	449977-00	QUADRANT
Fig. 74	080164-00	SCREW
Fig. 76	065288-02	HOLDER
Fig. 77	099056-04	HEX WRENCH
Fig. 78	098000-11	HEX KEY

mmToolParts
Big Time Experience. Small Town Service. .com