
DW331K Type 11 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DW331K Type 11 | Additional parts have no assigned figure



mmToolParts
Big Time Experience. Small Town Service. .com

DW331K Type 11 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DW331K Type 11 | Additional parts have no assigned figure

Fig. 1	582811-02SV	ARMATURE & BRG.
Fig. 2	N378010	FIELD
Fig. 3	582822-01	SWITCH 115V
Fig. 4	589016-01	BRUSH PAIR 115V
Fig. 5	583696-01	BRUSH HOLDER SA
Fig. 6	NA073534	CORD PROTECTOR
Fig. 7	330072-98	CORDSET
Fig. 8	330065-06	SCREW
Fig. 10	821070	CORD CLAMP
Fig. 11	628274-00	LEAD WIRE
Fig. 12	628274-01	LEAD WIRE
Fig. 14	330003-56	BEARING
Fig. 15	330065-07	SCREW
Fig. 16	588997-00	HANDLE SA
Fig. 17	581269-00	GUARD
Fig. 18	581239-01	SCREEN
Fig. 21	581577-00	CASTING
Fig. 22	584627-00	PIN
Fig. 23	581418-00	SPRING
Fig. 24	589055-00	ACTUATOR
Fig. 25	N142823	GEARCASE SA
Fig. 26	581244-00	GASKET
Fig. 27	330045-09	SCREW
Fig. 30	330065-11	SCREW
Fig. 31	582837-00	BOLT
Fig. 32	N072135SV	BLADE CLAMP
Fig. 33	582262-00	HOLDER
Fig. 34	582263-00	FELT SEAL
Fig. 35	586646-00	SPRING

mmToolParts
Big Time Experience. Small Town Service. .com

DW331K Type 11 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DW331K Type 11 | Additional parts have no assigned figure

Fig. 36	582259-00	BEARING
Fig. 37	581274-00	RECIPROCATOR
Fig. 38	N621424	SUPPORT BEARING
Fig. 39	324006-00	SCREW
Fig. 40	490329-00	BEARING
Fig. 46	582261-00	CLAMP
Fig. 47	582257-00	DRIVE ROLLER
Fig. 48	571181-00	CLIP
Fig. 49	582829-00	WASHER
Fig. 50	N466547	SCREW
Fig. 51	330004-02	BEARING NEEDLE
Fig. 52	N607672	CRANK KIT
Fig. 53	N034837	COUNTERWEIGHT
Fig. 55	N607675	GEAR ASSEMBLY
Fig. 56	581247-00	ACTUATOR
Fig. 57	330019-15	SCREW
Fig. 58	589011-00	GEARCASE SA
Fig. 65	581255-05	LEVER
Fig. 66	326467-00	DETENT
Fig. 67	582830-05	BODY
Fig. 68	582831-00	BAFFLE
Fig. 70	589056-00	SUPPORT BRACKET
Fig. 72	330041-29	PIN
Fig. 73	584450-00	NOZZLE
Fig. 74	330041-49	PIN
Fig. 76	581257-00	LEVER
Fig. 77	330003-96	BEARING BALL
Fig. 78	N089310	SPRING CLIP
Fig. 80	581241-01	MOTOR HOUSING

mmToolParts
Big Time Experience. Small Town Service. .com

DW331K Type 11 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DW331K Type 11 | Additional parts have no assigned figure

Fig. 81	581240-00	BAFFLE FAN
Fig. 82	930029-00	HOLDER BEARING
Fig. 85	581263-00	SHOE
Fig. 86	493248-00	LEVER
Fig. 87	581266-00	ADAPTOR
Fig. 88	584686-00	PLUNGER
Fig. 89	496996-00	CLAMP
Fig. 90	582826-00	BOLT
Fig. 91	582828-00	WASHER
Fig. 92	582827-00	BOLT
Fig. 93	581281-00	VACUUM ADAPTOR
Fig. 94	581264-00	SOLE PLATE
Fig. 95	389235-00	SCREW
Fig. 96	581268-00	SOLE PLATE
Fig. 100	402140-00	ANTI SPLINTER DEVICE
Fig. 800	283484-01	GREASE
Fig. 816	587464-01	ID LABEL
Fig. 821	N416545	RATING LABEL
Fig. 856	1004501-00	FENCE
Fig. 856	N515525	JIG SAW BLADE
Fig. 856	N536023	BLADE PACK
Fig. 861	393455-00	KITBOX

mmToolParts
Big Time Experience. Small Town Service. .com