
DW352-AR Type 2 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DW352-AR Type 2 | Additional parts have no assigned figure



mmToolParts
Big Time Experience. Small Town Service. .com

DW352-AR Type 2 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DW352-AR Type 2 | Additional parts have no assigned figure

Fig. 1	186395-01	ARMATURE 220V
Fig. 2	185438-01	FIELD 220V
Fig. 3	450374-12	BRUSH & SPRING
Fig. 4	562097-00	SCREW
Fig. 5	448083-01	BRUSHBOX SA
Fig. 6	448084-01	BRUSH CAP
Fig. 7	380772-00	SWITCH
Fig. 8	185081-08	CORD
Fig. 9	605040-06	BEARING,BALL
Fig. 10	605040-20	BEARING
Fig. 11	70907-00	SCREW
Fig. 12	142950-00	WASHER OUTER CLAMP
Fig. 13	133876-00	RETAINER
Fig. 14	142949-00	BLADE CLAMP
Fig. 15	696060-00	RETAINER
Fig. 16	N918736	CORD PROTECTOR
Fig. 17	646470-00	GUARD LOWER
Fig. 18	187610-00	SPRING
Fig. 19	158472-00	SCREW
Fig. 20	155455-00	GEARCASE COVER
Fig. 21	449460-01	END CAP
Fig. 22	153170-00	GEARCASE
Fig. 23	155461-02	SPINDLE & GEAR
Fig. 24	70473-00	BEARING
Fig. 25	131890-00	SCREW
Fig. 26	131982-00	BUMPER
Fig. 27	155453-00	BAFFLE
Fig. 28	185328-00	CORD CLAMP
Fig. 29	679139-00	SCREW

mmToolParts
Big Time Experience. Small Town Service. .com

DW352-AR Type 2 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DW352-AR Type 2 | Additional parts have no assigned figure

Fig. 30	330013-13	SCREW
Fig. 31	95100-19	SHOE
Fig. 32	695197-00	ROLLPIN
Fig. 33	142881-00	SCREW
Fig. 34	38910-00	SCREW
Fig. 35	090914-00	WING NUT
Fig. 36	5130830-00	WASHER
Fig. 37	385668-07	HANDLE SA
Fig. 38	185215-01	NAMEPLATE
Fig. 40	330019-14	SCREW
Fig. 41	155452-00	FIELD CASE
Fig. 42	399729-00	SCREW
Fig. 43	445217-02	SLEEVE
Fig. 44	144461-00	SCREW.TEMP
Fig. 45	188515-00	GUARD UPPER
Fig. 100	87118-00	RIP FENCE
Fig. 101	73199-00	SCREW
Fig. 103	N035355	SPANNER

mmToolParts
Big Time Experience. Small Town Service. .com