
DW378G-CA Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DW378G-CA Type 1 | Additional parts have no assigned figure



mmToolParts
Big Time Experience. Small Town Service. .com

DW378G-CA Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DW378G-CA Type 1 | Additional parts have no assigned figure

Fig. 1	145344-01	BLADE BOLT
Fig. 2	381018-00	BLADE CLAMP
Fig. 3	381017-00	WASHER OUTER CLAMP
Fig. 4	381004-00	SPINDLE
Fig. 5	381067-00	O-RING
Fig. 7	388496-00	RETAINER
Fig. 8	385865-00	SCREW
Fig. 9	381057-00SV	UPPER GUARD
Fig. 10	656823-00SV	LOWER GUARD
Fig. 11	381066-00	BUMPER
Fig. 12	381075-00	SCREW
Fig. 13	605040-15	BEARING BALL
Fig. 14	5140160-68	HUB & SPRING
Fig. 15	394877-00	LEVER
Fig. 16	148641-00	LOCK NUT
Fig. 18	381058-00SV	GEAR CASE ASM
Fig. 19	381065-00	CORD CLAMP
Fig. 20	330019-02	SCREW
Fig. 21	381054-00SV	ARMATURE & BRGS
Fig. 23	381020-00	FIELDCASE
Fig. 25	381050-01	HOOK
Fig. 26	381063-00	HANDLE SA
Fig. 27	330003-29	BEARING BALL
Fig. 28	381032-00	BRUSH COVER
Fig. 29	381052-00	SPRING
Fig. 30	429913-00	BOLT
Fig. 31	381042-00	SEAL
Fig. 32	381043-00	SEAL
Fig. 33	N030334	SWITCH

mmToolParts
Big Time Experience. Small Town Service. .com

DW378G-CA Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DW378G-CA Type 1 | Additional parts have no assigned figure

Fig. 34	384127-01	SCREW
Fig. 34	N111595	SCREW
Fig. 35	381059-00	SEAL
Fig. 36	381051-00	BUSHING
Fig. 37	388828-00SV	SPINDLE LOCK
Fig. 38	381056-00	FIELD 115V
Fig. 39	605040-20	BEARING
Fig. 40	145312-00	PLUG
Fig. 41	381024-00	BRUSH & HOLDER SA
Fig. 42	381028-10	BRUSH
Fig. 43	381053-00	DETENT
Fig. 44	330043-01	PIN
Fig. 45	605040-27	BEARING
Fig. 48	381071-00SV	SHOE
Fig. 49	396631-00	SCREW
Fig. 52	145347-00	LEVER
Fig. 54	152211-00	RING
Fig. 55	610744-00	NUT
Fig. 56	610625-00	NUT
Fig. 60	330100-98	CORDSET
Fig. 61	330005-02	CORD PROTECTOR
Fig. 63	611966-00	NAMEPLATE
Fig. 64	098128-37	CARRIAGE BOLT
Fig. 65	330019-30	SCREW
Fig. 67	330045-15	SCREW
Fig. 68	330019-13	SCREW
Fig. 69	330019-14	SCREW
Fig. 70	330045-20	SCREW
Fig. 72	330019-27	SCREW

mmToolParts
Big Time Experience. Small Town Service. .com

DW378G-CA Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DW378G-CA Type 1 | Additional parts have no assigned figure

Fig. 73	381069-00	SCREW
Fig. 74	098094-13	SCREW
Fig. 75	5140160-00	SCREW
Fig. 76	381045-00	O RING
Fig. 77	381068-00	SEAL
Fig. 78	053650-03	TERMINAL
Fig. 101	392666-00	NUT WING
Fig. 103	145378-01	WRENCH
Fig. 800	449562-01	LUBRICANT-6 OZ.
Fig. 856	DW3178	7-1/4 24T SAW BL - CARDED
Fig. 861	392345-00	KIT BOX

mmToolParts
Big Time Experience. Small Town Service. .com

DW378G-CA Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DW378G-CA Type 1 | Additional parts have no assigned figure

Additional parts - no figure assigned by DeWalt

-	145345-00	SCREW.SPECIAL
-	145378-02	WRENCH
-	150339-00	TERMINAL
-	152014-00	WASHER
-	330003-08	BEARING
-	330003-09	BEARING
-	330003-13	BEARING
-	330019-11	SCREW
-	381004-00SV	SPINDLE ASM
-	381026-00	SPRING TORSION
-	381028-01	BRUSH
-	381033-00	SWITCH
-	381050-00	HOOK
-	381054-00	ARMATURE 110V
-	381057-00	GUARD UPPER
-	381058-00	GEARCASE SA
-	381071-00	SHOE SA
-	387906-00	NP:DW378G T1
-	388823-03	NUT & WASHER
-	388828-00	SPINDLE LOCK
-	445338-00	CORD PROTECTOR
-	541351-00	RING
-	614497-00	O RING
-	643362-00	HUB
-	647343-00	SPRING
-	656823-00	LOWER GUARD
-	98094-13	SCREW
-	98103-17	SCREW

mmToolParts
Big Time Experience. Small Town Service. .com

DW378G-CA Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DW378G-CA Type 1 | Additional parts have no assigned figure

-	98128-37	CARRIAGE BOLT

mmToolParts
Big Time Experience. Small Town Service. .com