
DW678K-CA Type 4 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DW678K-CA Type 4 | Additional parts have no assigned figure



mmToolParts
Big Time Experience. Small Town Service. .com

DW678K-CA Type 4 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DW678K-CA Type 4 | Additional parts have no assigned figure

Fig. 1	578603-02	ARMATURE 115V
Fig. 2	327429-14	FIELD 115V
Fig. 3	327383-01	SWITCH 115V
Fig. 4	575963-04	BRUSH PAIR 115V
Fig. 5	330072-97	CORDSET
Fig. 6	574232-01	BLADEDRUM SA
Fig. 7	916969-00	CORD PROTECTOR
Fig. 8	329301-00	CORD CLAMP
Fig. 9	330065-06	SCREW
Fig. 10	323635-17	LEAD SA
Fig. 12	323635-18	LEAD SA
Fig. 13	326592-00	CAP
Fig. 14	328772-00	NUT
Fig. 15	326590-01	BASE
Fig. 16	326589-04	SCALE
Fig. 17	326381-00	RATCHET
Fig. 18	327341-00	WASHER SPRING
Fig. 19	000000-00	NO LONGER AVAILABLE
Fig. 20	326629-00	COVER BRUSH
Fig. 21	326636-00	POST
Fig. 22	330065-08	SCREW
Fig. 25	323722-00	SPRING
Fig. 26	326823-01	BUSH
Fig. 27	324006-00	SCREW
Fig. 28	327387-00	EJECTOR
Fig. 29	324006-11	SCREW
Fig. 30	578758-00	BRAND LABEL
Fig. 32	572255-00	SPRING
Fig. 34	323481-00	CAP

mmToolParts
Big Time Experience. Small Town Service. .com

DW678K-CA Type 4 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DW678K-CA Type 4 | Additional parts have no assigned figure

Fig. 35	605040-63	BEARING
Fig. 37	326596-00	BAFFLE
Fig. 39	324006-06	SCREW
Fig. 40	327381-00	HOUSING BEARING
Fig. 41	605040-23	BEARING
Fig. 42	577745-00	BEARING
Fig. 43	324105-00	PULLEY
Fig. 44	327065-00	PINION
Fig. 45	325106-00	BELT TOOTHED
Fig. 46	761225-02	NUT
Fig. 47	329269-00	COVER
Fig. 48	574696-01	COVER
Fig. 54	330004-31	BEARING
Fig. 55	327392-00	ADAPTOR
Fig. 57	327393-00	GUIDE
Fig. 58	326573-01	SCREW WING
Fig. 59	327391-00	GUIDE FENCE
Fig. 60	328834-00	NUT WING
Fig. 61	911111-00	BOLT
Fig. 62	328175-00	BRACKET
Fig. 64	326637-00	GUARD
Fig. 68	330065-10	SCREW
Fig. 70	N542564	CLAMP SA
Fig. 72	N381124	STAND
Fig. 82	868148-00	SPANNER
Fig. 89	273794	BLADE
Fig. 90	574754-00	WARNING LABEL
Fig. 91	574541-00	HEX KEY 2.5 MM
Fig. 97	329145-00	CLIP

mmToolParts
Big Time Experience. Small Town Service. .com

DW678K-CA Type 4 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DW678K-CA Type 4 | Additional parts have no assigned figure

Fig. 98	328848-00	GUARD
Fig. 99	328847-00	SPRING
Fig. 100	330065-04	SCREW
Fig. 101	579448-00	RATING PLATE
Fig. 107	329323-00	SEAL
Fig. 110	571213-00	BAFFLE
Fig. 861	578772-54	KITBOX

mmToolParts
Big Time Experience. Small Town Service. .com

DW678K-CA Type 4 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DW678K-CA Type 4 | Additional parts have no assigned figure

Additional parts - no figure assigned by DeWalt

-	326635-01	STAND
-	330003-11	BEARING
-	330003-35	BEARING
-	330004-07	BEARING NEEDLE
-	372105-01	BLADE
-	577706-00	CLAMP SA
-	578772-04	KITBOX

mmToolParts
Big Time Experience. Small Town Service. .com