
DW708-BR Type 2 - Parts List

Use the figure number to match each part to the corresponding parts schematic.



mmToolParts
Big Time Experience. Small Town Service. .com

DW708-BR Type 2 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

Fig. 1	98094-55	SCREW
Fig. 2	330019-19	SCREW
Fig. 3	330019-13	SCREW
Fig. 4	153778-00	SCREW
Fig. 5	330045-05	SCREW
Fig. 6	330045-13	SCREW
Fig. 7	330045-14	SCREW
Fig. 8	330045-15	SCREW
Fig. 9	330045-18	SCREW
Fig. 11	330045-20	SCREW
Fig. 12	145344-01	BLADE BOLT
Fig. 13	153666-00	SCREW
Fig. 14	604410-01	SCREW
Fig. 15	153637-02	SCREW
Fig. 16	330045-23	SCREW
Fig. 17	150075-00	SCREW
Fig. 18	153576-00	SCREW
Fig. 19	394034-00	SCREW
Fig. 20	144949-00	SCREW.SPECIAL
Fig. 21	386112-00	SCREW
Fig. 22	151799-00	SCREW
Fig. 23	153639-00	SCREW
Fig. 24	384127-01	SCREW
Fig. 25	147791-00	SCREW
Fig. 26	330045-06	SCREW
Fig. 27	330045-47	SCREW
Fig. 28	330045-33	SCREW
Fig. 29	330019-03	SCREW
Fig. 30	330019-14	SCREW

mmToolParts
Big Time Experience. Small Town Service. .com

DW708-BR Type 2 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

Fig. 31	330045-24	SCREW
Fig. 32	5140117-87	SCREW
Fig. 33	153794-00	NUT
Fig. 34	153792-00	WASHER
Fig. 35	062487-00	WASHER
Fig. 36	153781-00	WASHER
Fig. 37	153559-00	WASHER
Fig. 38	153782-00	WASHER
Fig. 39	098198-05	WASHER
Fig. 40	153769-01	WASHER THRUST
Fig. 41	153586-00	WASHER
Fig. 42	148296-00	WASHER
Fig. 43	153655-00	WASHER
Fig. 44	144803-00	CIRCLIP
Fig. 46	393071-00	PLATE
Fig. 47	142273-00	RING
Fig. 48	153752-00	RETAINER
Fig. 49	153763-00	RING
Fig. 50	153783-00	RING
Fig. 51	034158-00	O RING
Fig. 52	39945-00	RING
Fig. 53	140733-00	SPRING
Fig. 54	606888-00	SPRING
Fig. 55	448176-00	SPRING
Fig. 56	096723-00	SPRING
Fig. 57	88165-00	SPRING
Fig. 58	150718-00	NUT WING
Fig. 59	167785-00	SPRING
Fig. 60	153596-01	SPRING

mmToolParts
Big Time Experience. Small Town Service. .com

DW708-BR Type 2 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

Fig. 61	N110359	BEARING
Fig. 62	N127530	BEARING BALL
Fig. 66	330004-02	BEARING NEEDLE
Fig. 67	330003-47	BEARING
Fig. 68	065786-00	BEARING
Fig. 69	153554-00	DRIVE PULLEY
Fig. 70	153796-00	PULLEY
Fig. 71	153555-00	BELT
Fig. 72	153560-00	GASKET
Fig. 73	153561-00	LOCKING PIN
Fig. 74	153638-00	KEY
Fig. 76	5140000-28	GEARCASE SA
Fig. 77	604765-00	CLAMP OUTER
Fig. 78	152636-00	BLADE HOLDER
Fig. 79	604768-00	BLADE CLAMP
Fig. 81	153649-00	SLEEVE
Fig. 82	153563-00	COVER
Fig. 83	391317-00	FIELDCASE
Fig. 84	391933-01	END CAP
Fig. 85	391325-00	IDENTITY LABEL
Fig. 86	153797-00	BOLT
Fig. 88	N225698	ARMATURE ASSEMBLY
Fig. 89	391318-00SV	FIELD 115V
Fig. 90	389512-01	BRUSH PLATE
Fig. 91	616467-00	NAME PLATE
Fig. 92	391375-00	BAFFLE
Fig. 93	397931-00	MOTOR CORD
Fig. 94	394036-00	PLATE
Fig. 95	615828-02	CORDSET

mmToolParts
Big Time Experience. Small Town Service. .com

DW708-BR Type 2 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

Fig. 96	5140125-81	CONNECTOR
Fig. 97	395624-00	COVERPLATE
Fig. 98	153669-00	CORD CLAMP
Fig. 99	153609-00	SWITCH
Fig. 101	153755-01	CLAMSHELL PAIR
Fig. 102	429932-00	ARM LINK
Fig. 103	153721-00	FOAM
Fig. 104	153562-00	BELT COVER
Fig. 105	153648-06	UPPER GUARD ASY
Fig. 106	605188-00	LABEL, IDENT
Fig. 107	605408-00	DUST PORT
Fig. 109	606883-02	GUARD
Fig. 110	153719-01	LINK
Fig. 111	145318-00	BUMPER
Fig. 112	146774-00	ROLLER
Fig. 113	146740-00	SLEEVE
Fig. 114	385756-00	BUSH
Fig. 115	146751-00	SHAFT
Fig. 116	153593-01	SPACER
Fig. 118	387131-00	LOCKING PIN
Fig. 119	397000-00	SCREW.SPECIAL
Fig. 120	153603-01	PAWL
Fig. 121	429941-00	TRUNNION
Fig. 123	153582-00	GUIDE
Fig. 126	147107-03	KNOB
Fig. 128	605155-00	BUSHING
Fig. 131	153578-00	SCALE
Fig. 132	153575-00	POINTER
Fig. 133	392422-00	HANDLE

mmToolParts
Big Time Experience. Small Town Service. .com

DW708-BR Type 2 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

Fig. 135	386757-01	PIN
Fig. 136	153574-00	BUTTON RELEASE
Fig. 137	615045-00	TABLE
Fig. 138	5140006-45	PIVOT SHAFT
Fig. 139	153640-00	PIN
Fig. 140	153620-04	PLATE,MITER DET
Fig. 141	153624-00	POINTER
Fig. 142	153632-00	PIN
Fig. 143	153621-00	HANDLE
Fig. 144	153722-01	TRIGGER
Fig. 145	153622-00	LOCKING PIN
Fig. 146	153626-00	LEVER
Fig. 147	682149-00	BUSH
Fig. 148	153768-00	SPRING SA
Fig. 149	395672-00	PLATE SA
Fig. 152	153765-03	BASE
Fig. 153	153612-00	FOOT
Fig. 154	153614-01	THRUST PLATE
Fig. 156	153627-00	FENCE SA
Fig. 157	153766-06	FENCE, LEFT
Fig. 158	153767-07	FENCE,RIGHT
Fig. 159	147107-02	KNOB LOWER
Fig. 163	608563-01	WRENCH SPECIAL
Fig. 164	381028-08	BRUSH & LEAD
Fig. 166	606512-00	WARNING LABEL
Fig. 167	616674-00	LABEL,WARNING
Fig. 168	390905-00	SUPPORT BRACKET
Fig. 169	609003-00	WARNING LABEL
Fig. 173	385652-00SV	LOCK SA

mmToolParts
Big Time Experience. Small Town Service. .com

DW708-BR Type 2 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

Fig. 191	145312-00	PLUG
Fig. 192	330045-45	SCREW
Fig. 193	391358-01	HOLDER
Fig. 194	398367-00	SCREW
Fig. 200	147734-06	DUSTBAG
Fig. 201	606886-00	GUARD PLATE
Fig. 202	607137-00	COVER
Fig. 203	385915-01	SCREW
Fig. 205	613497-00	THRUST PLATE
Fig. 206	395716-00	TERMINAL
Fig. 800	5140061-28	GREASE
Fig. 800	93488-00	GREASE
Fig. 856	153650-00	CLAMP
Fig. 856	5140050-83	LENGTH STOP
Fig. 856	624616-00	BLADE
Fig. 856	DW7053	DUST BAG SA
Fig. 856	DW7080	EXTENSION SYSTEM
Fig. 856	DW7084	STOP PLATE
Fig. 860	340992-08	BIT

mmToolParts
Big Time Experience. Small Town Service. .com