
DW818-BR Type 5 - Parts List

Use the figure number to match each part to the corresponding parts schematic.



mmToolParts
Big Time Experience. Small Town Service. .com

DW818-BR Type 5 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

Fig. 101	401702-11	ARMATURE 115V
Fig. 102	605527-01	FIELD 115V
Fig. 103	NA952688	SWITCH
Fig. 104	939539-00	BRUSH CUT OFF
Fig. 105	330122-18	CORD & PLUG
Fig. 106	401678-05	OUTER FLANGE
Fig. 107	391969-00	INNER FLANGE
Fig. 108	385676-00	SCREW
Fig. 110	397661-01	GUARD SA
Fig. 111	631609-02	SCREW
Fig. 112	330045-46	SCREW
Fig. 113	608801-00	GEAR CASE COVER
Fig. 114	616144-00	SPINDLE
Fig. 116	N918736	CORD PROTECTOR
Fig. 117	390701-00	GEAR
Fig. 118	562097-01	SCREW
Fig. 119	615073-00SV	GEAR CASE ASSY.
Fig. 120	652465-00	RETAINING PLATE
Fig. 121	562211-00	HANDLE SIDE SA
Fig. 122	604597-00	WASHER
Fig. 123	945292-00	NUT
Fig. 124	944575-00	BUTTON
Fig. 125	562210-00	SPRING
Fig. 126	944571-00	SPINDLE LOCK
Fig. 127	330003-64	BEARING
Fig. 128	641823-00	SLEEVE
Fig. 129	401623-00	BAFFLE
Fig. 130	949638-01	BUFFER
Fig. 132	606574-01SV	BRUSH HOLDER

mmToolParts
Big Time Experience. Small Town Service. .com

DW818-BR Type 5 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

Fig. 133	562204-00	SPRING
Fig. 134	615071-04	FIELD CASE ASSY
Fig. 135	605040-02	BEARING
Fig. 136	613186-01	END CAP
Fig. 137	611540-00	SUPPORT
Fig. 138	401680-00	WRENCH
Fig. 139	562097-05	SCREW
Fig. 140	401622-01	FLANGE
Fig. 145	562097-00	SCREW
Fig. 153	562100-01	PINION
Fig. 160	N110359	BEARING
Fig. 162	611737-01	LINK
Fig. 163	569624-01	BUTTON
Fig. 164	562097-13	SCREW
Fig. 166	398906-00	SPACER INSULATING
Fig. 171	393799-00	O RING
Fig. 800	286436-00	GREASE
Fig. 821	614727-01	NAME PLATE
Fig. 856	562086-10	GRINDING WHEEL

mmToolParts
Big Time Experience. Small Town Service. .com