



Parts List for DW818 Type 1

Item Number	Part Number	Description	Qty Required
101	401702-07	ARMATURE	1
102	000000-00	No Longer Available	1
102	395991-01	LEADED FIELD	1
103	945614-00	SWITCH,ON/OFF	1
104	939539-00	BRUSH,CUTOFF	2
105	330072-47	POWER CORD	1
106	401678-06	WASHER	1
107	389181-00	FLANGE,INNER	1
108	562160-06	SCREW	3
109	605415-00	FLANGE	1
110	393163-00	GUARD	1
111	393576-00	GUARD SPRING	1
112	562160-07	SCREW	1
113	945298-00	COVER,GEAR CASE	1
114	391052-00	SPINDLE,5/8X11	1
116	330005-01	PROTECTOR,CORD	1
117	390701-00	GEAR	1
118	562097-01	SCREW	4
119	610704-01	GEAR CASE ASSY.	1
121	149142-00	HANDLE,SIDE	1
122	945299-00	FLANGE	1
123	945292-00	NUT	1
124	944574-00	BUTTON	1
125	562210-00	SPRING	1
126	944571-00	LOCK,SPINDLE	1
127	605040-22	BEARING	1
128	930275-00	COVER,BEARING	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for DW818 Type 1

Item Number	Part Number	Description	Qty Required
129	401623-00	BAFFLE	1
130	949638-01	PLUG,RUBBER	2
132	395985-00S	BRUSH HOLDER	1
132	000000-00	No Longer Available	1
133	562204-00	SPRING	2
134	000000-00	No Longer Available	1
134	000000-00	No Longer Available	1
135	605040-02	BALL BEARING	1
136	613186-00	END CAP	1
137	5140000-13	SWITCH SUPPORT	1
138	401680-00	WRENCH	1
139	562097-05	SCREW	1
140	401622-01	RETAINER,BRG	1
145	562097-00	SCREW	2
149	402489-00	FELT PAD	2
153	562100-01	PINION	1
160	330003-60	BEARING	1
162	611737-01	SWITCH LINK	1
163	569624-01	SWITCH BUTTON	1
164	562097-13	SCREW	1
800	286436-00	GREASE	1
816	946194-00	LABEL	1
821	233308-00	DEWALT NP-SHEET	1
856	DW4514	4-1/2X1/4 METL	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.