

129
130
135
128
140
101
166
124
119
123
153
160
125
118
121
171
172
104
133
132
134
145
104
126
114
162
102
163
136
164
821
103
816
112
111
109
108
110
139
116
105
137
107
138
800
106

Parts List for DW818-AR Type 4

Item Number	Part Number	Description	Qty Required
101	401702-10	ARMATURE	1
102	605527-00	FIELD	1
103	945614-00	SWITCH,ON/OFF	1
104	939539-01	POP-OFF BRUSH	2
105	330080-55	CORD & PLUG	1
106	401678-05	FLANGE	1
107	391969-00	CLAMP WASHER	1
108	562160-06	SCREW	3
109	605415-00	FLANGE	1
110	944685-00	GUARD	1
111	393576-00	GUARD SPRING	1
112	330045-46	SCREW	4
114	945301-12	SPINDLE ASSY	1
116	330005-01	PROTECTOR,CORD	1
118	562097-01	SCREW	4
119	615073-00SV	GEAR CASE ASSY.	1
121	573115-00	HANDLE, SIDE	1
123	945292-00	NUT	1
124	944575-00	BUTTON,LOCK	1
125	562210-00	SPRING	1
126	944571-00	LOCK,SPINDLE	1
128	641823-00	BEARING CUP	1
129	401623-00	BAFFLE	1
130	949638-01	PLUG,RUBBER	2
132	606574-01SV	BRUSH HOLDER	2
133	562204-00	SPRING	2
134	395243-24SV	FIELD CASE ASSY	1

COPYRIGHT© 2005. All Rights Reserved.
Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for DW818-AR Type 4

Item Number	Part Number	Description	Qty Required
135	605040-02	BALL BEARING	1
136	613186-00	END CAP	1
137	611540-00	SWITCH SUPPORT	1
138	401680-00	WRENCH	1
139	562097-05	SCREW	1
140	401622-01	RETAINER,BRG	1
145	562097-00	SCREW	2
153	562100-01	PINION	1
160	330003-60	BEARING	1
162	611737-01	SWITCH LINK	1
163	569624-01	SWITCH BUTTON	1
164	562097-13	SCREW	1
166	398906-00	SLINGER	1
171	393799-00	O-RING	1
172	396044-00	WARNING LABEL	1
800	286436-00	GREASE	1
816	946194-00	LABEL	1
821	614831-00	NAME PLATE	1

COPYRIGHT© 2005. All Rights Reserved.
Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.