



Parts List for DW818-AR Type 5

Item Number	Part Number	Description	Qty Required
101	401702-10	ARMATURE	1
102	605527-00	FIELD	1
103	945614-01	SWITCH, ON/OFF	1
104	939539-01	POP-OFF BRUSH	2
105	N117779	CORD & PLUG	1
106	401678-05	FLANGE	1
107	391969-00	CLAMP WASHER	1
108	562160-06	SCREW	3
109	605415-00	FLANGE	1
110	944685-00	GUARD	1
111	393576-00	GUARD SPRING	1
112	330045-46	SCREW	4
113	945298-01	GEAR CASE COVER	1
114	641892-00	SPINDLE	1
116	330005-01	PROTECTOR,CORD	1
117	657369-00	GEAR	1
118	562097-01	SCREW	4
119	562304-02S	GEAR CASE ASSY.	1
121	562211-00	HANDLE,SIDE	1
122	945299-00	FLANGE	1
123	945292-00	NUT	1
124	944575-00	BUTTON,LOCK	1
125	562210-00	SPRING	1
126	944571-00	LOCK,SPINDLE	1
127	605040-22	BEARING	1
128	641823-00	BEARING CUP	1
129	401623-00	BAFFLE	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for DW818-AR Type 5

Item Number	Part Number	Description	Qty Required
130	949638-01	PLUG,RUBBER	2
132	606574-01SV	BRUSH HOLDER	2
133	562204-00	SPRING	2
134	615071-03S	FIELD CASE ASSY	1
135	605040-03	BALL BEARING	1
136	613186-00	END CAP	1
137	611540-00	SWITCH SUPPORT	1
138	401680-00	WRENCH	1
139	562097-05	SCREW	1
140	401622-01	RETAINER,BRG	1
145	562097-00	SCREW	2
149	641893-00	FELT SEAL	1
153	657370-00	PINION GEAR	1
160	330003-60	BEARING	1
162	611737-01	SWITCH LINK	1
163	569624-01	SWITCH BUTTON	1
164	562097-13	SCREW	1
166	398906-00	SLINGER	1
171	393799-00	O-RING	1
172	393802-00	LABEL	1
800	286436-00	GREASE	1
816	946194-00	LABEL	1
821	N104779	NAME PLATE	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.