

129
130
135
128
140
101
166
124
125
119
160
153
123
118
104
133
132
145
171
126
121
134
117
113
112
127
120
122
108
114
102
162
163
136
164
103
110
111
821
139
116
105
107
106
138
137
856
800
DEWALT

Parts List for DW818-BR Type 5

Item Number	Part Number	Description	Qty Required
101	401702-11	ARMATURE	1
102	605527-01	FIELD & LEADS	1
103	945614-00	SWITCH,ON/OFF	1
104	939539-00	BRUSH,CUTOFF	2
105	330122-18	CORD & PLUG	1
106	401678-05	FLANGE	1
107	391969-00	CLAMP WASHER	1
108	385676-00	SCREW	3
110	397661-01	GUARD	1
111	631609-02	SCREW	1
112	330045-46	SCREW	4
113	608801-00	GEAR CASE COVER	1
114	616144-00	SPINDLE, M14	1
116	330005-01	PROTECTOR,CORD	1
117	390701-00	GEAR	1
118	562097-01	SCREW	4
119	615073-00SV	GEAR CASE ASSY.	1
120	652465-00	DUST SEAL	1
121	562211-00	HANDLE,SIDE	1
122	604597-00	WASHER	1
123	945292-00	NUT	1
124	944575-00	BUTTON,LOCK	1
125	562210-00	SPRING	1
126	944571-00	LOCK,SPINDLE	1
127	330003-64	BALL BEARING	1
128	641823-00	BEARING CUP	1
129	401623-00	BAFFLE	1

COPYRIGHT© 2005. All Rights Reserved.
Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for DW818-BR Type 5

Item Number	Part Number	Description	Qty Required
130	949638-01	PLUG,RUBBER	2
132	606574-01SV	BRUSH HOLDER	2
133	562204-00	SPRING	2
134	615071-04	FIELD CASE ASSY	1
135	605040-02	BALL BEARING	1
136	613186-01	END CAP	1
137	611540-00	SWITCH SUPPORT	1
138	401680-00	WRENCH	1
139	562097-05	SCREW	1
140	401622-01	RETAINER,BRG	1
145	562097-00	SCREW	2
153	562100-01	PINION	1
160	330003-60	BEARING	1
162	611737-01	SWITCH LINK	1
163	569624-01	SWITCH BUTTON	1
164	562097-13	SCREW	1
166	398906-00	SLINGER	1
171	393799-00	O-RING	1
800	286436-00	GREASE	1
821	614727-01	NAME PLATE	1
856	562086-10	GRINDING WHEEL	1

COPYRIGHT© 2005. All Rights Reserved.
Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.