
# DW866 Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DW866 Type 1 | Additional parts have no assigned figure






mmToolParts
Big Time Experience. Small Town Service. .com

# DW866 Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DW866 Type 1 | Additional parts have no assigned figure

| | | |
|---|---|---|
| Fig. 1 | 146650-39 | ARMATURE |
| Fig. 2 | 619752-00 | FIELD |
| Fig. 3 | 145019-00 | BRUSH & SPRING |
| Fig. 4 | 145018-00 | HOLDER,BRUSH |
| Fig. 5 | 49888-01 | CAP,BRUSH |
| Fig. 6 | 96122-00 | O RING |
| Fig. 7 | 131004-00 | SWITCH |
| Fig. 8 | 50272-98 | CORD |
| Fig. 9 | 14201-00 | BEARING |
| Fig. 9 | 158475-00 | BEARING |
| Fig. 10 | 50271-00 | BEARING |
| Fig. 11 | 62272-00 | FAN |
| Fig. 12 | 62299-00 | SHAFT |
| Fig. 14 | 24926-01 | NUT |
| Fig. 15 | 133064-00 | PINION |
| Fig. 16 | 50241-00 | COVER |
| Fig. 17 | 50047-00 | O RING |
| Fig. 18 | 131519-00 | PLATE |
| Fig. 19 | 072954-00 | SCREW |
| Fig. 20 | 93281-01 | HANDLE ASM |
| Fig. 21 | 922772-00 | BAFFLE,FAN |
| Fig. 22 | 093263-00 | SCREW,CAP |
| Fig. 23 | 36390-00 | WASHER |
| Fig. 24 | 093290-00 | NUT |
| Fig. 25 | 18759-00 | SCREW |
| Fig. 26 | 5140058-90 | WASHER |
| Fig. 27 | 417-00 | WASHER LOCK |
| Fig. 28 | 94593-03 | TERMINAL |
| Fig. 29 | 922773-00 | RING,WEAR |

mmToolParts
Big Time Experience. Small Town Service. .com

# DW866 Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DW866 Type 1 | Additional parts have no assigned figure

| | | |
|---|---|---|
| Fig. 30 | 030612-00 | PLUG |
| Fig. 31 | 50280-02 | CASE,FIELD |
| Fig. 33 | 389212-00 | NP:DW866 T1 |
| Fig. 34 | 15782-00 | LOCKING SCREW |
| Fig. 35 | 093285-00 | SHOE |
| Fig. 36 | 096779-00 | BOLT |
| Fig. 37 | 67414-00 | TUBE |
| Fig. 38 | 63580-00 | FILTER |
| Fig. 39 | 50255-00 | COVER,BRUSH |
| Fig. 40 | 36285-00 | SCREW |
| Fig. 41 | 032172-00 | SCREW |
| Fig. 42 | 93289-00 | WASHER,CLAMP O |
| Fig. 43 | 93288-00 | WASHER,CLAMP I |
| Fig. 44 | 99187-16 | SCREW |
| Fig. 45 | 93272-00 | BUMPER |
| Fig. 46 | 31705-00 | WASHER |
| Fig. 47 | 330019-10 | SCREW |
| Fig. 48 | 132319-01 | CORD CLAMP |
| Fig. 49 | 62300-00 | CORD PROTECTOR |
| Fig. 51 | 50706-00 | BEARING |
| Fig. 52 | 330016-07 | WASHER |
| Fig. 53 | 96089-00 | SCREW |
| Fig. 54 | 131527-02 | SWITCH HANDLE |
| Fig. 55 | 133063-01 | GEAR |
| Fig. 56 | 082007-00 | NUT |
| Fig. 57 | 131673-01 | INSERT |
| Fig. 58 | 920216-00 | WASHER,THRUST |
| Fig. 59 | 48742-00 | WASHER |
| Fig. 60 | 56902-01 | NUT |

mmToolParts
Big Time Experience. Small Town Service. .com

# DW866 Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DW866 Type 1 | Additional parts have no assigned figure

| | | |
|---|---|---|
| Fig. 61 | 91172-00 | LABEL |
| Fig. 62 | 99433-14 | SCREW |
| Fig. 63 | 000416-00 | WASHER |
| Fig. 64 | 082481-00 | WASHER |
| Fig. 65 | 021635-00 | NEEDLE BEARING |
| Fig. 66 | 99461-28 | SCREW.TEMP |
| Fig. 67 | 131678-02 | CASE,GEAR |
| Fig. 68 | 133274-01 | PIN |
| Fig. 69 | 132069-00 | SCREW |
| Fig. 70 | 93293-00 | INSULATOR |
| Fig. 71 | 93294-00 | WASHER |
| Fig. 72 | 99478-09 | WASHER |
| Fig. 73 | 81884-00 | BOLT |
| Fig. 74 | 37327-00 | BOLT |
| Fig. 75 | 93280-02 | CLAMP |
| Fig. 76 | 93273-05 | GUARD |
| Fig. 77 | 849314 | CONNECTOR |
| Fig. 78 | 093291-00 | WRENCH |
| Fig. 79 | 99180-43 | O RING |
| Fig. 80 | 384637-00 | LABEL,IDENT |
| Fig. 81 | 385041-00 | DW8503 MAS WHL |
| Fig. 82 | 385041-01 | DW8501 MET WHL |
| Fig. 800 | 429698-00 | GREASE |
| Fig. 856 | DW4704 | 12 DRY CUT DIAMOND WHEEL |

mmToolParts
Big Time Experience. Small Town Service. .com