
DW871-AR Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DW871-AR Type 1 | Additional parts have no assigned figure



mmToolParts
Big Time Experience. Small Town Service. .com

DW871-AR Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DW871-AR Type 1 | Additional parts have no assigned figure

Fig. 1	330045-16	SCREW
Fig. 2	330019-33	SCREW
Fig. 3	330019-13	SCREW
Fig. 4	330019-14	SCREW
Fig. 5	330019-02	SCREW
Fig. 6	330045-17	SCREW
Fig. 7	330045-20	SCREW
Fig. 8	384844-00	SCREW SPECIAL
Fig. 9	098123-25	SCREW
Fig. 10	098123-16	SCREW
Fig. 11	624158-01	FIELD 230V
Fig. 12	383652-09SV	ARMATURE
Fig. 13	383151-00	FIELDCASE SA
Fig. 14	383155-00	END CAP
Fig. 15	383167-00	BAFFLE
Fig. 16	383685-01SV	BRUSH RING ASM
Fig. 17	386628-00SV	ARM
Fig. 18	605040-27	BEARING
Fig. 19	330003-64	BEARING
Fig. 21	383158-00SV	GEAR CASE COV
Fig. 22	386527-02	GUARD SA
Fig. 23	383175-00	GUARD COVER
Fig. 24	607173-00	INNER FLANGE
Fig. 25	382884-00	CLAMP OUTER
Fig. 26	383286-00	SCREW
Fig. 27	383246-00	WASHER
Fig. 28	383966-00	LOCKING PIN
Fig. 29	384716-00	SPRING
Fig. 32	621514-00S	SWITCH KIT

mmToolParts
Big Time Experience. Small Town Service. .com

DW871-AR Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DW871-AR Type 1 | Additional parts have no assigned figure

Fig. 33	387746-00	SCREW
Fig. 34	387282-00	SPRING
Fig. 35	383168-00SV	PIVOT BRACKET
Fig. 36	383118-00	PIN
Fig. 37	383148-00	LOCKING PIN
Fig. 39	384137-00	FENCE SA
Fig. 40	384180-00S	CLAMP
Fig. 41	382366-00	BASE
Fig. 42	383243-00	FOOT
Fig. 43	384159-00	DEFLECTOR
Fig. 44	330045-23	SCREW
Fig. 45	330080-88	CORD SET
Fig. 46	386540-00	CORD CLAMP
Fig. 47	384762-00	LEAD
Fig. 48	386515-00	LEAD
Fig. 49	386765-00	HOLDER TOOL
Fig. 50	604123-00	NAME PLATE
Fig. 51	397340-00	BRAND LABEL
Fig. 60	330003-17	BEARING
Fig. 61	384612-00	SPRING
Fig. 62	384613-01	BRUSH
Fig. 63	146555-01	BEARING
Fig. 64	382882-00	SPINDLE
Fig. 65	382675-00	KEY
Fig. 66	386277-00	GEAR
Fig. 67	605040-20	BEARING
Fig. 68	386526-00	STOP RUBBER
Fig. 70	391459-00	PLATE LOCK
Fig. 71	382677-00	FENCE

mmToolParts
Big Time Experience. Small Town Service. .com

DW871-AR Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DW871-AR Type 1 | Additional parts have no assigned figure

Fig. 72	382540-00	LEVER
Fig. 73	383254-00	BLOCK
Fig. 74	383450-00	SCREW
Fig. 75	383252-00	LOCK HANDLE
Fig. 76	330036-08	PIN
Fig. 77	395856-00	ROD
Fig. 78	384365-00	WASHER
Fig. 79	607592-00	WASHER
Fig. 80	144803-00	CIRCLIP
Fig. 81	383169-00	CIRCLIP
Fig. 82	5140000-11	PIN
Fig. 83	607278-00	VICE JAW
Fig. 84	386525-01	DOWEL
Fig. 85	383828-00	LOCKING DEVICE
Fig. 86	148641-00	LOCK NUT
Fig. 87	386525-00	DOWEL
Fig. 88	033055-00	PLUG
Fig. 89	383451-00	SADDLE
Fig. 93	098197-09	WASHER
Fig. 94	383810-00	MOUNT SA
Fig. 104	388354-00	WASHER
Fig. 108	397343-00	LABEL
Fig. 109	330045-49	SCREW
Fig. 113	391740-00	SPACER
Fig. 118	391485-00	O RING
Fig. 132	384717-00	WRENCH
Fig. 153	398605-00	RETAINER
Fig. 800	429954-00	GREASE
Fig. 800	583534-00	GREASE

mmToolParts
Big Time Experience. Small Town Service. .com