
DWD460K Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DWD460K Type 1 | Additional parts have no assigned figure



DWD460K Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DWD460K Type 1 | Additional parts have no assigned figure

Fig. 2	660804-00SV	BRUSH
Fig. 3	654946-00	HANDLE SET
Fig. 4	444518-98	CORD
Fig. 5	445338-00	CORD PROTECTOR
Fig. 6	150036-00	SCREW
Fig. 7	450877-00	CORD CLAMP
Fig. 8	330019-11	SCREW
Fig. 10	646486-00	WIRE HARNESS
Fig. 11	N393822	VSR SWITCH
Fig. 12	636379-00	BAR
Fig. 14	N606014	MODULE KIT
Fig. 19	330019-72	SCREW
Fig. 20	330019-32	SCREW
Fig. 21	649086-00	BRUSH DOOR
Fig. 22	648777-00	SCREW
Fig. 23	N469354	BAIL HANDLE
Fig. 24	636385-00	ADJUSTER
Fig. 25	649085-00	BRUSH DOOR
Fig. 26	650093-00SV	SHROUD
Fig. 27	330045-08	SCREW
Fig. 28	650546-00SV	SIDE HANDLE
Fig. 29	660152-00	NAMEPLATE
Fig. 30	659573-00	WARNING LABEL
Fig. 31	659574-00	ID LABEL
Fig. 32	660154-00	LABEL
Fig. 101	636394-00	GEAR CASE
Fig. 102	N182022	FIELD CASE
Fig. 103	636398-00	FAN BAFFLE
Fig. 104	448373-00	WASHER SPRING

mmToolParts
Big Time Experience. Small Town Service. .com

DWD460K Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DWD460K Type 1 | Additional parts have no assigned figure

Fig. 105	636395-00SV	ARMATURE&BRGS.
Fig. 106	636345-00	END CAP
Fig. 107	145312-00	PLUG
Fig. 108	330045-06	SCREW
Fig. 109	660509-01	SPINDLE
Fig. 110	330003-15	BEARING
Fig. 113	652831-00	COVER
Fig. 114	N030550SV	CLUTCH SA
Fig. 116	649228-00	THRUST WASHER
Fig. 117	610541-00	BEARING THRUST
Fig. 119	652890-00	RETAINER
Fig. 121	649351-00	PIN
Fig. 122	636387-00	HOLDER
Fig. 123	636386-01	SPRING
Fig. 124	650249-00	O RING
Fig. 125	326467-00	DETENT
Fig. 126	636388-00	LEVER
Fig. 128	636360-00	SLIDER
Fig. 130	N453556	GEAR
Fig. 131	N019978	GEAR
Fig. 133	636348-00SV	GEAR & PINION
Fig. 134	658818-00	GASKET
Fig. 135	636393-00SV	GEARCASE COVER SA
Fig. 137	660938-00	LEAD
Fig. 138	660938-01	LEAD
Fig. 139	660938-02	LEAD
Fig. 140	660938-03	LEAD
Fig. 141	660938-04	LEAD
Fig. 142	652893-00	GUIDE

mmToolParts
Big Time Experience. Small Town Service. .com

DWD460K Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DWD460K Type 1 | Additional parts have no assigned figure

Fig. 144	660514-01	DETENT
Fig. 145	660513-00	SPACER
Fig. 146	660512-00	SPRING
Fig. 200	N110359	BEARING
Fig. 202	330041-23	ROLLER PIN
Fig. 203	330041-07	PIN
Fig. 204	616857-00	BRUSH HOLDER
Fig. 205	383387-00	BRUSH SPRING
Fig. 206	176951-00	SCREW
Fig. 210	447735-02	SCREW
Fig. 219	636392-00	SLEEVE BEARING
Fig. 220	605040-60	BEARING 6200
Fig. 221	330003-83	BEARING,BALL
Fig. 222	395716-00	TERMINAL
Fig. 223	330034-16	CHUCK KEY
Fig. 224	065288-02	HOLDER
Fig. 225	386780-00	BEARING
Fig. 226	654944-00	BALL BEARING
Fig. 227	5140057-77	CHUCK & KEY
Fig. 800	286436-00	GREASE
Fig. 861	653089-00	KIT BOX

mmToolParts
Big Time Experience. Small Town Service. .com