
DWEHF1838K-CA Type 0 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DWEHF1838K-CA Type 0 | Additional parts have no assigned figure

DEWALT
DWEHF1838K



IP1470-1RA 07/16
To be used with parts list IP1470-2 and operation and maintenance manual 9R214370.

mmToolParts
Big Time Experience. Small Town Service. .com

DWEHF1838K-CA Type 0 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DWEHF1838K-CA Type 0 | Additional parts have no assigned figure

Fig. 1	182237	SCREW
Fig. 2	9R215113	CAP
Fig. 3	175682	GASKET
Fig. 4	180445	PLATE
Fig. 4	N905958	PLATE
Fig. 5	180446	SEAL
Fig. 6	180447	SPRING
Fig. 7	180448	O RING
Fig. 8	180449	WASHER
Fig. 9	180450-S	BODY
Fig. 10	180205-K	DRIVER SA
Fig. 11	180457	PISTON RING
Fig. 11	N905972	PISTON RING
Fig. 12	180458	CYLINDER
Fig. 13	180459	O RING
Fig. 14	180460	SEAL
Fig. 15	180461	BUMPER
Fig. 16	180462	GUIDE
Fig. 16	N906034	GUIDE
Fig. 17	9R215112	FRAME
Fig. 18	180463	GASKET
Fig. 19	180465	CAP
Fig. 20	MSC4070-16	SCREW
Fig. 21	182235	FILTER
Fig. 22	180577	MUFFLER
Fig. 23	180475	PIN
Fig. 24	174345	PIN
Fig. 25	184518	BUTTON LOCK-ON
Fig. 26	184519	PIN

mmToolParts
Big Time Experience. Small Town Service. .com

DWEHF1838K-CA Type 0 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DWEHF1838K-CA Type 0 | Additional parts have no assigned figure

Fig. 27	MRG002514	O RING
Fig. 28	182182	PIN TRIGGER
Fig. 29	181956	TRIGGER ASSY.
Fig. 30	182181	O-RING
Fig. 31	TVA21	TRIGGER VALVE KIT
Fig. 32	180476	SPRING
Fig. 33	180192	MAGAZINE
Fig. 34	9R215119	MAGAZINE BRACKET
Fig. 35	180528	SPRING
Fig. 36	9R195735	LATCH
Fig. 37	180504	WASHER
Fig. 37	N905878	WASHER
Fig. 39	174307	SCREW
Fig. 40	MHE4070-100	NUT
Fig. 41	180198	PUSHER
Fig. 42	180206	MAGAZINE SA
Fig. 43	9R214371	WARNING LABEL
Fig. 44	9R214377	PRODUCT/FAST. LABEL
Fig. 47	180636	NOSE-MACHINING
Fig. 48	180490	PIN
Fig. 49	9R215121	INSERT
Fig. 50	158443	FOOT-ADJUSTABLE
Fig. 51	9R215122	KNOB
Fig. 52	117398	SCREW-HHCS-M6X1.0X30
Fig. 53	188697	GUIDE- BLOCK
Fig. 54	121052	SCREW
Fig. 55	180637	COVER TRIP
Fig. 56	180199	GUIDE
Fig. 57	180527	SPRING

mmToolParts
Big Time Experience. Small Town Service. .com

DWEHF1838K-CA Type 0 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DWEHF1838K-CA Type 0 | Additional parts have no assigned figure

Fig. 58	180526	ROD
Fig. 59	180200	SUPPORT
Fig. 60	180201	END CAP
Fig. 61	MPG030012	PIN
Fig. 62	180567	PIN
Fig. 63	180208	PLATE
Fig. 64	180641	GUIDE-LOWER CONTACT
Fig. 65	180646	TRIP SPRING
Fig. 66	180639	TRIP-UPPER
Fig. 67	189986	CONTACT ARM
Fig. 69	BTFP72333	PLUG
Fig. 70	189882	PIN,SOLID
Fig. 800	100679	GREASE
Fig. 800	9R206705	LUBE (2CC)
Fig. 876	102341	BLOCK-INSTALLATION

mmToolParts
Big Time Experience. Small Town Service. .com

DWEHF1838K-CA Type 0 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DWEHF1838K-CA Type 0 | Additional parts have no assigned figure

Additional parts - no figure assigned by DeWalt

-	100653	GREASE
-	180205	DRIVER SA
-	9R189986	CONTACT ARM
-	ISWIVEL-14M	AIR CONNECTION

mmToolParts
Big Time Experience. Small Town Service. .com