
DWS780-AR Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.


SE



mmToolParts
Big Time Experience. Small Town Service. .com

DWS780-AR Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.



mmToolParts
Big Time Experience. Small Town Service. .com

DWS780-AR Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

Fig. 1	N240379	ARM ASSEMBLY
Fig. 2	618193-00	BELT COVER
Fig. 3	330045-14	SCREW
Fig. 4	146751-00	SHAFT
Fig. 5	146732-00	SPACER
Fig. 6	N039404	SPRING
Fig. 7	150075-00	SCREW
Fig. 8	148296-00	WASHER
Fig. 9	387130-00	LOCKING PIN
Fig. 10	034158-00	O RING
Fig. 11	N058304	GUARD REAR
Fig. 12	330045-23	SCREW
Fig. 13	153603-01	PAWL
Fig. 14	153639-00	SCREW
Fig. 15	153655-00	WASHER
Fig. 16	N185664	SCREW
Fig. 17	150718-00	NUT WING
Fig. 18	N030317	LED LIGHT
Fig. 20	618198-00	SCREW
Fig. 23	145344-01	BLADE BOLT
Fig. 24	151962-01	CLAMP OUTER
Fig. 25	152636-00	BLADE HOLDER
Fig. 26	644999-00	WASHER INNER CLAMP
Fig. 28	393702-00SV	SPINDLE & GEAR
Fig. 29	330003-66	BEARING,BALL
Fig. 30	391616-00	BEARING NEEDLE
Fig. 31	NA135793	SPINDLE & GEAR SA
Fig. 32	605040-20	BEARING
Fig. 33	605040-33	BEARING

mmToolParts
Big Time Experience. Small Town Service. .com

DWS780-AR Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

Fig. 34	N105443	PULLEY SA
Fig. 35	153752-00	RETAINER
Fig. 36	618244-00	RETAINING PLATE
Fig. 37	330045-49	SCREW
Fig. 38	391310-00	BEARING PLATE
Fig. 40	N004511	DRIVE PULLEY
Fig. 44	5140239-56	GEARCASE COVER SA
Fig. 45	391315-00	GASKET
Fig. 47	153555-00	BELT
Fig. 48	N004510	DRIVE PULLEY
Fig. 49	153561-00	LOCKING PIN
Fig. 50	448176-00	SPRING
Fig. 51	393071-00	PLATE
Fig. 52	330045-45	SCREW
Fig. 53	153559-00	WASHER
Fig. 56	146740-00	SLEEVE
Fig. 57	394589-01	SCREW
Fig. 60	330045-15	SCREW
Fig. 61	N142121	DUST PORT
Fig. 62	N080677	KNOB
Fig. 68	N058308	POINTER
Fig. 69	N058309	POINTER
Fig. 70	N080199	KNOB
Fig. 72	060325-01	RING
Fig. 74	330045-06	SCREW
Fig. 76	N090294	BEVEL SCALE
Fig. 80	N043045	PAWL
Fig. 83	N049689	STOP RH
Fig. 85	N051519	STOP LH

mmToolParts
Big Time Experience. Small Town Service. .com

DWS780-AR Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

Fig. 91	330015-03	NUT
Fig. 92	N058312	SCREW
Fig. 93	N772471	BASE SA
Fig. 94	618192-00	PLATE
Fig. 95	N057391	PLATE
Fig. 96	N773133	TABLE SA
Fig. 97	N401778	COVER
Fig. 99	049787-00	O RING
Fig. 100	N058318	SCREW
Fig. 101	N044739	LOCK NUT
Fig. 102	153792-00	WASHER
Fig. 103	N059784	PLATE
Fig. 104	604410-00	SCREW
Fig. 105	391358-01	HOLDER
Fig. 106	608563-01	WRENCH SPECIAL
Fig. 107	N057963	POINTER
Fig. 108	N050755	ACTUATOR
Fig. 109	N066280	PLATE
Fig. 110	622396-00	SHAFT
Fig. 111	622395-00	LEVER LOCK-OFF
Fig. 112	N488468	DETENT
Fig. 114	093128-00	BEARING NEEDLE
Fig. 115	618254-00	RETAINER
Fig. 116	N082785	LEVER
Fig. 117	N057386	PIN
Fig. 118	624460-00	PIN
Fig. 119	624461-00	SLEEVE
Fig. 120	618186-00	ROD
Fig. 121	618185-00	BLOCK

mmToolParts
Big Time Experience. Small Town Service. .com

DWS780-AR Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

Fig. 122	385915-03	SCREW
Fig. 123	618253-00	SPRING COMPRESSION
Fig. 124	624730-00	HANDLE SA
Fig. 125	330045-18	SCREW
Fig. 126	330019-32	SCREW
Fig. 127	N078832	SA POWER SUPPLY
Fig. 128	606056-00	SWITCH
Fig. 129	384127-01	SCREW
Fig. 130	330045-25	SCREW
Fig. 131	N114499	MOTOR CORD
Fig. 132	N104994	CORD
Fig. 133	N083060	HANDLE
Fig. 134	330019-22	SCREW
Fig. 135	398443-00	CABLE CLAMP
Fig. 137	N030322	COVER
Fig. 138	N597938	FENCE
Fig. 139	N240440	LEFT FENCE
Fig. 140	N301219	RIGHT FENCE
Fig. 141	147107-02	KNOB LOWER
Fig. 142	098105-03	SCREW
Fig. 143	391317-05	FIELDCASE
Fig. 144	N093107	ARMATURE
Fig. 145	391318-01SV	FIELD
Fig. 146	391282-00	MOUNTING BRACKET
Fig. 147	394034-00	SCREW
Fig. 148	N127530	BEARING BALL
Fig. 149	N110359	BEARING
Fig. 150	144803-00	CIRCLIP
Fig. 151	145312-00	PLUG

mmToolParts
Big Time Experience. Small Town Service. .com

DWS780-AR Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

Fig. 152	98094-55	SCREW
Fig. 153	391933-01	END CAP
Fig. 154	330019-13	SCREW
Fig. 155	330019-19	SCREW
Fig. 156	391375-00	BAFFLE
Fig. 157	389512-01	BRUSH PLATE
Fig. 158	391325-00	IDENTITY LABEL
Fig. 159	N084742	NAMEPLATE
Fig. 160	153783-00	RING
Fig. 161	605155-00	BUSHING
Fig. 163	330019-12	SCREW
Fig. 170	N084698SV	HOUSING SA
Fig. 170	N121003	CARRIAGE SA
Fig. 171	603390-00	SCREW
Fig. 172	397118-00	GUIDE
Fig. 173	153576-04	SCREW
Fig. 174	613497-00	THRUST PLATE
Fig. 176	682149-00	BUSH
Fig. 177	N051244	BUMPER
Fig. 178	659919-00	SPRING
Fig. 179	612008-00	SCREW
Fig. 180	N056883	LOCK HANDLE
Fig. 181	330016-04	WASHER
Fig. 183	N095579	LEVER SA
Fig. 184	167785-00	SPRING
Fig. 185	N041865	PIN
Fig. 186	660786-00	BUSHING
Fig. 187	153797-00	BOLT
Fig. 188	N058315	SCREW.SPECIAL

mmToolParts
Big Time Experience. Small Town Service. .com

DWS780-AR Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

Fig. 189	385946-00	WASHER SPRING
Fig. 192	153797-04	SCREW
Fig. 193	N377514	BUSHING
Fig. 194	N058306	DUST DEFLECTOR
Fig. 195	153451-00	BEARING THRUST
Fig. 200	393706-00	LABEL
Fig. 201	630403-00	WARNING LABEL
Fig. 202	148608-00	INSERT
Fig. 203	386780-00	BEARING
Fig. 204	N028803	GUARD LOWER
Fig. 205	N020822	PLATE
Fig. 206	385915-01	SCREW
Fig. 207	621037-00	PLATE
Fig. 207	N390812	LOWER GUARD ASSY
Fig. 208	146768-00	BUMPER
Fig. 209	N142523	LINK
Fig. 213	N034013	SPRING
Fig. 214	148295-00	SLEEVE
Fig. 215	625825-00	ROLLER
Fig. 216	142273-00	RING
Fig. 217	394976-00	LABEL
Fig. 218	146760-02	STUD
Fig. 219	153666-00	SCREW
Fig. 221	145332-00	TERMINAL
Fig. 223	630416-00	WARNING LABEL
Fig. 224	381028-08	BRUSH & LEAD
Fig. 225	395716-00	TERMINAL
Fig. 226	153669-00	CORD CLAMP
Fig. 227	N391680	RETAINER

mmToolParts
Big Time Experience. Small Town Service. .com

DWS780-AR Type 1 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

Fig. 228	397117-00	SEAL
Fig. 229	N049684	COVERPLATE
Fig. 230	618142-00	END CAP
Fig. 231	N069475	TRUNNION
Fig. 239	147734-06	DUSTBAG
Fig. 239	DW7053	DUST BAG SA
Fig. 240	630065-00	CLAMP SA
Fig. 247	N058314	SCREW
Fig. 248	N043046	PAWL
Fig. 250	330019-14	SCREW
Fig. 315	N058319	RAIL
Fig. 800	429698-00	GREASE
Fig. 800	93488-00	GREASE
Fig. 856	5140050-83	LENGTH STOP
Fig. 856	DW3126	BLADE
Fig. 856	DW7084	STOP PLATE

mmToolParts
Big Time Experience. Small Town Service. .com