
DXGNR5700 Type 0 - Parts List

Use the figure number to match each part to the corresponding parts schematic.

DeWalt ServiceNet: DXGNR5700 Type 0 | Additional parts have no assigned figure



mmToolParts
Big Time Experience. Small Town Service. .com

DXGNR5700 Type 0 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DXGNR5700 Type 0 | Additional parts have no assigned figure

Fig. 1	5140174-89	FRAME RAIL
Fig. 2	5140243-91	PAN HEAD SCREW
Fig. 3	5140174-91	CURVED HEAD BOLT
Fig. 4	5140246-24	CONTROL PANEL ASSY
Fig. 5	5140174-93	OUTLET COVER
Fig. 6	5140174-94	NUT
Fig. 7	5140246-25	FACE PLATE
Fig. 8	5140174-96	IDLE SPEED CONTROL
Fig. 9	5140174-97	NUT
Fig. 10	5140174-98	RECEPTACLE
Fig. 11	5140174-99	NUT
Fig. 12	5140246-26	CIRCUIT BREAKER
Fig. 13	5140175-01	CIRCUIT BREAKER
Fig. 14	5140175-02	BACK COVER
Fig. 15	5140244-31	HOUR METER
Fig. 16	5140243-95	RECEPTACLE GFCI 120V
Fig. 17	5140175-05	IDLE SPEED SWITCH
Fig. 18	5140175-06	ON/OFF SWITCH
Fig. 19	5140175-08	OUTLET COVER
Fig. 20	5140175-09	NUT
Fig. 21	5140175-11	BOLT
Fig. 22	5140175-13	HANDLE PLUG
Fig. 23	5140175-14	HANDLE
Fig. 24	5140175-15	SNAP BUTTON
Fig. 25	5140175-16	HANDLE BRACKET
Fig. 26	5140175-17	BOLT
Fig. 27	5140175-18	CARRIAGE HEAD
Fig. 28	5140246-27	FRAME
Fig. 29	5140175-20	NUT

mmToolParts
Big Time Experience. Small Town Service. .com

DXGNR5700 Type 0 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DXGNR5700 Type 0 | Additional parts have no assigned figure

Fig. 30	5140243-97	NUT
Fig. 31	5140175-22	ISOLATOR
Fig. 32	5140244-34	FOOT
Fig. 33	5140244-35	SHOCK ABSORBER
Fig. 34	5140175-25	SOCKET HEAD CAP SCRE
Fig. 35	5140244-36	AXLE PIN
Fig. 36	5140244-37	BOLT
Fig. 37	5140244-38	WHEEL
Fig. 38	5140244-00	COTTER PIN
Fig. 39	5140175-30	FLAT WASHER
Fig. 40	5140175-33	BOLT
Fig. 41	5140175-34	LOCK WASHER
Fig. 42	5140175-35	NUT
Fig. 43	5140175-36	FLAT WASHER
Fig. 44	5140175-37	NUT
Fig. 45	5140175-38	GROUND WIRE ASSY
Fig. 46	5140175-39	BAFFLE
Fig. 47	5140246-28	ROTOR/STATOR ASSY.
Fig. 48	5140175-41	BRUSH ASSEMBLY
Fig. 49	5140175-42	WIRE-CONNECTION
Fig. 50	5140175-43	FLAT WASHER
Fig. 51	5140175-44	STATOR BOLT
Fig. 52	5140244-04	VOLTAGE REGULATOR
Fig. 53	5140175-46	END COVER
Fig. 54	5140175-47	BOLT
Fig. 55	5140175-48	BOLT
Fig. 56	5140175-49	ROTOR BOLT
Fig. 57	5140175-50	STATOR BOLT
Fig. 58	5140175-51	BEARING HOUSING

mmToolParts
Big Time Experience. Small Town Service. .com

DXGNR5700 Type 0 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DXGNR5700 Type 0 | Additional parts have no assigned figure

Fig. 59	5140244-07	RUBBER MOUNT
Fig. 60	5140244-08	INSERT
Fig. 61	5140244-09	BOLT
Fig. 62	5140244-10	FUEL FILTER
Fig. 63	5140246-29	FUEL CAP
Fig. 64	5140244-44	FUEL GAUGE
Fig. 65	5140244-12	SCREW
Fig. 66	5140246-30	FUEL TANK
Fig. 67	5140175-60	FUEL SHUT OFF VALVE
Fig. 68	5140175-61	ROLL OVER VALVE
Fig. 69	5140244-14	BACK RAIL
Fig. 70	5140175-63	BOLT
Fig. 71	5140175-64	GASKET
Fig. 72	5140175-65	MUFFLER
Fig. 74	5140175-67	BOLT
Fig. 75	5140244-16	HOSE
Fig. 76	5140175-69	HOSE CLAMP
Fig. 77	5140244-17	CLAMP
Fig. 78	5140175-71	HOSE
Fig. 79	5140175-72	CARBON CANISTER
Fig. 80	5140175-73	BRACKET
Fig. 81	5140175-74	LIMIT BOARD
Fig. 82	5140175-75	BRACKET
Fig. 83	5140175-76	BOLT
Fig. 84	5140175-77	FUEL HOSE
Fig. 85	5140175-78	FUEL FILTER
Fig. 86	5140175-79	FUEL HOSE
Fig. 87	5140175-80	HOSE CLAMP
Fig. 89	5140175-83	TWO HEADED BOLT

mmToolParts
Big Time Experience. Small Town Service. .com

DXGNR5700 Type 0 - Parts List

Use the figure number to match each part to the corresponding parts schematic.
DeWalt ServiceNet: DXGNR5700 Type 0 | Additional parts have no assigned figure

Fig. 90	5140175-84	COVER
Fig. 91	5140175-85	EXHAUST MANIFOLD
Fig. 92	5140175-86	NUT
Fig. 93	5140175-87	GASKET
Fig. 94	5140246-31	BRACKET
Fig. 95	5140175-89	ALTERNATOR SCROLL
Fig. 96	5140175-90	BOLT
Fig. 97	5140244-22	STRAP

mmToolParts
Big Time Experience. Small Town Service. .com