
JET EHB-1018VM | Stock 891070

Diagram A - Stand and Bed

Band Saw | Original JET parts reference



mmToolParts
Big Time Experience. Small Town Service. .com

JET EHB-1018VM | Stock 891070

Parts List A - Stand and Bed

Band Saw | Original JET parts reference

Ref.	Part number	Description	Size	Qty.
64	JT9-EHB916V-64	Fitting		2
65	JT9-EHB916V-65	Tubing		1
65-1	**	Tubing		1
66	JT9-EHB1018VM-66	Valve		1
67	JT9-EHB1018VM-67	Feed Knob		1
101	JT9-EHB916V-101	Cable Gland	M20	4
190	JT9-TS-0209071	Socket Head Cap Screw	3/8 × 1-1/2"	2
191	JT9-EHB1018VM-191	Rack block		1
192	JT9-EHB1018VM-192	Vise jaw Bracket		1
193	JT9-TS-0267041	Set Screw	1/4-20 × 3/8"	1
194	JT9-EHB1018VM-194	Rack block		1
195	JT1-1365	Acme Nut Assembly		1
196	JT9-EHB1018VM-196	Fixed Pin		1
197	**	Rack		1
198	JT9-TS-0208041	Hex Cap Screw	5/16-18 × 3/4"	2
199	CM9-EHB1018VM-199	Moveable Bed		1
200	JT9-EHB1018VM-200	Adjustable Handle		1
201	JT9-TS-0680041	Flat Washer	3/8"	1
202	JT9-EHB1018VM-202	Vise Jaw Bracket (fixed)		1
203	JT9-TS-0208071	Socket Head Cap Screw	5/16"-18 × 1-1/4"	4
204	JT9-TS-0060081	Hex Cap Screw	3/8-16 × 1-3/4"	1
205	JT9-TS-0561031	Hex Nut	3/8"	1
206	JT9-EHB916V-206	Limit Switch		1
207	**	Limit Switch Kit (Protection box, cable head, wire, Fix plate)		1
208	JT9-EHB1018VM-208	Limit Switch		1
208-1	**	Protection box with Cable Head		1
209	**	Bracket		1
209-1	**	Knob		1

mmToolParts
Big Time Experience. Small Town Service. .com

JET EHB-1018VM | Stock 891070

Parts List A - Stand and Bed (continued)

Band Saw | Original JET parts reference

Ref.	Part number	Description	Size	Qty.
209-2	JT9-EHB916V-191	Special Washer		1
209-3	**	Screw		1
209-4	JT9-TS-0561011	Nut		1
209-5	**	Block		1
209-6	**	Screw		2
209-7	**	Screw		2
209-8	JT9-EHB916V-225	Screw		3
209-9	**	Ring		1
	JT9-EHB1018VM-OHCA	Oil Hydraulic Cylinder Assembly (includes #210-219,222)		1
210	JT9-EHB916V-219	Cap		1
25-1	JT9-EHB1018VM-25-1	Air Flow Brass		1
211	JT9-EHB916V-211	Oil Seal	20.35.7	1
213	JT9-EHB1018VM-213	Rod		1
214	JT9-TS-0680031	Flat Washer	5/16"	1
215	JT9-EHB1018VM-215	Piston		1
216	JT9-EHB916V-216	Seal		1
217	JT9-EHB1018VM-217	O-Ring		1
218	JT9-TS-0561021	Hex Nut	5/16" x 18T	2
219	**	Tube Assembly		1
222	JT9-EHB916V-222	Tube Fitting		1
223	JT9-EHB916V-223	Retaining Ring	S-17	1
224	JT9-EHB1018VM-224	Pivot Shaft		1
225	JT9-EHB916V-225	Socket Set Screw	3/8"-16T × 3/8"	1
230	JT9-TS-0680031	Flat Washer	5/16"	4
231	JT9-TS-0051051	Hex Cap Screw	5/16 × 1"	4
232	JT1-2362	Motor Plate		1
233	JT9-EHB1018V-233	Rear Pivot Bracket		1
234	**	Socket Set Screw	1/2" x 2"	2

mmToolParts
Big Time Experience. Small Town Service. .com

JET EHB-1018VM | Stock 891070

Parts List A - Stand and Bed (continued)

Band Saw | Original JET parts reference

Ref.	Part number	Description	Size	Qty.
235	JT9-EHB916V-235	Hex Nut	1/2"-12	2
236	JT9-TS-0209081	Socket Head Cap Screw	3/8"-16T × 1-3/4"	3
237	JT9-TS-0680041	Flat Washer	3/8"	3
240	JT9-TS-0271051	Set Screw	3/8"-16 × 1/2"	1
241	JT9-EHB1018VM-241	Eccentric		1
242	JT9-TS-0051081	Hex Cap Screw	5/16 x 1-3/4"	1
243	JT9-TS-0680031	Flat Washer	5/16"	1
244	JT9-TS-0561021	Hex Nut	5/16 x 18T	1
245	JT9-TS-0561071	Hex Nut.	5/8"	1
247	JT9-EHB1018VM-247	Handle		1
248	JT9-EHB916V-248	Pin		1
249	JT9-EHB916V-249	Hand Wheel		1
249-1	JT9-EHB916V-249-1	Handle		1
250	JT9-EHB1018VM-250	Seat (1018VM only)		1
250-1	JT9-TS-0051051	Hex Cap Screw (1018VM only)	5/16"-18 × 1"	2
250-2	JT9-TS-0720081	Lock Washer (1018VM only)	5/16"	2
	**	Acme Screw Kit (including 252,252-1 and 253)		1
	**	Acme Screw Kit (including 252,252-1 and 253)		1
	**	Acme Screw(1018VMH only)(not shown)		1
252	JT9-EHB1018VM-252	Acme Screw(1018VM only)		1
252-1	JT9-EHB916V-252-1	Collar		1
253	JT9-EHB916V-253	Roll Pin	6 ø ×30 ø	1
254	JT9-EHB1018VM-254	Locking screw		1
255	JT9-EHB1018VM-255	Special Washer		1
256	JT9-EHB1018VM-256	Locking pieces		1
257	JT9-TS-0680061	Flat Washer	1/2"	1
258	JT9-JWS25-202	Hex Nut.	1/2"-12	2
259	JT9-TS-0267121	Socket Set Screw	1/4 x 3/4"	1

mmToolParts
Big Time Experience. Small Town Service. .com

JET EHB-1018VM | Stock 891070

Parts List A - Stand and Bed (continued)

Band Saw | Original JET parts reference

Ref.	Part number	Description	Size	Qty.
260	JT9-EHB1018VM-260	Table		1
261	JT9-TS-0208061	Socket Head Cap Screw	5/16" × 1"	4
262	JT9-EHB1018VM-262	Block		1
263	JT9-EHB1018VM-263	Swiveling Seat		1
263-1	JT9-HB1018VM-263-1	Support Seat		1
263-2	JT9-TS-0070161	Hex Cap Screw	1/2 x 5-1/2	1
263-3	JT9-TS-0640111	Hex Nut	1/2"	1
263-4	JT9-TS-0060071	Hex Cap Screw	3/8 x 1-1/2	1
263-5	JT9-TS-0570031	Hex Nut.	3/8"-16	1
264	JT9-TS-0050031	Hex Cap Screw	1/4" × 3/4"	2
265	JT9-EHB916V-265	Collar		2
266	JT9-TS-0271031	Socket Set Screw	3/8-16T ×3/8"	4
267	JT9-EHB916V-267	Copper		2
268	JT9-TS-0271031	Socket Set Screw	3/8-16T ×3/8"	2
269	JT9-EHB916V-269	Pivot Shaft		1
270	JT9-EHB1018VM-270	Spindle		1
271	JT9-EHB1018VM-271	Base Assembly		1
272-1	JT9-HB1018VM-271-1	Base Lid		1
272-2	JT9-HB1018VM-271-2	Base Lid		1
272-3	**	Door		1
272-4	**	Wiring box		1
272	JT9-EHB1018VM-272	Sliding Surface		1
273	JT9-TS-0267071	Socket Set Screw	1/4-20 × 3/4"	6
274	JT9-TS-0208061	Socket Head Cap Screw	5/16"-18 × 1"	3
276	JT9-EHB1018VM-276	Seat		1
277	JT9-EHB1018VM-277	Movable Pin		1
278	JT9-EHB916V-278	Gun Set		1
278-1	JT9-EHB916V-278-1	Hook		1

mmToolParts
Big Time Experience. Small Town Service. .com

JET EHB-1018VM | Stock 891070

Parts List A - Stand and Bed (continued)

Band Saw | Original JET parts reference

Ref.	Part number	Description	Size	Qty.
278-2	JT9-EHB916V-278-2	Hex Cap Screw		2
279	JT9-TS-0051051	Hex Cap Screw	5/16"-18 × 1"	2
280	JT9-JWS25-202	Hex Nut	1/2"-12T	4
281	**	Coolant Tank		1
281-1	JT9-HB1018VM-281-1	Coolant Pump	1/8Hp 230/460V 3Ph	1
281-2	JT9-EHB916V-281-2	Pan Head Machine Screw		4
281-3	JT9-EHB916V-96	3 Way Coolant Block		1
281-4	JT9-EHB916V-281-4	Lock W/Key		1
281-5	**	Lock W/o Key		2
282	JT9-EHB1018VM-282	Bracket		1
283	JT9-TS-0070051	Hex Cap Screw	1/2"-12 × 2"	4
284	JT9-TS-0208071	Socket Head Cap Screw	5/16' x 1-1/4"	8
285	JT9-TS-0267071	Set Screw	1/4"-20 × 3/4"	8
286	JT9-EHB1018VM-286	Strap		1
287	JT9-EHB916V-26	Special Washer		1
288	JT9-TS-0680021	Flat Washer	1/4"	2
289	JT9-TS-0050031	Hex Cap Screw	1/4"-20 × 3/4"	2
290	JT9-EHB916V-245	Knob		1
	JT9-EHB1018VM-SA	Adj. Stock Stop Assembly (includes #291-294,#297)		
291	JT9-EHB1018V-258	Shaft	7/8”	1
292	**	Stop Bracket		1
293	JT9-EHB1018V-260	Bar		1
294	**	Knob		2
295	**	Arch Seat		1
296	JT9-EHB1018VM-296	Support Block		1
296-1	JT9-HB1018VM-296-1	Socket Head Cap Screw		2
296-2	JT9-HB1018VM-296-2	Screw w/Nut		1
297	**	Knob		1

mmToolParts
Big Time Experience. Small Town Service. .com

JET EHB-1018VM | Stock 891070

Parts List A - Stand and Bed (continued)

Band Saw | Original JET parts reference

Ref.	Part number	Description	Size	Qty.
298	JT9-EHB1018VM-298	Scale		1
299	JT9-EHB1018VM-299	Indicator		1
300	JT9-EHB1018VM-300	Nameplate		1
301	JT9-EHB1018VM-301	Start Switch		1
301-1	JT9-HB1018VM-301-1	Raise/Lower/Vise Clamp/Vise Unclamp Switch		4
302	JT9-EHB1018VM-302	Stop Switch		1
303	JT9-EHB1018VM-303	Selection Switch	coolant pump	1
304	JT9-EHB1018VM-304	Emergency Switch		1
305	JT9-EHB916V-305	Indication Light For Power		1
306	JT9-EHB1018VM-306	Control Box		1
306-1	JT9-HB1018VM-306-1	Tube		1
307	JT9-EHB1018VM-307	Screw	3/16" x 3/8"	9
308	**	Selection Switch	manual/auto	1
311	JT9-EHB1018VM-311	Acme Leadscrew Seat		1
312	JT9-TS-0680031	Flat Washer	5/16"	2
313	JT9-TS-0208061	Socket Head Cap Screw	5/16-18 × 1"	2
314	JT9-EHB1018VM-314	Fixing Rod for Spring		1
315	**	Socket Head Cap Screw	1/2" × 1-1/2"	1
316	JT9-EHB1018VM-316	Spring		1
317	JT9-EHB1018VM-317	Spring Cover		1
318	JT9-EHB1018VM-318	Bracket		1
319	JT9-EHB1018VM-319	Spindle		1
319-1	JT9-HB1018VM-319-1	Open Pin	1/8” x1”	2
321	JT9-EHB1018VM-321	Hydraulic Motor	1/4Hp 230/460V 3Ph	1
325	JT9-EHB1018VM-325	Hydraulic Pump		1
326	JT9-EHB1018VM-326	Oil Box		1
	JT9-EHB1018VM-129	Sight Glass (not shown)		1
327	JT9-EHB1018VM-327	Solenoid Valve		1


** These parts are shown for reference only and are not available for order individually. Non-proprietary parts, such as fasteners, can usually be found at local hardware stores.

mmToolParts
Big Time Experience. Small Town Service. .com

JET EHB-1018VM | Stock 891070

Diagram B - Saw Arm

Band Saw | Original JET parts reference



mmToolParts
Big Time Experience. Small Town Service. .com

JET EHB-1018VM | Stock 891070

Parts List B - Saw Arm

Band Saw | Original JET parts reference

Ref.	Part number	Description	Size	Qty.
1	**	Handwheel		1
1-1	JT9-EHB916V-01-1	Handwheel handle		2
2	JT9-EHB916V-20	Lock Nut		1
3	JT9-EHB916V-03	Shaft		1
4	JT9-EHB916V-04	Bracket		1
5	JT9-EHB916V-05	Slide		1
6	JT9-EHB916V-06	Gib		2
7	JT9-EHB916V-07	Collar		1
8	JT9-EHB916V-08	Roll pin	5x30	2
8-1	JT9-EHB916V-08-1	Roll pin	5x40	1
9	JT9-TS-0208041	Hex Cap Screw	5/16 x 3/4	4
10	JT9-EHB916V-10	Adjusting Screw	3/4 x 1-1/2	1
11	JT9-TS-0060111	Hex Cap Screw	3/8 x 2-1/2	1
12	JT9-TS-0271031	Set Screw	3/8" x 3/8	1
13	JT9-EHB916V-13	Spindle		1
14	JT9-BB-51103	Thrust bearing	BB51103	2
15	JT9-TS-0060061	Hex Cap Screw	3/8 x 1-1/4	1
16	JT9-EHB916V-16	Roll Pin	5 x 30	2
17	JT9-TS-0732061	Lock Washer	3/8"	1
18	JT9-EHB916V-18	Driven		1
19	JT9-EHB916V-19	Thrust Bearing Housing		1
20	JT9-EHB916V-02	Collar		1
21	JT9-EHB916V-21	Disc Spring		6
22	JT9-EHB916V-22	Copper		1
23	JT9-TS-0267041	Set Screw	1/4 x 3/8	1
24	JT9-TS-0720081	Lock Washer	5/16"	1

mmToolParts
Big Time Experience. Small Town Service. .com

JET EHB-1018VM | Stock 891070

Parts List B - Saw Arm (continued)

Band Saw | Original JET parts reference

Ref.	Part number	Description	Size	Qty.
25	JT9-TS-0060051	Hex Cap Screw	3/8" x 1"	1
26	JT9-EHB916V-26	Special Washer		1
28	JT9-EHB916V-28	Wheel L.H.		1
29	**	Bearing	BB6306ZZ	2
31	**	Output Shaft		1
32	JT9-EHB916V-32	Oil Seal	32.42.7	1
33	JT9-BB-30207	Bearing		1
34	JT9-EHB916V-34	Oil Plug	1/4"	2
35	JT9-EHB916V-35	Gear Box Housing		1
35-1	JT9-EHB916V-35-1	Cover		1
	**	Gear Box Cover Assembly (includes 35, 35-1)		
36	JT9-TS-0060081	Hex Cap Screw	3/8-16 × 3/4"	3
37	JT9-TS-0732061	Lock Washer	3/8"	3
38	JT9-EHB916V-38	Worm Gear		1
39	JT9-EHB916V-39	Key	7 x 7 x 35	1
40	JT9-BB-30206	Bearing		1
41	JT9-TS-0267121	Set Screw	1/4" × 3/4"	3
42	JT9-EHB916V-42	Cap		1
43	JT9-TS-0732061	Lock Washer	3/8"	3
44	JT9-TS-0060071	Hex Cap Screw	3/8"-16 × 1-1/2"	3
45	JT9-TS-0207021	Socket Head Cap Screw	1/4"-20 × 5/8"	3
46	JT9-TS-0561011	Hex Nut	1/4”	3
47	JT9-EHB916V-47	Cap		1
48	JT9-SB-3/16	Steel Ball	3/16”	2
49	JT9-TS-0270061	Set Screw	5/16"-18 × 5/8"	2
50	JT9-TS-0207021	Socket Head Cap Screw	1/4"-20 × 5/8"	4

mmToolParts
Big Time Experience. Small Town Service. .com

JET EHB-1018VM | Stock 891070

Parts List B - Saw Arm (continued)

Band Saw | Original JET parts reference

Ref.	Part number	Description	Size	Qty.
51	JT9-BB-6004	Bearing	BB6004	1
52	JT9-EHB916V-52	Input Shaft		1
55	JT9-BB-5205	Bearing	3205	1
56	JT9-EHB916V-56	Oil Seal	25.35.7	1
57	JT9-EHB916V-57	Cap		1
58	JT9-TS-0207021	Socket Head Cap Screw	1/4"-20 × 5/8"	4
68	JT9-EHB-1018VM-68	Bow Frame		1
68-1	JT9-EHB916V-68-1	Frame Handle		1
70	JT9-TS-0208041	Hex Cap Screw	5/16" x 3/4"	2
71	JT9-TS-0680031	Flat Washer	5/16"	2
73	JT9-EHB916V-73	Tube Retainer		2
74	JT9-EHB916V-74	Round Head Screw	3/16" x 3/8"	2
76	JT9-TS-0680031	Flat Washer	5/16"	2
77	JT9-TS-0208041	Hex Cap Screw	5/16" x 3/4"	2
78	JT9-TS-0208041	Hex Cap Screw	5/16" x 3/4"	2
79	JT9-TS-0680031	Flat Washer	5/16"	2
80	JT9-EHB916V-80	Drive Wheel.		1
81	JT9-TS-0271032	Socket Set Screw	3/8-24 ×3/8"	1
82	JT9-EHB916V-82	Key	7 x 7 x 40	1
83	JT9-TS-0208041	Hex Cap Screw	5/16-18 ×3/4"	2
84	JT9-TS-0720081	Lock Washer	5/16"	2
86	JT9-EHB916V-86	Sensor		1
86-1	JT9-EHB916V-86-1	Sensor seat		1
86-2	JT9-EHB916V-86-2	Screw		2
87	JT9-EHB916V-75	Bracket		1
88	JT9-EHB916V-88	Knob		2

mmToolParts
Big Time Experience. Small Town Service. .com

JET EHB-1018VM | Stock 891070

Parts List B - Saw Arm (continued)

Band Saw | Original JET parts reference

Ref.	Part number	Description	Size	Qty.
89	JT9-EHB916V-88	Knob		1
90	JT9-EHB916V-90	Blade Tension Gauge		1
BTA	CM9-EHB916-BTA	Blade Tension Assembly(includes 1~24, 48~49,90~90-1)		1
90-1	JT9-EHB916V-90-1	Pin		1
91	JT9-EHB1018V-91	Front Pivot Bracket		1
92	JT9-TS-0732061	Lock Washer	3/8"	3
93	JT9-TS-0060081	Hex Cap Screw	3/8-16 ×3/4"	3
94	JT9-TS-0271051	Socket Set Screw	3/8-16 ×1/2"	1
95	JT9-EHB-1018VM-95	Motor	2Hp,230/460V	1
96	JT9-EHB916V-96	3 Way Coolant Block		1
97	JT1-1056	Hose Kit	260cm/155cm/75cm	1
98	JT9-EHB916V-98	Valve		2
99	JT1-1057	Hose Clamp		2
100	JT9-EHB-1018VM-100	Belt (for 1018VM/1018VMH)		1
101	JT9-EHB916V-101	Cable Glands (not show)	PG-11	5
102	**	Pulley Fixed Plate		1
103	JT9-EHB916V-103	Upper Guard		1
104	JT9-TS-0680021	Flat Washer	1/4"x19x2.0	3
105	JT9-TS-0207031	Socket Head Cap Screw	1/4"x20x5/8"	3
109	JT9-EHB916V-109	Lower Guard		1
109-1	JT9-TS-0680021	Flat Washer	1/4"x19x2.0	2
109-2	JT9-TS-0207031	Socket Head Cap Screw	1/4"x20x5/8"	2
110	JT9-EHB916V-110	Motor Pulley		1
111	JT9-TS-0270021	Socket Set Screw	5/16-18 ×5/16"	1
112	JT9-EHB916V-112	Pulley		1
113	JT9-TS-0270021	Socket Set Screw	5/16-18 ×5/16"	1

mmToolParts
Big Time Experience. Small Town Service. .com

JET EHB-1018VM | Stock 891070

Parts List B - Saw Arm (continued)

Band Saw | Original JET parts reference

Ref.	Part number	Description	Size	Qty.
114	JT9-EHB916V-114	Key	5 x 5 x 40	1
121	JT9-EHB916V-121	Round Head Screw	10-3/16 ×3/8"	4
122	JT9-EHB-1018VM-122	Cover R.H.		1
123	JT9-TS-0680041	Lock Washer	3/8"	4
126	JT9-TS-0680041	Lock Washer	3/8"	3
127	JT9-TS-0060081	Hex Cap Screw	3/8 ×16 ×3/4"	3
128	JT9-EH-B1018V-128	Stationary plate		2
129	JT9-EH-B1018V-129	Bracket		1
130	JT9-TS-0209061	Socket Head Cap Screw	3/8"-16 ×1-1/4"	2
131	JT9-TS-0267071	Set Screw	1/4"-20 ×3/4"	4
132	JT9-TS-0270061	Set Screw	5/16"-18 ×5/8"	1
133	JT9-EH-B1018V-133	Bracket-R.H.		4
134	JT9-EHB-1018VM-134	Slide		1
134-1	JT1-411	Scale		1
135	JT9-EHB916V-135	Screw	3/16"-24 × 7/8"	4
136	JT9-EHB916V-136	Carbide Guide		4
137	JT9-EH-B1018V-137	Collar		2
138	JT9-TS-0267021	Set Screw	1/4"×1/4"	2
139	JT9-EHB916V-139	Wire Brush		1
140	JT9-EH-B1018V-140	Bracket		1
141	JT9-TS-0207021	Socket Head Cap Screw	1/4"-20 × 5/8"	2
142	JT9-TS-0680021	Flat Washer	1/4" x 19 x 2.0	2
143	**	Spring Washer	5/16"	2
143-1	**	Hex. Nut	1/2"	2
144	JT9-EHB916V-144	Guide, Right		1
144-1	JT9-EH-B916V-144-1	Guide, Left		1

mmToolParts
Big Time Experience. Small Town Service. .com

JET EHB-1018VM | Stock 891070

Parts List B - Saw Arm (continued)

Band Saw | Original JET parts reference

Ref.	Part number	Description	Size	Qty.
145	JT9-TS-0561021	Hex Nut	5/16"-18T	2
146	JT9-5051911	Flat Washer	M10	6
147	**	Bearing	6200 ZZ	1
148	JT9-EHB916V-148	Special Screw	M10 x 30	2
149	**	Bearing	6200 ZZ	2
150	JT9-EHB916V-150	Special Screw		2
151	JT9-EHB916V-151	Special Screw		2
152	**	Flat Washer	5/16"	2
153	JT9-EHB916V-153	Adjustable Handle		1
154	JT9-EHB916V-154	Guide Cover		1
154-1	JT9-EH-B916V-154-1	Screw	3/16” x 3/8”	2
154-2	JT9-6860800	Washer		2
155	JT9-EH-B1018V-155	Bracket-L.H.		4
156	JT9-EHB916V-156	Bladecover		1
156-1	JT9-EH-B916V-156-1	Screw		2
156-2	JT9-6860800	Washer		2
157	JT9-EHB916V-157	Blade cover		1
158	JT9-EHB916V-158	Special Knob		2
159	JT9-TS-0680041	Flat Washer	3/8"	1
160	JT9-TS-0060031	Hex Head Screw	3/8 x 16 x 3/4”	3
161	JT9-EH-B1018V-161	Bracket		1
165	JT9-EHB916V-165	Round Head Screw	3/16 ×3/8"	4
166	JT9-EHB916V-166	Cover L.H.		1
167	JT9-EHB916V-167	Handle		2
168	JT9-TS-081F051	Phillips Screw	1/4”-20 × 3/4”	4
169	JT9-891097	Blade	1 “x0.035”x 144” (4/6T)	1


** These parts are shown for reference only and are not available for order individually. Non-proprietary parts, such as fasteners, can usually be found at local hardware stores.

mmToolParts
Big Time Experience. Small Town Service. .com

JET EHB-1018VM | Stock 891070

Diagram C - Electrical Box

Band Saw | Original JET parts reference



mmToolParts
Big Time Experience. Small Town Service. .com

JET EHB-1018VM | Stock 891070

Parts List C - Electrical Box

Band Saw | Original JET parts reference

Ref.	Part number	Description	Size	Qty.
308-1	JT9-HB1018VM-308-1	Transformer	230/460/12/24/110V	1
308-2	JT9-HB1018VM-308-2	Fuse Blocks	32A 600V	1
308-2-1	JT9-1018VM-308-2-1	Fuse (240V)	5A	1
	JT9-HB916V-308-2-1	Fuse (460V)	3A	1
308-3	JT9-HB1018VM-308-3	Relay	250V 10A	1
308-4	JT9-HB1018VM-308-4	Relay Socket		1
308-5	JT9-HB1018VM-308-5	Terminal Block		9
308-6	JT9-HB1018VM-308-6	Electrical Plate		1
308-7	JT9-HB1018VM-308-7	Round Head Screw	3/16” x 3/8”	54
308-8	JT9-6860800	Washer	3/16”	54
308-9	JT9-HB1018VM-308-9	Power Cable		1
308-10	JT9-B1018VM-308-10	Control Wire		1
308-11	JT9-B1018VM-308-11	Ground Cable	Yellow/Green	1
308-12	JT9-B1018VM-308-12	Overload Relay (4.5-6.5A) (240V)	RHU-10K1	1
	**	Overload Relay (2.9-4A) (460V)	RHU-10/4K1	1
308-13	JT9-B1018VM-308-13	Magnetic Contactor	CU-11 110V	3
308-15	**	Motor Cable		1
308-16	**	Pump Cable		1
308-17	**	Hydraulic Cable		1
308-18	**	Limit Switch Cable		1
308-19	**	Limit Switch Cable		1

** These parts are shown for reference only and are not available for order individually. Non-proprietary parts, such as fasteners, can usually be found at local hardware stores.

mmToolParts
Big Time Experience. Small Town Service. .com