
JET ESN-40 | Stock 754420

Diagram A - Pipe Notcher

Exploded diagrams and replacement parts



mmToolParts
Big Time Experience. Small Town Service. .com

JET ESN-40 | Stock 754420

Parts List A - Pipe Notcher

Exploded diagrams and replacement parts

Ref.	Part number	Description	Size	Qty.
1	ESN40-01	Stand I		1
2	TS-1540081	Hex Nut	M12	6
3	TS-2360121	Flat Washer	12mm	12
4	ESN40-04	Switch Plate		1
5	TS-1505021	Socket Head Cap Screw	M10x20	5
6	TS-1505061	Socket Head Cap Screw	M10x40	5
7	TS-1505051	Socket Head Cap Screw	M10x35	5
8	ESN40-08	Pin		2
9	ESN40-09	Pin		2
10	ESN40-10	Cover		1
11	ESN40-11	Joint plate I		1
12	ESN40-12	Body III		1
13	ESN40-13	Eccentric shaft		1
14	ESN40-14	Body I		1
15	TS-1492061	Hex Cap Screw	M12x60	2
16	ESN40-16	Blade I		1
17	ESN40-17	Reduction Box		1
18	ESN40-18	Switch	KJD12, 230V	1
19	ESN40-19	Blade III		1
20	ESN40-20	Body II		1

mmToolParts
Big Time Experience. Small Town Service. .com

JET ESN-40 | Stock 754420

Parts List A - Pipe Notcher (continued)

Exploded diagrams and replacement parts

Ref.	Part number	Description	Size	Qty.
21	ESN40-21	Blade II	2x20 mm	1
22	ESN40-22	Spring		1
23	ESN40-23	Spring		2
24	ESN40-24	Power Cord	14AWG	1
25	TS-1491081	Hex Cap Screw	M10x50	4
26	ESN40-26	Key	10x50 mm	1
27	ESN40-27	Support for Switch		1
28	TS-1504011	Socket Head Cap Screw	M8x10	2
29	ESN40-29	Box for Magnetic Switch		1
30	F011287	Phillips Pan Hd Tapping Screw	#8x1/2 (ST4.2x13)	2
31	ESN40-31	Thermal Overload Protector		1
32	ESN40-32	Cord Clamp		2
33	ESN40-33	Motor	2HP 230V 1PH	1
33-1	ESN40-33-1	Key (not shown)	8x35 mm	1
	ESN40-33-2	Motor Fan Cover (not shown)		1
	ESN40-33-3	Motor Fan (not shown)		1
34	TS-1491031	Hex Cap Screw	M10x25	4
35	ESN40-35	Junction Box		1
36	TS-2284082	Phillips Pan Head Machine Screw	M4x8	4
37-1	ESN40-37-1	Starting Capacitor	250V 200µf	1
37-2	ESN40-37-2	Running Capacitor	450V 30µf	1

mmToolParts
Big Time Experience. Small Town Service. .com

JET ESN-40 | Stock 754420

Parts List A - Pipe Notcher (continued)

Exploded diagrams and replacement parts

Ref.	Part number	Description	Size	Qty.
38	ESN40-38	Junction Box Cover		1
39	ESN40-39	Self-Tapping Screw	ST4.2x20	4
40	ESN40-40	Oil Fill Plug		1
41	ESN40-41	Lifting Ring		1
42	TS-1503041	Socket Head Cap Screw	M6x16	2
43	TS-2361061	Lock Washer	6 mm	10
44	TS-2361011	Lock Washer	12 mm	6
45	TS-2311121	Hex Nut	M12	1
46	F002101	Lock Washer, Int. Tooth	12 mm	1
47	ESN40-47	Drain Plug Screw		1
48	TS-1534032	Machine Screw, Pan Head, Phillips	M6x10	6
49	TS-2361101	Lock Washer	10 mm	4
50	TS-1534052	Machine Screw, Pan Head, Phillips	M6x16	2
51	ESN40-51	Wire		1
52	ESN40-52	Guard		1
53	ESN40-53	Junction plate		1
54	TS-2284082	Machine Screw, Pan Head, Phillips	M4x8	4
	LM000218	ID Label, ESN-40 (not shown)		1
	LM000219	Warning Label (not shown)		1
	LM000230	Label - hole size (not shown)		1
	JET-92	JET Logo (not shown)	92x38mm	1

mmToolParts
Big Time Experience. Small Town Service. .com