
JET EVTBS16V-230 | Stock 891200

Diagram A - Cabinet

Band Saw | Original JET parts reference



mmToolParts
Big Time Experience. Small Town Service. .com

JET EVTBS16V-230 | Stock 891200

Parts List A - Cabinet

Band Saw | Original JET parts reference

Ref.	Part number	Description	Size	Qty.
1	EVTBS16V-A1	Base Frame-Table Top		1
2	EVTBS16V-A2	Rod-Carriage Way		2
3	TS-1525031	Set Screw	M10 x 16L	12
4	TS-1541031	Nylon Lock Hex Nut	M8, Nylon Insert	1
5	TS-1504101	Socket Hd Cap Screw	M8 x 50L	1
6	TS-1504041	Socket Hd Cap Screw	M8 x 20L	1
7	EVTBS16V-A7	Block-Limit Switch		2
8	TS-1540041	Hex Nut	M5	1
9	TS-1522041	Set Screw	M5 x 12L	1
10	EVTBS16V-A10	Locking Handle	M8 x 25L	1
11	TS-1503011	Socket Hd Cap Screw	M6 x 8L	1
12	EVTBS16V-A12	Bent Rod-Limit Switch		1
13	EVTBS16V-A13	Rod-Limit Switch		1
14	EVTBS16V-A14	Mounted Ball Bearings	Shaft Dia. 15 mm	2
15	TS-2361081	Lock Washer	M8	4
16	TS-1504031	Socket Hd Cap Screw	M8 x 16L	4
17	TS-1513011	Socket Head Flat Screw	M5 x 10L	3
18	EVTBS16V-A18	Cover - Cables and Tubes		1
19	TS-1504031	Socket Hd Cap Screw	M8 x 16L	6
20	TS-2361081	Lock Washer	M8	6
21	TS-1503011	Socket Hd Cap Screw	M6 x 8L	2
22	TS-2361061	Lock Washer	M6	2
23	EVTBS16V-A23	Guard-Front Sprocket	RS40 10T	1
24	TS-1513011	Socket Head Flat Screw	M5 x 10L	4
25	EVTBS16V-A25	Drip Cover		1

mmToolParts
Big Time Experience. Small Town Service. .com

JET EVTBS16V-230 | Stock 891200

Parts List A - Cabinet (continued)

Band Saw | Original JET parts reference

Ref.	Part number	Description	Size	Qty.
26	EVTBS16V-A26	Machine Base Weldment-Front		1
27	EVTBS16V-A27	Hook		1
28	TS-2361061	Lock Washer	M6	2
29	TS-1503011	Socket Hd Cap Screw	M6 x 8L	2
30	EVTBS16V-A30	Nozzle, Coolant Spray		1
31	EVTBS16V-A31	Nozzle Joint		1
32	TS-1541021	Nylon Lock Hex Nut	M6, Nylon Insert	4
33	TS-1550041	Flat Washer	M6	8
34	TS-1482041	Hex Cap Screw	M6 x 20L	4
35	F008871	Hex Cap Screw	M12 x 20L	8
36	TS-2360121	Flat Washer	M12	8
37	TS-2211451	Hex Cap Screw	M12 x 45L	4
38	TS-1540081	Hex Nut	M12	4
39	EVTBS16V-A39	Stand Weldment		2
40	EVTBS16V-A40	Coolant Tank		1
41	EVTBS16V-A41	Splash Guard		2
42	EVTBS16V-A42	Plug	3/8" NPT	1
43	EVTBS16V-A43	Chip Tray		1
44	EVTBS16V-A44	Fitting	For Hose ID 3/8", 1/4" NPT	3
45	EVTBS16V-A45	Tee Connector	1/4" NPT Female	1
46	EVTBS16V-A46	Hose	ID 3/8"	1
47	EVTBS16V-A47	Fitting	For Hose ID 3/8", 3/8" NPT	1
48	EVTBS16V-A48	Coolant Pump	32W	1
49	TS-1550041	Flat Washer	M6	2
50	TS-1503061	Socket Hd Cap Screw	M6 x 25L	2

mmToolParts
Big Time Experience. Small Town Service. .com

JET EVTBS16V-230 | Stock 891200

Parts List A - Cabinet (continued)

Band Saw | Original JET parts reference


Ref.	Part number	Description	Size	Qty.
51	TS-1513011	Socket Head Flat Screw	M5 x 10L	2
52	EVTBS16V-A52	Pump Splash Guard		1
53	EVTBS16V-A53	Cover-Coolant Tank		1
54	TS-1513011	Socket Head Flat Screw	M5 x 10L	4
55	EVTBS16V-A55	Drip Cover		1
56	F006045	C-Retaining Ring, Ext	S17	6
57	EVTBS16V-A57	Shaft	For Sprocket RS40 T17	3
58	TS-1503011	Socket Hd Cap Screw	M6 x 8L	2
59	TS-2361061	Lock Washer	M6	2
60	EVTBS16V-A60	Guard-Rear Sprocket	RS40 17T	1
61	EVTBS16V-A61	Machine Base Weldment-Rear		1
62	TS-2361081	Lock Washer	M8	6
63	TS-1504031	Socket Hd Cap Screw	M8 x 16L	6
64	EVTBS16V-A64	Guard-Air Cylinder		1
65	TS-1513011	Socket Head Flat Screw	M5 x 10L	8
66	EVTBS16V-A66	Filter	1/4" Tube Fitting	1
67	EVTBS16V-A67	Tube Fitting	For Tube OD 8 mm, 1/4" NPT	2
68	TS-1513011	Socket Head Flat Screw	M5 x 10L	2
69	EVTBS16V-A69	Outlet Box		1
70	TS-1513011	Socket Head Flat Screw	M5 x 10L	2
71	EVTBS16V-A71	Outlet Box Cover		1
72	TS-1513011	Socket Head Flat Screw	M5 x 10L	4
73	EVTBS16V-A73	Nylon Nut	M6, Nylon Insert	4
74	TS-1550041	Flat Washer	M6	8
75	TS-1482041	Hex Cap Screw	M6 x 20L	4

mmToolParts
Big Time Experience. Small Town Service. .com

JET EVTBS16V-230 | Stock 891200

Diagram B - Turning Bracket

Band Saw | Original JET parts reference



mmToolParts
Big Time Experience. Small Town Service. .com

JET EVTBS16V-230 | Stock 891200

Parts List B - Turning Bracket

Band Saw | Original JET parts reference

Ref.	Part number	Description	Size	Qty.
1	EVTBS16V-B1	Carriage Weldment		1
2	TS-2311101	Hex Nut	M10	2
3	EVTBS16V-B3	Carriage Bumper		2
4	TS-1491031	Hex Cap Screw	M10 x 25L	3
5	TS-2361101	Lock Washer	M10	3
6	EVTBS16V-B6	Bolt, Bow Pivot		1
7	TS-2246101	Socket Head Flat Screw	M6 x 16L	4
8	TS-1504041	Socket Hd Cap Screw	M8 x 20L	2
9	TS-2361081	Lock Washer	M8	2
10	EVTBS16V-B10	Positioning Plate-Bow Pivot		1
11	EVTBS16V-B11	Grease Fitting	1/4"-28	1
12	TS-2228161	Hex Cap Screw	M8 x 16L	2
13	TS-2361081	Lock Washer	M8	2
14	TS-1550061	Flat Washer	M8(Dia. 25 mm)	2
15	BB-6203ZZ	Ball Bearing	6203ZZ	2
16	EVTBS16V-B16	Shaft-Bearing Mount		2
17	EVTBS16V-B17	Carriage Stop Bracket		1
18	TS-2361081	Lock Washer	M8	2
19	TS-1504051	Socket Hd Cap Screw	M8 x 25L	2
20	TS-1504041	Socket Hd Cap Screw	M8 x 20L	1
21	TS-2361081	Lock Washer	M8	1
22	TS-1550061	Flat Washer	M8(Dia. 25 mm)	1
23	BB-6002ZZ	Ball Bearing	6002ZZ	1
24	EVTBS16V-B24	Eccentric Shaft		1
25	EVTBS16V-B25	Bracket-Rear Carriage		1
26	TS-2361121	Lock Washer	M12	1
27	TS-1540081	Hex Nut	M12	1
28	TS-1504061	Socket Hd Cap Screw	M8 x 30L	4

mmToolParts
Big Time Experience. Small Town Service. .com

JET EVTBS16V-230 | Stock 891200

Parts List B - Turning Bracket (continued)

Band Saw | Original JET parts reference


Ref.	Part number	Description	Size	Qty.
29	TS-2361081	Lock Washer	M8	4
30	TS-1524021	Set Screw	M8 x 10L	8
31	TS-1526021	Set Screw	M12 x 16L	2
32	TS-2311101	Hex Nut	M10(P1.25)	1
33	TS-149105	Hex Cap Screw	M10 x 35L(P1.25)	1
34	EVTBS16V-B34	Yoke-Extension Spring		2
35	EVTBS16V-B35	Extension Spring		2
36	TS-1492091	Hex Cap Screw	M12 x 90L	1
37	EVTBS16V-B37	Shaft-Lower Yoke		1
38	EVTBS16V-B38	Bracket-Extension Spring		1
39	TS-1550061	Flat Washer	M8(Dia. 30 mm)	1
40	TS-1504031	Socket Hd Cap Screw	M8 x 16L	1
41	F006036	C-Retaining Ring, Int	R45	4
42	EVTBS16V-B42	Linear Bearing	LM30UU	2
43	EVTBS16V-B43	Bracket-Linear Bearing		2
44	EVTBS16V-B44	Handle-Handwheels		1
45	EVTBS16V-B45	Handwheel		1
46	TS-1524021	Set Screw	M8 x 10L	1
47	KF2R5515	Key, Dbl Rd Hd	5x5x15L	2
48	EVTBS16V-B48	Shaft	For Sprocket RS40 T10	1
49	TS-1522041	Set Screw	M5 x 12L	1
50	EVTBS16V-B50	Sprocket	RS40 T10	1
51	EVTBS16V-B51	Sprocket	RS40 T17	3
52	BB-6003ZZ	Ball Bearing	6003ZZ	3
53	F006054	C-Retaining Ring, Ext	R35	3
54	EVTBS16V-B54	Chain	RS40 x 225 Pitch	1
55	EVTBS16V-B55	Chain	RS40 x 49 Pitch	1
56	EVTBS16V-B56	Bracket-Feed Chain		2
57	TS-2311101	Hex Nut	M10(P1.25)	1

mmToolParts
Big Time Experience. Small Town Service. .com

JET EVTBS16V-230 | Stock 891200

Diagram C - Air Cylinder

Band Saw | Original JET parts reference



mmToolParts
Big Time Experience. Small Town Service. .com

JET EVTBS16V-230 | Stock 891200

Parts List C - Air Cylinder

Band Saw | Original JET parts reference


Ref.	Part number	Description	Size	Qty.
1	EVTBS16V-C1	U-Bolts	1-1/4 x 1/4"	2
2	TS-2228161	Hex Cap Screw	M8 x 16L	4
3	TS-2361081	Lock Washer	M8	4
4	EVTBS16V-C4	Air Cylinder		1
5	EVTBS16V-C5	Channel Weldment		1
6	TS-0561011	Hex Nut	1/4"-20	4
7	TS-1550041	Flat Washer	M6	4
8	TS-1550041	Flat Washer	M6	2
9	TS-0561011	Hex Nut	1/4"-20	4
10	EVTBS16V-C10	Tube Fitting(90° Elbow)	For Tube OD 8 mm, 1/8" NPT	2
11	EVTBS16V-C11	Cover-Air Cylinder		1
12	TS-1513011	Socket Head Flat Screw	M5 x 10L	8
13	EVTBS16V-C13	Air-Hydro Converter		1
14	EVTBS16V-C14	Tube Fitting(90° Elbow)	For Tube OD 8 mm, 1/4" NPT	4
15	EVTBS16V-C15	Plug	1/2" NPT	1
16	TS-2361061	Lock Washer	M6	2
17	TS-1503011	Socket Hd Cap Screw	M6 x 8L	2

mmToolParts
Big Time Experience. Small Town Service. .com

JET EVTBS16V-230 | Stock 891200

Diagram D - Table

Band Saw | Original JET parts reference



mmToolParts
Big Time Experience. Small Town Service. .com

JET EVTBS16V-230 | Stock 891200

Parts List D - Table

Band Saw | Original JET parts reference


Ref.	Part number	Description	Size	Qty.
19	EVTBS16V-D19	Right Table		1
20	EVTBS16V-D20	Left Table		1
21	TS-1525031	Set Screw	M10 x 16L	24
22	TS-1505041	Socket Hd Cap Screw	M10 x 30L	24
23	EVTBS16V-D23	T-Slot Nut	M10	1
24	EVTBS16V-D24	Base - Quick Action Clamp		1
25	EVTBS16V-D25	Hex Nut	M10 x 20L	1
26	EVTBS16V-D26	Quick Locked and Released Clamp		1
27	TS-2361081	Lock Washer	M8	4
28	TS-1504081	Socket Hd Cap Screw	M8 x 40L	4
29	EVTBS16V-D29	Font Vise		1
30	TS-1504051	Socket Hd Cap Screw	M8 x 25L	1
31	EVTBS16V-D31	Rear Vise		1
32	TS-2361121	Lock Washer	M12	2
33	TS-1492031	Hex Cap Screw	M12 x 35L	2
34	TS-2360121	Flat Washer	M12	1

mmToolParts
Big Time Experience. Small Town Service. .com

JET EVTBS16V-230 | Stock 891200

Diagram E - Bow

Band Saw | Original JET parts reference



mmToolParts
Big Time Experience. Small Town Service. .com

JET EVTBS16V-230 | Stock 891200

Parts List E - Bow

Band Saw | Original JET parts reference

Ref.	Part number	Description	Size	Qty.
1	TS-1513011	Socket Head Flat Screw	M5 x 10L	10
2	EVTBS16V-E2	Hinge-Upper Wheel Housing		1
3	TS-2361051	Lock Washer	M5	10
4	TS-1540041	Hex Nut	M5	10
5	TS-1512011	Socket Head Flat Screw	M4 x 8L	2
6	EVTBS16V-E6	Cover Stop (2 pcs)		1
7	EVTBS16V-E7	Bracket-Cover Stops		7
8	TS-1513011	Socket Head Flat Screw	M5 x 10L	2
9	TS-1512011	Socket Head Flat Screw	M4 x 8L	2
10	EVTBS16V-E10	Knob Screw	M6 x 40	1
11	TS-1540041	Hex Nut	M6	1
12	EVTBS16V-E12	Cover-Upper Wheel Housing		1
13	EVTBS16V-E13	Bow		1
14	EVTBS16V-E14	Upper Blade Wheel		1
15	5508675	Key, Dbl Rd Hd	10x8x30L	1
16	EVTBS16V-E16	Blade Wheel Washer		2
17	TS-2361121	Lock Washer	M12	2
18	TS-1492021	Hex Cap Screw	M12 x 30L	2
19	EVTBS16V-E19	Band Saw Blade	1-1/16 x 0.035 x 168-1/2"	1
20	EVTBS16V-E20	Shaft-Lower Blade Wheel		1
21	BB-6208ZZ	Ball Bearing	6208ZZ	2
22	EVTBS16V-E22	Lower Blade Wheel		1
23	EVTBS16V-E23	Wire Brush	Dia. 3"	1
24	EVTBS16V-E24	Wire Brush Mount		1

mmToolParts
Big Time Experience. Small Town Service. .com

JET EVTBS16V-230 | Stock 891200

Parts List E - Bow (continued)

Band Saw | Original JET parts reference

Ref.	Part number	Description	Size	Qty.
25	TS-1541021	Nylon Lock Hex Nut	M6, Nylon Insert	1
26	TS-2361061	Lock Washer	M6	2
27	TS-1503011	Socket Hd Cap Screw	M6 x 8L	2
28	TS-1491021	Hex Cap Screw	M10 x 20	2
29	TS-2361101	Lock Washer	M10	2
30	EVTBS16V-E30	Hinge-Lower Wheel Housing		2
31	EVTBS16V-E31	Knob Screw	M6 x 15L	2
32	EVTBS16V-E32	Cover-Lower Wheel Housing		1
33	EVTBS16V-E33	Bracket-Swivel Plate		1
34	EVTBS16V-E34	Swivel Plate		1
35	TS-1504051	Socket Hd Cap Screw	M8 x 25L	3
36	TS-1505021	Socket Hd Cap Screw	M10 x 20L	2
37	TS-1505041	Socket Hd Cap Screw	M10 x 30L	4
38	TS-2361101	Lock Washer	M10	6
39	TS-1525031	Set Screw	M10 x 16L	3
40	TS-2361101	Lock Washer	M10	3
41	TS-1505041	Socket Hd Cap Screw	M10 x 30L	3
42	TS-1503031	Socket Hd Cap Screw	M6 x 12L	6
43	EVTBS16V-E43	Locking Handle	M10 x 25L	1
44	EVTBS16V-E44	Cover-Upper Blade Guide Arm		1
45	EVTBS16V-E45	Washer-Upper Blade Guide Arm		1
46	TS-1503111	Socket Hd Cap Screw	M6 x 50	1
47	EVTBS16V-E47	Upper Blade Guide Arm		1
48	TS-1503011	Socket Hd Cap Screw	M6 x 8L	1
49	EVTBS16V-E49	Gear Rack	3/4" M2	1

mmToolParts
Big Time Experience. Small Town Service. .com

JET EVTBS16V-230 | Stock 891200

Parts List E - Bow (continued)

Band Saw | Original JET parts reference

Ref.	Part number	Description	Size	Qty.
50	TS-1502031	Socket Hd Cap Screw	M5 x 12L	3
51	BB-6002ZZ	Ball Bearing	6002ZZ	2
52	EVTBS16V-E52	Bracket-Upper Blade Guide Arm		1
53	F006043	C-Retaining Ring, Ext	S15	2
54	EVTBS16V-E54	Handwheel		2
55	EVTBS16V-E55	Handle-Handwheels		1
56	TS-1524021	Set Screw	M8 x 10L	1
57	EVTBS16V-E57	Shaft-Upper Blade Guide		1
58	KF2R5515	Key, Dbl Rd Hd	5x5x15L	2
59	EVTBS16V-E59	Gear	M2	1
60	TS-1504051	Socket Hd Cap Screw	M8 x 25L	4
61	TS-2361081	Lock Washer	M8	4
62	EVTBS16V-E62	Work Lamp	9W	1
63	EVTBS16V-E63	Bracket-Tension Screw		1
64	TS-1505111	Socket Hd Cap Screw	M10 x 70L	2
68	TS-1524021	Set Screw	M8 x 10L	2
70	KF2R5515	Key, Dbl Rd Hd	5x5x15L	1
71	F006093	C-Retaining Ring, Int	R85	1
72	BB-6209ZZ	Ball Bearing	6209ZZ	1
73	EVTBS16V-E73	Sliding Plate-Blade Tension		1
74	EVTBS16V-E74	Sliding Plate Guide		2
75	EVTBS16V-E75	Sliding Plate Adjuster		4
76	TS-2361081	Lock Washer	M8	4
77	TS-1490091	Hex Cap Screw	M8 x 50L	4

mmToolParts
Big Time Experience. Small Town Service. .com

JET EVTBS16V-230 | Stock 891200

Parts List E - Bow (continued)

Band Saw | Original JET parts reference


Ref.	Part number	Description	Size	Qty.
78	EVTBS16V-E78	Output Shaft		1
79	EVTBS16V-E79	Gear Box Assembly	1/30	1
80	F006051	C-Retaining Ring, Ext	S28	1
81	EVTBS16V-E81	Motor	2HP, 230/460V, 3-Phase	1
82	TS-1491041	Hex Cap Screw	M10 x 30L	4
83	TS-2361101	Lock Washer	M10	4
84	TS-1550071	Flat Washer	M10	4
85	TS-1504031	Socket Hd Cap Screw	M8 x 16L	2
86	TS-2361081	Lock Washer	M8	2
87	TS-1540081	Hex Nut	M12	2
89	EVTBS16V-E89	Screw-Adjusting Damper		1
90	EVTBS16V-E90	Extension Spring-Adjusting Damper		1
96	EVTBS16V-E96	Washer-Bow Pivot		1
97	EVTBS16V-E97	Locking Handle	M16 x 30L	1
98	EVTBS16V-E98	Handle-Bow Pivot		2
99	TS-1504031	Socket Hd Cap Screw	M8 x 16L	4
100	EVTBS16V-E100	Shipping Brace		1
101	TS-1550061	Flat Washer	M8(Dia. 18 mm)	2
103	TS-2228161	Hex Cap Screw	M8 x 16L	2
104	EVTBS16V-E104	Blade-Tension Gauge		1
105	EVTBS16V-E105	Blade-Tension Screw		1
106	EVTBS16V-E106	Collar-Tension Screw		1
107	EVTBS16V-E107	Truist Bearing	51104	1
108	EVTBS16V-E108	Bracket-Adjusting Damper		1
109	EVTBS16V-E109	Bonded Washer		2

mmToolParts
Big Time Experience. Small Town Service. .com

JET EVTBS16V-230 | Stock 891200

Diagram F - Guide Post

Band Saw | Original JET parts reference



mmToolParts
Big Time Experience. Small Town Service. .com

JET EVTBS16V-230 | Stock 891200

Parts List F - Guide Post

Band Saw | Original JET parts reference

Ref.	Part number	Description	Size	Qty.
9A	EVTBS16V-F9A	Lower Guide Assembly (F1-F15)		1
1	F006090	E-Retaining Ring	E7	2
2	BB-608ZZ	Ball Bearing	608ZZ	6
3	EVTBS16V-F3	Eccentric Roller Shaft		1
4	EVTBS16V-F4	Carbide Guide		2
5	EVTBS16V-F5	Concentric Roller Shaft		1
6	TS-1503061	Socket Hd Cap Screw	M6 x 25L	2
7	TS-2361061	Lock Washer	M6	2
8	TS-1505021	Socket Hd Cap Screw	M10 x 20L	3
9	EVTBS16V-F9	Arm-Lower Blade Guide		1
10	EVTBS16V-F10	Lower Blade Guide Block		1
11	TS-2361081	Lock Washer	M8	2
12	TS-1540061	Hex Nut	M8	2
13	TS-1505041	Socket Hd Cap Screw	M10 x 30L	2
14	BB-608ZZ	Ball Bearing	608ZZ	1
15	TS-1504031	Socket Hd Cap Screw	M8 x 16L	1
24A	EVTBS16V-F24A	Upper Guide Post Assembly		1
16	TS-1503061	Socket Hd Cap Screw	M6 x 25L	2
17	TS-2361061	Lock Washer	M6	2
18	EVTBS16V-F18	Carbide Guide		2
19	EVTBS16V-F19	Retaining Ring	E7	2
20	BB-608ZZ	Ball Bearing	608ZZ	6
21	EVTBS16V-F21	Eccentric Roller Shaft		1
22	EVTBS16V-F22	Concentric Roller Shaft		1
23	TS-1491041	Hex Cap Screw	M10 x 30L	2
24	EVTBS16V-F24	Upper Blade Guide Block		1

mmToolParts
Big Time Experience. Small Town Service. .com

JET EVTBS16V-230 | Stock 891200

Parts List F - Guide Post (continued)

Band Saw | Original JET parts reference


Ref.	Part number	Description	Size	Qty.
25	BB-608ZZ	Ball Bearing	608ZZ	1
26	EVTBS16V-F26	Shaft-Back Roller Bearing		1
27	TS-2361081	Lock Washer	M8	2
28	TS-1540061	Hex Nut	M8	2
31	EVTBS16V-F31	Upper Blade Guard		1
32	TS-1503011	Socket Hd Cap Screw	M6 x 8L	2
33	EVTBS16V-F33	Lower Blade Guard		1
34	TS-1503011	Socket Hd Cap Screw	M6 x 8L	2
35	TS-1504051	Socket Hd Cap Screw	M8 x 25L	4
36	TS-2361081	Lock Washer	M8	4
37	TS-1540041	Hex Nut	M5	1
38	TS-1522041	Set Screw	M5 x 12L	1
39	EVTBS16V-F39	Indicator-Pivot Gauge		1
40	TS-1550031	Flat Washer	M5	2
41	EVTBS16V-F41	Shaft-Indicator Block		1
42	BB-608ZZ	Ball Bearing	608ZZ	1
43	TS-1504031	Socket Hd Cap Screw	M8 x 16L	1
44	EVTBS16V-F44	Spring-Indicator Block		1
45	EVTBS16V-F45	Pivot Indicator Block		1
46	TS-1540061	Hex Nut	M8	1
47	TS-1504071	Hex Nut	M8 x 35L	1
48	EVTBS16V-F48	Fitting	For Hose ID 3/8", 1/4" NPT	1
49	EVTBS16V-F49	Coolant Valve Switch	Female x Female, 1/4" NPT	1
50	EVTBS16V-F50	Metal Coolant Hose	1/4" NPT	1
51	EVTBS16V-F51	Valve Holder		1
52	TS-2361061	Lock Washer	M6	2
53	TS-1503011	Socket Head Cap Screw	M6x8	2

mmToolParts
Big Time Experience. Small Town Service. .com

JET EVTBS16V-230 | Stock 891200

Diagram G - Electrical Box

Band Saw | Original JET parts reference



mmToolParts
Big Time Experience. Small Town Service. .com

JET EVTBS16V-230 | Stock 891200

Parts List G - Electrical Box

Band Saw | Original JET parts reference

Ref.	Part number	Description	Size	Qty.
1	EVTBS16V-G1	Electrical Box Weldment		1
2	EVTBS16V-G2	Electrical Box Cover		1
3	TS-1503061	Socket Hd Cap Screw	M6 x 25L	2
4	TS-1550041	Flat Washer	M6	2
5	TS-1540041	Hex Nut	M6	2
6	EVTBS16V-G6	Tube Fitting	For Tube OD 8 mm, 1/4" NPT	2
7	TS-1501081	Socket Head Cap Screw	M4 x 30L	2
8	EVTBS16V-G8	Solenoid Valve		1
9	EVTBS16V-G9	Breather Vent		2
10	EVTBS16V-G10	Tube Fitting (90° Elbow)	For Tube OD 8 mm, 1/4" NPT	1
11	TS-1540021	Hex Nut	M4	2
12	F010991	Socket Head Flat Screw	M4 x 30L	1
13	EVTBS16V-G13	Tooth Washer	M5	2
14	TS-1540021	Hex Nut	M4	3
15	TS-1513031	Socket Hd Flat Screw	M5 x 10L	2
16	TS-2361061	Lock Washer	M6	2
17	EVTBS16V-G17	Lower Bushing-Control Box Support		1
18	TS-1503011	Socket Hd Cap Screw	M6 x 8L	4
19	TS-2361061	Lock Washer	M6	4
20	TS-1540021	Hex Nut	M4	2
21	EVTBS16V-G21	Limit Switch		1
22	F010991	Socket Head Flat Screw	M4 x 30L	2
23	EVTBS16V-G23	Tube Fitting (90° Elbow)	For Tube OD 8 mm, 1/4" NPT	2
24	EVTBS16V-G24	Compressed Air Regulator		1

mmToolParts
Big Time Experience. Small Town Service. .com

JET EVTBS16V-230 | Stock 891200

Parts List G - Electrical Box (continued)

Band Saw | Original JET parts reference

Ref.	Part number	Description	Size	Qty.
25	EVTBS16V-G25	Decrease or Increase Decal		1
26	EVTBS16V-G26	Pressure Gauge		1
27	EVTBS16V-G27	Tube Fitting (90° Elbow)	For Tube OD 8 mm, 1/8" NPT	1
28	EVTBS16V-G28	Connector	1/4" Female	1
29	EVTBS16V-G29	Tube Fitting	For Tube OD 8 mm, 1/4" NPT	1
30	TS-1503011	Socket Head Cap Screw	M6 x 8L	4
31-1	EVTBS16V-G31-1	Electrical Plate		1
31-2	EVTBS16V-G31-2	Rail		3
31-3	EVTBS16V-G31-3	Terminal Block	50A/600V	2
31-4	EVTBS16V-G31-4	Main Power Switch		1
31-5	EVTBS16V-G31-5	Transformer	153VA/ 230/460V-24V	1
31-6	EVTBS16V-G31-6	Wiring Duct		4
31-7	EVTBS16V-G31-7	Fuse Block	10x38	2
31-8	EVTBS16V-G31-8	Fuse Block	5x10	1
31-9	EVTBS16V-G31-9	Fuse Block	5x10	2
31-10	EVTBS16V-G31-10	Relay Socket	PYF-14AE	1
31-11	EVTBS16V-G31-11	Relay Socket	PYF-08AE	2
31-12	EVTBS16V-G31-12	Fuse for 460V	10x38 mm (1A)	2
	EVTBS16V-FU2A	Fuse for 230V	10x38 mm (2A)	2
31-13	EVTBS16V-G31-13	Fuse	5x10 mm (5A)	1
31-14	EVTBS16V-G31-14	Fuse	5x10 mm (1A)	2
31-15	EVTBS16V-G31-15	Relay	BMY5-4C5	1
31-16	EVTBS16V-G31-16	Relay	BMY5-2C5	2
31-17	EVTBS16V-G31-17	Potentiometer	RV24YN	1
31-18	EVTBS16V-G31-18	Pushbutton Switch With Light	NLB22-F10GA	1

mmToolParts
Big Time Experience. Small Town Service. .com

JET EVTBS16V-230 | Stock 891200

Parts List G - Electrical Box (continued)

Band Saw | Original JET parts reference

Ref.	Part number	Description	Size	Qty.
31-19	EVTBS16V-G31-19	Pilot Light(Red)	NLD22-R	1
31-20	EVTBS16V-G31-20	E-Stop Button	NPB22-T01R	1
31-21	EVTBS16V-G31-21	Selector Switch	NSS22-S210B	1
31-22	EVTBS16V-G31-22	Selector Switch	NSS22-S210B	1
31-23	EVTBS16V-G31-23	Pushbutton Switch(Red)	NPB22-F01R	1
31-24	EVTBS16V-G31-24	Pushbutton Switch(Red)	NPB22-F01G	1
31-25	EVTBS16V-G31-25	Ground Wire-Control Box		1
31-26	EVTBS16V-G31-26	Ground Copper Bar		1
32	EVTBS16V-G32	AC Motor Controller		1
	EVTBS16V-G32/4	AC Motor Controller	460V / 3Ph	1
32-1	EVTBS16V-G32-1	Keypad (Blade Speed Readout)	KP601A	1
	EVTBS16V-G32-1-4	Keypad (Blade Speed Readout)	KP603	1
33	EVTBS16V-G33	Tooth Washer	M5	1
34	TS-1540041	Hex Nut	M5	1
35	TS-1513011	Socket Head Flat Screw	M5 x 10L	9
36	EVTBS16V-G36	Control Panel		1
37	TS-1503031	Socket Hd Cap Screw	M6 x 12L	2
38	TS-2361061	Lock Washer	M6	2
39	EVTBS16V-G39	Control Box		1
40	EVTBS16V-G40	Upper Bushing-Control Box Support		1
41	EVTBS16V-G41	Locking Handle	M8 x 25L	1
42	EVTBS16V-G42	Handle-Control Box		1
43	TS-1504021	Socket Hd Cap Screw	M8 x 12L	2
44	EVTBS16V-G44	Control Box Support		1
45	F006053	C-Retaining Ring, Ext	S32	1

mmToolParts
Big Time Experience. Small Town Service. .com